

### **OPERATOR'S MANUAL**

MODEL #100458 1200W PORTABLE GENERATOR



**REGISTER YOUR PRODUCT ONLINE** 

at championpowerequipment.com















or visit championpowerequipment.com

**READ AND SAVE THIS MANUAL.** This manual contains important safety precautions which should be read and understood before operating the product. Failure to do so could result in serious injury. This manual should remain with the product.

Specifications, descriptions and illustrations in this manual are as accurate as known at the time of publication, but are subject to change without notice.

TABLE OF CONTENTS	
Introduction	3
Safety Definitions	3
Important Safety Instructions	4
Fuel Safety	
Safety Symbols	7
Operation Symbols	8
Safety Labels	9
Controls and Features	10
Generator	
Control Panel	
Parts Included	
Assembly	
<u>Unpacking</u>	
Attach Vibration Mounts	
Add Engine Oil	
Add Fuel	
Grounding	
Operation	
Generator Location	
Grounding*	
Surge Protection	
Starting the Engine Connecting Electrical Loads	
Do Not Overload Generator	
Stopping the Engine.	
<u>Maintenance</u>	
Cleaning the Generator	
Changing the Engine Oil	
Cleaning and Adjusting the Spark Plug(s)	
Cleaning the Air Filter	
Cleaning the Spark Arrestor	
Adjusting the Governor	
Maintenance Schedule	
Storage	
Short Term Storage (up to 1 year)	
Long Term Storage (over 1 year)	
Removing from Storage	20

<u>Specifications</u>	21
Generator Specifications	21
Engine Specifications	21
Oil Specifications	21
Fuel Specifications	21
Spark Plug Specifications.	21
Valve Specifications	21
Temperature Specifications	21
IC Warning	21
Parts Diagram	22
Parts List	23
Engine Parts Diagram	24
Engine Parts List	25
Wiring Diagram	27
Troubleshooting	28

#### INTRODUCTION

Congratulations on your purchase of a Champion Power Equipment (CPE) product. CPE designs, builds, and supports all of our products to strict specifications and guidelines. With proper product knowledge, safe use, and regular maintenance, this product should bring years of satisfying service.

Every effort has been made to ensure the accuracy and completeness of the information in this manual at the time of publication, and we reserve the right to change, alter and/ or improve the product and this document at any time without prior notice.

Since CPE highly values how our products are designed, manufactured, operated and are serviced, and also highly value your safety and the safety of others, we would like you to take the time to review this product manual and other product materials thoroughly and be fully aware and knowledgeable of the assembly, operation, dangers and maintenance of the product before use. Fully familiarize yourself, and make sure others who plan on operating the product fully familiarize themselves too, with the proper safety and operation procedures before each use. Please always exercise common sense and always err on the side of caution when operating the product to ensure no accident, property damage, or injury occurs. We want you to continue to use and be satisfied with your CPE product for years to come.

When contacting CPE about parts and/or service, you will need to supply the complete model and serial numbers of your product. Transcribe the information found on your product's nameplate label to the table below

CPE TECHNICAL SUPPORT TEAM
1-877-338-0999
MODEL NUMBER
100458
SERIAL NUMBER
DATE OF PURCHASE
PURCHASE LOCATION

#### **SAFETY DEFINITIONS**

The purpose of safety symbols is to attract your attention to possible dangers. The safety symbols, and their explanations, deserve your careful attention and understanding. The safety warnings do not by themselves eliminate any danger. The instructions or warnings they give are not substitutes for proper accident prevention measures.

#### **A** DANGER

DANGER indicates a hazardous situation which, if not avoided, will result in death or serious injury.

#### **A WARNING**

WARNING indicates a hazardous situation which, if not avoided, could result in death or serious injury.

#### **A** CAUTION

CAUTION indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.

#### NOTICE

NOTICE is used to address practices not related to physical injury.

#### **IMPORTANT SAFETY INSTRUCTIONS**

#### **A** DANGER

Generator exhaust contains carbon monoxide, a colorless, odorless, poison gas. Breathing carbon monoxide will cause nausea, dizziness, fainting or death. If you start to feel dizzy or weak, get to fresh air immediately.

## OPERATE GENERATOR OUTDOORS ONLY IN A WELL VENTILATED AREA.

DO NOT operate the generator inside any building, including garages, basements, crawlspaces and sheds, enclosure or compartment, including the generator compartment of a recreational vehicle.

DO NOT allow exhaust fumes to enter a confined area through windows, doors, vents or other openings.

#### **A** DANGER

Using a generator indoors **CAN KILL YOU IN MINUTES**. Generator exhaust contains carbon monoxide. This is a poison you cannot see or smell.

**NEVER** use inside a home or garage, **EVEN IF** doors and windows are open.

**ONLY** use **OUTSIDE** and far away from windows, doors, and vents.



Install battery-operated carbon monoxide alarms or plug-in carbon monoxide alarms with battery back-up according to the manufacturer's instructions.

#### **A** DANGER

Rotating parts can entangle hands, feet, hair, clothing and/ or accessories. Traumatic amputation or severe laceration can result.

Keep hands and feet away from rotating parts.

Tie up long hair and remove jewelry.

Operate equipment with guards in place.

DO NOT wear loose-fitting clothing, dangling drawstrings or items that could become caught.

#### **A WARNING**

Operation of this equipment may create sparks that can start fires around dry vegetation.

A spark arrestor may be required. The operator should contact local fire agencies for laws or regulations relating to fire prevention requirements.

#### **A** DANGER

Generator produces powerful voltage.

DO NOT touch bare wires or receptacles.

DO NOT use electrical cords that are worn, damaged or frayed. Use Champion electrical cords only for proper application.

DO NOT operate generator in wet weather.

DO NOT allow children or unqualified persons to operate or service the generator

Use a ground fault circuit interrupter (GFCI) in damp areas and areas containing conductive material such as metal decking.

Connection to your home's electrical system requires a listed 30A transfer switch installed by a licensed electrician and approved by the local authority having jurisdiction. The connection must isolate the generator from the utility power and must comply with all applicable laws and electrical codes.

#### **A WARNING**

Sparks can result in fire or electrical shock.

#### When servicing the generator:

Disconnect the spark plug wire and place it where it cannot contact the plug.

DO NOT check for spark with the plug removed.

Use only approved spark plug testers.

#### **A WARNING**

Running engines produce heat. Severe burns can occur on contact. Combustible material can catch fire on contact.

DO NOT touch hot surfaces.

Avoid contact with hot exhaust gases.

Allow equipment to cool before touching.

Maintain at least 3 ft. (91.4 cm) of clearance on all sides to ensure adequate cooling.

Maintain at least 5 ft. (1.5 m) of clearance from combustible materials.

#### **A WARNING**

Rapid retraction of the starter cord will pull hand and arm towards the engine faster than you can let go. Unintentional startup can result in entanglement, traumatic amputation or laceration. Broken bones, fractures, bruises or sprains could result.

When starting engine, pull the starter cord slowly until resistance is felt and then pull rapidly to avoid kickback.

DO NOT start or stop the engine with electrical devices plugged in and turned on.

#### **A** CAUTION

Exceeding the generator's running capacity can damage the generator and/or electrical devices connected to it.

DO NOT overload the generator.

DO NOT tamper with the governed speed.

DO NOT modify the generator in any way.

#### **A** CAUTION

Start the generator and allow the engine to stabilize before connecting electrical loads.

Connect electrical equipment in the off position, and then turn them on for operation.

Turn electrical equipment off and disconnect before stopping the generator.

#### **A** CAUTION

Improper treatment or use of the generator can damage it, shorten its life and void your warranty.

Use the generator only for intended uses.

Operate only on level surfaces.

DO NOT expose generator to excessive moisture, dust, or dirt.

DO NOT allow any material to block the cooling slots.

If connected devices overheat, turn them off and disconnect them from the generator.

#### DO NOT use the generator if:

- Electrical output is lost
- Equipment sparks, smokes or emits flames
- Equipment vibrates excessively

#### **A WARNING**

Medical and life support uses.

In case of emergency, call 911 immediately.

NEVER use this product to power life support devices or life support appliances.

NEVER use this product to power medical devices or medical appliances.

Inform your electricity provider immediately if you or anyone in your household depends on electrical equipment to live.

Inform your electrical provider immediately if a loss of power would cause you or anyone in your household to experience a medical emergency.

#### **Fuel Safety**

#### **A** DANGER

GASOLINE, GASOLINE VAPORS AND PROPANE (LPG) ARE HIGHLY FLAMMABLE AND EXPLOSIVE.

Fire or explosion can cause severe burns or death.

#### Gasoline and gasoline vapors:

- Gasoline is highly flammable and explosive.
- Gasoline can cause a fire or explosion if ignited.
- Gasoline is a liquid fuel but it's vapors can ignite.
- Gasoline is a skin irritant and needs to be cleaned up immediately if spilled on skin or clothes.
- Gasoline has a distinctive odor, this will help detect potential leaks quickly.
- In any petroleum gas fire, flames should not be extinguished unless by doing so the fuel supply valve can be turned OFF.
   This is because if a fire is extinguished and a supply of fuel is not turned OFF, then an explosion hazard could be created.
- Gasoline expands or contracts with ambient temperatures.
   Never fill the gasoline tank to full capacity, as gasoline needs room to expand if temperatures rise.

#### LPG:

- LPG is highly flammable and explosive.
- LPG is under pressure and can cause a fire or explosion if ignited.
- LPG is heavier than air and can settle in low places while dissipating.
- LPG has a distinctive odor added to help detect potential leaks quickly.
- In any petroleum gas fire, flames should not be extinguished unless the fuel supply valve is turned OFF. This is because if a fire is extinguished and a supply of fuel is not turned OFF, then an explosion hazard could be created.
- When exchanging LPG cylinders, be sure the cylinder valve is of the same type.
- Always keep the LPG cylinder in an upright position.
- LPG will burn skin if it comes in contact with it. Keep any and all LPG away from skin at all times.

#### When adding or removing gasoline:

Turn the generator off and let it cool for at least two minutes before removing the gasoline cap. Loosen the cap slowly to relieve pressure in the tank.

Only fill or drain gasoline outdoors in a well-ventilated area.

DO NOT pump gasoline directly into the generator at the gas station. Use an approved container to transfer the fuel to the generator.

DO NOT overfill the gasoline tank.

Always keep gasoline away from sparks, open flames, pilot lights, heat and other sources of ignition.

DO NOT light or smoke cigarettes.

#### When starting the generator:

DO NOT attempt to start a damaged generator.

Make certain that the gasoline cap, air filter, spark plug, fuel lines and exhaust system are properly in place.

Allow spilled gasoline to evaporate fully before attempting to start the engine.

Make certain that the generator is resting firmly on level ground.

#### When operating the generator:

DO NOT move or tip the generator during operation.

DO NOT tip the generator or allow fuel or oil to spill.

#### When transporting or servicing the generator:

Make certain that the fuel valve is in the OFF position, the gasoline tank is empty.

For LPG compatible models, be sure that the LPG cylinder is disconnected and stored securely away from the generator.

Disconnect the spark plug wire.

#### When storing the generator:

Store away from sparks, open flames, pilot lights, heat and other sources of ignition.

Do not store generator, gasoline or LPG cylinders near furnaces, water heaters, or any other appliances that produce heat or have automatic ignitions.

#### **A WARNING**

Never use a gasoline container, gasoline tank, LPG connector hose, LPG cylinder or any other fuel item that is damaged or appears damaged.

#### **Safety Symbols**

Some of the following symbols may be used on this product. Please study them and learn their meaning. Proper interpretation of these symbols will allow you to more safely operate the product.

SYMBOL	MEANING
	Read Operator's Manual. To reduce the risk of injury, user must read and understand operator's manual before using this product.
↑ • • • • • • • • • • • • • • • • • • •	Clearance. Keep all objects at least 5 feet from this machine. Heat from the muffler and exhaust gas can ignite combustible objects.
	Ground. Consult with local electrician to determine grounding requirements before operation.
4	<b>Electric Shock.</b> Failure to use in dry conditions and to observe safe practices can result in electric shock. Improper connections to a building can allow current to backfeed into utility lines, creating an electrocution hazard. A transfer switch must be used when connecting to a building.
	Fire/Explosion. Fuel and its vapors are extremely flammable and explosive. Fire or explosion can cause severe burns or death. Operation of this equipment may create sparks that can start fires around dry vegetation. A spark arrestor may be required. The operator should contact local fire agencies for laws or regulations relating to fire prevention requirements.
	Hot Surface. To reduce the risk of injury or damage, avoid contact with any hot surface.
	Open Flame Alert. Fuel and its vapors are extremely flammable and explosive. Keep fuel away from smoking, open flames, sparks, pilot lights, heat, and other ignition sources.
	Wet Conditions Alert. Do not expose to rain or use in damp locations.

#### **Operation Symbols**

Some of the following symbols may be used on this product. Please study them and learn their meaning. Proper interpretation of these symbols will allow you to more safely operate the product.


SYMBOL	MEANING
<b>6 6</b>	Start.
10W-30	Check Oil Level. Recommended oil is 10W-30. The engine can be seriously damaged without oil. Always check the oil level before using. The machine must be resting firmly on level ground when checking.
	Check Fuel Level. Use clean, fresh, regular unleaded gasoline with a minimum octane rating of 85 and an ethanol content of less than 10% by volume.
	Fuel Valve ON.
100	Engine Switch ON. Press the Engine Switch to "ON" position.
<u>\</u>	<b>Choke.</b> Move choke lever to "CHOKE" position.
*	Recoil Starter. Pull recoil starter to start the engine.
<b>∓</b>	<b>Choke.</b> Move choke lever to "RUN" position.
4	Plug In. Plug in desired devices.
4	<b>Unplug.</b> Unplug devices when turning generator off.

SYMBOL	MEANING
	Engine Switch OFF. Press the Ignition Switch to "OFF" position.
	Fuel Valve OFF.
<b>3 4</b>	Stop.
<b>√</b>	<b>Hertz.</b> Shown on Intelligauge as "F##.#"
V	<b>Volts.</b> Shown on Intelligauge as "U###"
U	Runtime. Shown on Intelligauge as "###.#"
4	Engine ON
0	Engine OFF

#### **Safety Labels**

These labels warn you of potential hazards that can cause serious injury. Read them carefully.

If a label comes off or becomes hard to read, contact Technical Support Team for possible replacement.




	LABEL	DESCRIPTION
Α	Using a generator indoors CAN KILL YOU IN MINUTES. Generator exhaust contains carbon monoxide. This is a poison you cannot see or smell.  NEVER use inside a home or garage, EVEN IF doors and windows are open.  A PELIGRO  EL use de un generator en interiores PUEDE MATARLO EN MINUTOS. El escape del generador contiene monóxido de carbono. Este es un veneno que no se puede un os en puede de lo use dentro del hogar ni el garaje, INCLUSO SI las puertas y ventanas están abiertas. Uselo SOLO a la INTEMPERIE lejos de ventanas, puertas, y orificios de ventilación.  A DANGER  Utiliser un générateur à l'intérieur PEUT VOUS TUER EN QUELQUES MINUTES. L'échappement du générateur contient du monoxyde de carbono. Il s'agit d'un poison que vous ne pouvez ni voir ni sentir. Ne l'utilisez JAMAIS dans la maison ou le garage MEME SI es portes et les fenères sorti ouvertes. Utilisez-e builque MEME SI es portes et les fenères sorti ouvertes. Utilisez-e builque MEME SI es portes et l'appes de ventilación.	CO Danger
В	FILL SFA	Safety Icons
С	UNLEADED FUEL ONLY. Minimum octane rating of 85. Maximum 10% ethanol.  GASOLINA REGULAR SOLAMENTE. 85 octanos como minimo. Máximo de etanol de 10%.  ESSENCE SANS PLOMB SEULEMENT. Indice d'octane minimal de 85. Maximum 10% d'éthanol.	Fuel
D	A ADVERTISEMENT  Both of program  Both o	Hot Surface
Ε	A WARNING  Coverage the special power representations of the special power personal power and power representations of the special power personal power representations of the special power personal power representations of the special power personal power perso	Spark Arrestor

#### **CONTROLS AND FEATURES**

Read this operator's manual before operating your generator. Familiarize yourself with the location and function of the controls and features. Save this manual for future reference.


#### **Generator**



- 1. **Gasoline Tank** 1.9 gal. (7 L)
- 2. Choke Used to start the engine.
- 3. Fuel Valve Used to turn fuel supply on and off to engine.
- 4. **Air Filter** Protects the engine by filtering dust and debris from the intake air.
- 5. **Recoil Starter** Used to manually start the engine.

- 6. Oil Fill Cap/Dipstick Used to check and fill oil level.
- 7. **Control Panel** See "Control Panel" section.
- 8. Carrying Handle(s) Used to lift or carry the unit.
- 9. **Ground Terminal** Consult an electrician for local grounding regulations.

#### **Control Panel**




- Circuit Breakers (Push Reset) Protects the generator against electrical overloads.
- 2. **Intelligauge** Three mode digital meter for displaying running time, voltage and hertz.
- 3. Engine Switch Used to START or STOP the generator.

# RECEPTAGLES (2x) 120V AC, 20A (NEMA 5-20R) May be used to supply electrical power for operation of 120 Volt AC, 20 Amp, single phase, 60 Hz electrical loads.

#### **Parts Included**

#### **Accessories**

Oil Funnel......1



#### **Assembly Parts**

Vibration Mounts (engine side) (A)	. 2
Vibration Mounts (alternator side) (B)	. 2
Flange Bolt M8 × 20 (C)	. 2
Lock Nut M8 (D)	. 4

#### **ASSEMBLY**

Your generator requires some assembly. This unit ships from our factory without oil. It must be properly serviced with fuel and oil before operation.

If you have any questions regarding the assembly of your generator, call our Technical Support Team at 1-877-338-0999. Please have your serial number and model number available.


#### **Unpacking**

- 1. Set the shipping carton on a solid, flat surface.
- 2. Remove everything from the carton except the generator.
- Carefully cut each corner of the box from top to bottom.Fold each side flat on the ground to provide a surface area to work with the generator.

#### **Attach Vibration Mounts**


#### **Attach the Engine Vibration Mounts**

- 1. Thread the vibration mount bolt (A) through the frame (engine side).
- 2. Firmly secure the vibration mount bolt to the frame with the M8 lock nut (D). DO NOT over tighten.
- 3. Repeat steps 1-2 for the remaining mount (2 total).



#### **Attach the Alternator Vibration Mounts**

- 1. Thread the flange bolt (C) through the vibration mount (B) and then through the frame (alternator side).
- 2. Firmly secure the bolt to the frame with the M8 lock nut (D). DO NOT over tighten.
- 3. Repeat steps 1-2 for the remaining mount (2 total).



#### **Add Engine Oil**

#### **A** CAUTION


DO NOT attempt to crank or start the engine before it has been properly filled with the recommended type and amount of oil. Damage to the generator as a result of failure to follow these instructions will void your warranty.

#### NOTICE


The generator rotor has a sealed, pre-lubricated ball bearing that requires no additional lubrication for the life of the bearing.

#### NOTICE


The recommended oil type is 10W-30 automotive oil.



- 1. Place the generator on a flat, level surface.
- 2. Remove oil fill cap/dipstick to add oil.
- 3. Using a funnel, add up to 0.4 qt. (0.4 L) of oil (not included) and replace oil fill cap/dipstick. DO NOT OVERFILL.



4. Check engine oil level daily and add as needed.



#### NOTICE

Once oil has been added, a visual check should show oil about 1-2 threads from running out of the fill hole.

If using the dipstick to check oil level, DO NOT screw in the dipstick while checking.

#### NOTICE

Check oil often during the break-in period. Refer to the Maintenance section for recommended service intervals.

#### **A** CAUTION

The engine is equipped with a low oil shut-off and will stop when the oil level in the crankcase falls below the threshold level.

#### NOTICE

The first 5 hours of run time are the break-in period for the unit. During the break in period stay at or below 50% of the running watt rating and vary the load occasionally to allow stator windings to heat and cool. Adjusting the load will also cause engine speed to vary and help seat piston rings. After the 5 hour break-in period, change the oil.

#### NOTICE


Weather will affect engine oil and engine performance. Change the type of engine oil used based on weather conditions to suit the engine needs.

#### NOTICE

Synthetic oil may be used after the 5 hour initial breakin period. Using synthetic oil does not increase the recommended oil change interval. Full synthetic 5W-30 oil will aid in starting in cold ambient <5° C (41° F).

#### **Add Fuel**

- Use clean, fresh, regular unleaded gasoline with a minimum octane rating of 85 and an ethanol content of less than 10% by volume.
- 2. DO NOT mix oil with gasoline.
- 3. Remove the gasoline cap.
- 4. Slowly add gasoline to the tank. Tank is full when gasoline reaches red circle on screen. DO NOT OVERFILL. Gasoline can expand after filling. A minimum of ¼ in. (6.4 mm) of space left in the tank is required for gasoline expansion, although more than ¼ in. (6.4 mm) is recommended. Gasoline can be forced out of the tank as a result of expansion if overfilled, and can affect the stable running condition of the generator.



5. Screw on the gasoline cap and wipe away any spilled fuel.

#### **A** CAUTION

Use regular unleaded gasoline with a minimum octane rating of 85 and an ethanol content of less than 10% by volume.

DO NOT mix oil and gasoline.

Fill tank to approximately ¼ in. (6.4 mm) below the top of the tank to allow for gasoline expansion.

DO NOT pump gasoline directly into the generator at the pump. Use an approved container to transfer the gasoline to the generator.

DO NOT fill tank indoors.

DO NOT fill tank when the engine is running or hot.

DO NOT overfill the tank.

DO NOT light cigarettes or smoke when filling the tank.

#### **A WARNING**

Pouring gasoline too fast through the fuel screen may result in blow back of gasoline at the operator while filling.

#### NOTICE

Our engines work well with 10% or less ethanol blend gasoline. When using ethanol-gasoline blends there are some issues worth noting:

- Ethanol-gasoline blends can absorb more water than gasoline alone.
- These blends can eventually separate, leaving water or a watery goo in the tank, fuel valve and carburetor.
- With gravity-fed supplies, the compromised gasoline can be drawn into the carburetor and cause damage to the engine and/or potential hazards.
- There are only a few suppliers of fuel stabilizer that are formulated to work with ethanol-gasoline blends.
- Any damages or hazards caused by using improper gasoline, improperly stored gasoline, and/or improperly formulated stabilizers, are not covered by manufacturer's warranty.

It is advisable to always shut off the gasoline supply, run the engine to starvation and drain the tank when the equipment is not in use for more than 30 days.

#### Grounding

Your generator must be properly connected to an appropriate ground to help prevent electric shock.

#### **A WARNING**

Failure to properly ground the generator can result in electric shock.

A ground terminal connected to the frame of the generator has been provided (see <u>Controls and Features</u> for terminal location). For remote grounding, connect of a length of heavy gauge (12 AWG minimum) copper wire between the generator ground terminal and a copper rod driven into the ground. We strongly recommend that you consult with a qualified electrician to ensure compliance with local electrical codes.

#### **OPERATION**

#### **Generator Location**

NEVER operate the generator inside any building, including garages, basements, crawlspaces and sheds, enclosure or compartment, including the generator compartment of a recreational vehicle. Please consult your local authority. In some areas, generators must be registered with the local utility. Generators used at construction sites may be subject to additional rules and regulations. Generators should be on a flat, level surface at all times. (Even while not in operation) Generators must have at least 5 ft. (1.5 m) of clearance from all combustible material. In addition to clearance from all combustible material, generators must also have at least 3 ft. (91.4 cm) of clearance on all sides to allow for adequate cooling, maintenance and servicing. Generators should never be started or operated in the back of a SUV, camper, trailer, in the bed of a truck (regular, flat or otherwise), under staircases/stairwells, next to walls or buildings, or in any other location that will not allow for adequate cooling of the generator and/or the muffler. DO NOT contain generators during operation. Allow generators to properly cool before transport or storage.

Install battery-operated carbon monoxide alarms or plug-in carbon monoxide alarms with battery back-up in your home according to the manufacturer's instructions.

Place the generator in a well-ventilated area. DO NOT place the generator near vents or intakes where exhaust fumes could be drawn into occupied or confined spaces. Carefully consider wind and air currents when positioning generator.

Failure to follow proper safety precautions may void manufacturer's warranty.

#### **A** WARNING

Do not operate or store the generator in rain, snow, or wet weather.

Using a generator or electrical appliance in wet conditions, such as rain or snow, or near a pool or sprinkler system, or when your hands are wet, could result in electrocution.

#### **A WARNING**

During operation the muffler and exhaust fumes produced will become hot. If adequate cooling and breathing space are not supplied, or if the generator is blocked or contained, temperatures can become extremely heated and may lead to fire.

#### **Grounding**

A ground terminal connected to the frame of the generator has been provided (see Controls and Features for terminal location).

#### **Neutral Floating\***

- Neutral circuit IS NOT electrically connected to the frame/ ground of the generator.
- The generator (stator winding) is isolated from the frame and from the AC receptacle ground pin.
- Electrical devices that require a grounded receptacle pin connection will not function if the receptacle ground pin is not functional.

#### **Neutral Bonded to Frame\***

- Neutral circuit IS electrically connected to the frame/ground of the generator.
- The generator system ground connects lower frame cross-member below the alternator. The system ground is connected to the AC neutral wire.

#### **Surge Protection**

Electronic devices, including computers and many programmable appliances use components that are designed to operate within a narrow voltage range and may be affected by momentary voltage fluctuations. While there is no way to prevent voltage fluctuations, you can take steps to protect sensitive electronic equipment.

 Install UL1449, CSA-listed, plug-in surge suppressors on the outlets feeding your sensitive equipment.
 Surge suppressors come in single- or multi-outlet styles.
 They're designed to protect against virtually all shortduration voltage fluctuations.

#### **Starting the Engine**

- 1. Make certain the generator is on a flat, level surface.
- Disconnect all electrical loads from the generator. Never start or stop the generator with electrical devices plugged in or turned on.
- 3. Turn the gasoline fuel valve to the "ON" position.
- 4. Move the choke to the "CHOKE" position.
- 5. For restarting a warm engine, move the choke to 75% of the "CHOKE" position.
- 6. Push the engine switch to the "ON" position.
- Pull the starter cord slowly until resistance is felt and then pull rapidly
- 8. Do not over-choke. As soon as engine starts, move the choke to the "RUN" position over a 2-5 second duration.

#### NOTICE

Keep choke in "CHOKE" position for only 1 pull of the recoil starter. After first pull, move choke to the "RUN" position for up to the next 3 pulls of the recoil starter. Too much choke leads to spark plug fouling/engine flooding due to the lack of incoming air. This will cause the engine not to start.

#### NOTICE

For gasoline restarts with hot engine in hot ambient  $> 30^{\circ}$ C (86°F), keep the choke in 75% of the "CH0KE" position for only 1 pull of the recoil starter. After first pull, move choke to the "RUN" position for up to 3 more pulls of the recoil starter. Too much choke leads to spark plug fouling/engine flooding due to the lack of incoming air. This will cause the engine not to start.

#### NOTICE

For gas starting in cold ambient <15°C (59°F) the choke must be in 100% of the "CHOKE" position for recoil start procedures. Do not over-choke. As soon as engine starts, gradually move the choke lever to the "RUN" position over a 2-5 second duration.

#### NOTICE

If the engine starts but does not continue to run make certain that the generator is on a flat, level surface. The engine is equipped with a low oil sensor that will prevent the engine from running when the oil level falls below a critical threshold.

#### **Connecting Electrical Loads**

Let the engine stabilize and warm up for a few minutes after starting.

Plug in and turn on the desired 120 or 240 (if applicable) Volt AC single phase, 60 Hz electrical loads.

- DO NOT connect 3-phase loads to the generator.
- D0 N0T connect 50 Hz loads to the generator.
- DO NOT overload the generator.

<sup>\*</sup>See your model's control panel for specified type of grounding.

#### **A WARNING**

Connecting a generator to your electric utility company's power lines or to another power source may be against the law. In addition this action, if done incorrectly, could damage your generator and appliances and could cause serious injury or even death to you or a utility worker who may be working on nearby power lines. If you plan to run a portable electric generator during an outage, please notify your electric utility company immediately and remember to plug your appliances directly into the generator. Do not plug the generator into any electric outlet in your home. Doing so could create a connection to the utility company power lines. You are responsible for ensuring that your generator's electricity does not feed back into the electric utility power lines.

If the generator will be connected to a building electrical system, consult your local utility company or a qualified electrician. Connections must isolate generator power from utility power and must comply with all applicable laws and codes.

#### **Do Not Overload Generator**

#### Capacity

Follow these simple steps to calculate the running and starting watts necessary for your purposes:

- Select the electrical devices you plan on running at the same time.
- 2. Total the running watts of these items. This is the amount of power you need to keep your items running.
- 3. Identify the highest starting wattage of all devices identified in step 1. Add this number to the number calculated in step 2. Starting wattage is the extra burst of power needed to start some electric driven equipment. Following the steps listed under "Power Management" will guarantee that only one device will be starting at a time.

#### **Power Management**

Use the following formula to convert voltage and amperage to watts:

#### $Volts \times Amps = Watts$

To prolong the life of your generator and attached devices, follow these steps to add electrical load:

- Start the generator with no electrical load attached
- 2. Allow the engine to run for several minutes to stabilize.
- 3. Plug in and turn on the first item. It is best to attach the item with the largest load first.
- 4. Allow the engine to stabilize.

- 5. Plug in and turn on the next item.
- 6. Allow the engine to stabilize.
- 7. Repeat steps 5-6 for each additional item.

#### NOTICE

Never exceed the specified capacity when adding loads to the generator.

#### **Stopping the Engine**

- Turn off and unplug all electrical loads. Never start or stop the generator with electrical devices plugged in or turned on.
- Let the generator run at no-load for several minutes to stabilize internal temperatures of the engine and generator.
- 3. Turn the fuel valve to the "OFF" position.
- 4. Let the engine run until fuel starvation has stopped the engine. This usually takes a few minutes.
- 5. Press the engine switch to the "OFF" position.

**Important:** Always ensure that the fuel valve and the engine switch are in the "OFF" position when the generator is not in use.

#### NOTICE

If the engine will not be used for a period of two (2) weeks or longer, please see the <u>Storage</u> section for proper engine and fuel storage.

#### **MAINTENANCE**

Make certain that the generator is kept clean and stored properly. Only operate the unit on a flat, level surface in a clean, dry operating environment. DO NOT expose the unit to extreme conditions, excessive dust, dirt, moisture or corrosive vapors.

#### **A WARNING**

Never operate a damaged or defective generator.

#### **A WARNING**

Improper maintenance will void your warranty.

#### NOTICE

Maintenance, replacement, or repair of emission control devices and systems may be performed by any non-road engine repair establishment or individual.

The owner/operator is responsible for all periodic maintenance.

Complete all scheduled maintenance in a timely manner.

Correct any issue before operating the generator.

For service or parts assistance, contact our Technical Support Team at 1-877-338-0999.

#### **Cleaning the Generator**

#### **A CAUTION**

DO NOT spray engine with water.

Water can enter the generator through the cooling slots and damage the generator windings. It can also contaminate the fuel system.


- Use a damp cloth to clean exterior surfaces of the generator.
- 2. Use a soft bristle brush to remove dirt and oil.
- 3. Use an air compressor (25 PSI) to clear dirt and debris from the generator.
- 4. Inspect all air vents and cooling slots to ensure that they are clean and unobstructed.

To prevent accidental starting, remove and ground the spark plug wire before performing any service.

#### **Changing the Engine Oil**

Change oil when the engine is warm. Refer to the oil specification to select the proper grade for your operating environment.

- 1. Remove the oil drain plug with a 12 mm socket (not included) and extension.
- 2. Allow the oil to drain completely into an appropriate container.
- 3. Replace the oil drain plug.
- 4. Remove the oil fill cap/dipstick to add oil.




- Add oil according to "Add Engine Oil" on Assembly section. DO NOT OVERFILL. Oil not included for routine maintenance.
- 6. Dispose of used oil at an approved waste management facility.

#### NOTICE

Once oil has been added, a visual check should show oil about 1-2 threads from running out of the fill hole. If using the dipstick to check oil level, DO NOT screw in the dipstick while checking.

#### **Cleaning and Adjusting the Spark Plug(s)**

- 1. Remove the spark plug cable from the spark plug.
- 2. Use a spark plug socket tool (not included), or a 13/16 in. (21 mm) socket (not included) to remove the plug.
- 3. Inspect the electrode on the plug. It must be clean and not worn to produce the spark required for ignition.
- 4. Make certain the spark plug gap is 0.028-0.031 in. (0.7-0.8 mm).



Refer to the spark plug types in <u>Specifications</u> when replacing the plug.


- 6. Firmly re-install the plug.
- 7. Attach the spark plug cable to the spark plug.

#### Cleaning the Air Filter

- Remove the snap-on cover holding the air filter to the assembly.
- 2. Remove the foam element.
- Wash in liquid detergent and water. Squeeze thoroughly dry in a clean cloth.
- 4. Saturate in clean engine oil.
- Squeeze in a clean, absorbent cloth to remove all excess oil.
- 6. Place the filter in the assembly.
- 7. Reattach the air filter cover and snap in place.

#### **Cleaning the Spark Arrestor**

- 1. Allow the engine to cool completely before servicing the spark arrestor.
- Remove the two or three screws (varies by model) holding the cover plate which retains the spark arrestor to the muffler.
- 3. Remove the spark arrestor screen.
- 4. Carefully remove the carbon deposits from the spark arrestor screen with a wire brush.



- \*See your model's parts list for specified type of spark arrestor.
- 5. Replace the spark arrestor if it is damaged.
- 6. Position the spark arrestor on the muffler and attach with the screws removed in step 2.

#### **A** CAUTION

Failure to clean the spark arrestor will result in degraded engine performance.

#### **Adjusting the Governor**

#### WARNING

Tampering with the factory set governor will void your warranty.

The air-fuel mixture is not adjustable. Tampering with the governor can damage your generator and your electrical devices and will void your warranty. Contact our Technical Support Team at 1-877-338-0999 for all other service and/or adjustment needs.

#### **Maintenance Schedule**

Follow the service intervals indicated in the following maintenance schedule.

Service your generator more frequently when operating in adverse conditions.

Contact our Technical Support Team at 1-877-338-0999 to locate the nearest CPE certified service dealer for your generator or engine maintenance needs.

#### **EVERY 8 HOURS OR DAILY**

- ☐ Check oil level
- Clean around air intake and muffler

#### **FIRST 5 HOURS**

☐ Change oil

#### **EVERY 50 HOURS OR EVERY SEASON**

- Clean air filter
- ☐ Change oil if operating under heavy load or in hot environments

#### **EVERY 100 HOURS OR EVERY SEASON**

- ☐ Change oil
- ☐ Clean/adjust spark plug
- □ Check/adjust valve clearance\*
- Clean spark arrestor
- Clean fuel tank and filter\*

#### **EVERY 250 HOURS**

☐ Clean combustion chamber\*

#### **EVERY 3 YEARS**

Replace fuel line\*

<sup>\*</sup>To be performed by knowledgeable, experienced owners or CPE certified service centers.

#### **STORAGE**

#### **A** DANGER

Gasoline, gasoline vapors and propane (LPG) are highly flammable and extremely explosive.

Fire or explosion can cause severe burns or death. Only fill or drain fuel outdoors in a well-ventilated area. DO NOT pump gasoline directly into the generator. Use an approved container to transfer the fuel to the generator. Never use a gasoline container, gasoline tank, LPG connector hose, LPG cylinder or any other fuel item that is damaged or appears damaged. DO NOT overfill the gasoline tank. Always keep fuel away from sparks, open flames, pilot lights, heat and other sources of ignition. DO NOT light or smoke cigarettes.

#### **Short Term Storage (up to 1 year)**

Gasoline in the gasoline tank has a maximum shelf life of up to 1 year with the addition of properly formulated fuel stabilizers and if stored in a cool, dry place. Gasoline in the carburetor, however, may gum up and clog the carburetor if it isn't used or drained within 2-4 weeks.

- 1. Be sure all appliances are disconnected from the generator.
- 2. Add a properly formulated fuel stabilizer to the gasoline tank.
- Turn the fuel valve to the "ON" position or, for Dual Fuel models only, set the fuel selector switch for operation on gasoline.
- 4. Start and run the generator for 10 minutes so the treated gasoline cycles through the fuel system and carburetor.
- 5. Turn engine switch to the "OFF" position and allow generator to cool completely before continuing.

#### 6. Option 1: Drain Gasoline (all models)

- 6a. Turn the fuel valve to the "OFF" position *or, for Dual Fuel models ONLY,* set the fuel selector switch for operation on LPG and be sure any LPG fuel source is turned off and disconnected from the generator.
- 6b. Use the drain bolt on the carburetor to empty any excess gasoline from the carburetor into an appropriate container. Use a funnel (and appropriate hose if necessary) under the carburetor drain bolt to avoid spillage.
- 6c. When gasoline stops flowing from the carburetor, replace and tighten the carburetor drain bolt and be sure to properly dispose of the drained gasoline according to local regulations or guidelines.

#### 7. Option 2: Run Dry (gasoline type models ONLY)

- 7a. Turn engine switch to the "ON" position and start the generator.
- 7b. With the generator running, turn the fuel valve to the "OFF" position and allow the generator to run until the engine stops from complete fuel starvation. This may take a few minutes.
- 7c. Turn engine switch to the "OFF" position and allow generator to cool completely before continuing.
- 8. Remove the spark plug cap and spark plug and pour about a tablespoon of oil into the cylinder.
- 9. Pull the recoil slowly to crank the engine to distribute the oil and lubricate the cylinder.
- 10. Reattach the spark plug and spark plug cap.
- 11. If the generator includes a battery, disconnect and charge according to <u>Generator Battery</u>.
- 12. Clean the generator according to Cleaning the Generator.
- 13. Store the generator in a cool, dry place out of direct sunlight.

#### **Long Term Storage (over 1 year)**

For storage over 1 year, the gasoline tank and carburetor must be completely drained of gasoline.

- 1. Follow steps 1-5 according to **Short Term Storage**.
- Use the drain bolt on the carburetor to empty any excess gasoline from the gasoline tank and carburetor into an appropriate container. Use a funnel (and appropriate hose if necessary) under the carburetor drain bolt to avoid spillage.
- When gasoline stops flowing from the carburetor, replace and tighten the carburetor drain bolt and be sure to properly dispose of the drained gasoline according to local regulations or guidelines.
- 4. Turn the fuel valve to the "OFF" position or, for Dual Fuel models ONLY, set the fuel selector switch for operation on LPG and be sure any LPG fuel source is turned off and disconnected from the generator.
- 5. Follow steps 8-13 according to **Short Term Storage**.

#### **Removing from Storage**

If the generator has been improperly stored for a long period of time with gasoline in the gasoline tank and/or carburetor, all fuel must be drained and the carburetor must be thoroughly cleaned. This process involves technically advanced tasks. For assistance please call our Technical Support Team at 1-877-338-0999. If the gasoline tank and carburetor were properly emptied of all gasoline prior to the generator being stored, follow the below steps when removing from storage.

- Add gasoline to the generator according to <u>Add Fuel:</u> Gasoline.
- 2. Be sure the engine switch is in the "OFF" position.
- 3. Turn the fuel valve to the "ON" position *or, for Dual Fuel models ONLY,* set the fuel selector switch for operation on gasoline.
- 4. After 5 minutes check the carburetor and air filter areas for any leaking gasoline. If any leaks are found, the carburetor will need to be disassembled and cleaned or replaced. If no gasoline leaks are found, turn the fuel valve to the "OFF" position or, for Dual Fuel models ONLY, set the fuel selector switch for operation on propane (LPG).
- Check engine oil level and add clean, fresh oil if needed.
   See <u>Oil Specifications</u> for proper oil type.
- Check and clear air filter of any obstructions such as bugs or cobwebs. If necessary, clean air filter according to <u>Cleaning the Air Filter</u>.
- 7. If the generator includes a battery, connect according to Connect the Battery.
- 8. Start the generator according to Starting the Engine.

#### **A** DANGER

Generator exhaust contains odorless and colorless carbon monoxide gas.

To avoid accidental or unintended ignition of your generator during periods of storage, the following precautions should be followed:

- When storing the generator make sure the engine switch and fuel valve are set to the "OFF" position.
- If your generator includes a battery, disconnect according to <u>Generator Battery</u>.

#### **SPECIFICATIONS**

#### **Generator Specifications**

Generator Model	100458
Start Type	Manual
Watts (Starting/Running)	1500/1200
AC Volts	120
AC Amps @ 120 (Starting/Running)	12.5/10
Frequency	60 Hz
Phase	Single
Gross Weight	58.4 lb. (26.5 kg)
Net Weight	54.9 lb. (24.9 kg)
Length	19.3 in. (49 cm)
Width	14 in. (35.5 cm)
Height	16 in. (40.7 cm)


#### **Engine Specifications**

Model	YF152FD-4-010
Displacement	80 сс
Type	4-Stroke OHV

#### **Oil Specifications**

DO NOT OVERFILL.

Type	*See chart below
Capacity	0.4 qt. (0.4 L)



#### NOTICE

Weather will affect engine oil and engine performance. Change the type of engine oil used based on weather conditions to suit the engine needs.

#### **Fuel Specifications**

Use regular unleaded gasoline with a minimum octane rating of 85 and an ethanol content of less than 10% by volume. DO NOT USE E15 or E85. DO NOT OVERFILL.

Gasoline Capacity	1.9 gal.	(7 I \
DASONIE CADACITY	I . 🖰 Uai.	(/ L)

#### **Spark Plug Specifications**

OEM Type	NHSP E6RTC
Replacement Type	NGK BPR6HS or equivalent
Gap	0.028-0.031 in. (0.7-0.8 mm)

#### **Valve Specifications**

Intake Clearance	0.005-0.007 in. (0.13-0.17 mm)
Exhaust Clearance	0.007-0.009 in. (0.18-0.22 mm)

#### NOTICE

A technical bulletin regarding valve adjustment procedures is available at www.championpowerequipment.com.

#### **Temperature Specifications**

Starting Temperature Range (°F/°C) ...... 5 to 104/-15 to 40

#### **NOTICE**

An important message about temperature: Your product is designed and rated for continuous operation at ambient temperatures up to 40°C (104°F). When your product is needed it may be operated at temperatures ranging from 5°F (-15°C) to 122°F (50°C) for short periods of time. If exposed to temperatures outside this range during storage, it should be brought back within this range before operation. In any event, the product must always be operated outdoors, in a well-ventilated area and away from doors, windows and vents.


#### **IC Warning**

This device complies with Industry Canada license - exempt RSS standard(s).

Operation is subject to the following two conditions:

- 1. This device may not cause interference, and
- This device must accept any interference, including interference that may cause undesired operation of the device.

#### **Parts Diagram**




#### **Parts List**

#	Part Number	Description	Qty.
1	12.405	Engine, 79.8cc	1
2	12.100001.02		
3	12.101000.02 Muffler Assembly		1
4	1.848.08 Washer Ø8		2
5	1.93.08	Lock Washer Ø8	2
6	1.6175.08	Nut M8	2
7	46.101300.08	Spark Arrester Assembly	1
8	46.101503.08	Plate, Spark Arrester	1
9	1.9074.4.0514	Screw/Washer Assembly M5 × 14	2
10	122.070400.05	Fuel Valve	1
11	113.070011.04	Fuel Pipe, 130mm	1
12	2.06.016	Clamp, Ø8.7 × b8	2
13	113.070100.00	Fuel Tank Cap	1
14	122.070300.02	Fuel Filter	1
15	113.071000.09.48	Fuel Tank, 7L, Yellow	1
16	1.5789.0620.1	Flange Bolt M6 × 20, Black	4
17	1.93.06	Lock Washer Ø6	4
18	2.03.004.1	Flat Washer, $\emptyset$ 24 × $\emptyset$ 6.5 × 1.5, Black	4
19	122.070015.01	Mount Vibration, Fuel Tank	4
20	113.191100.13	Rotor Assembly, AI, Ø160 × 58mm	1
21	113.191002.00	191002.00 Stator Cover	
22	113.191200.13	Stator Assembly, Al, Ø160 × 58 mm,	1
23	2.08.148	Flange Bolt/Washer Assembly M8 × 160	1
24	1.5789.0612	Flange Bolt M6 × 12	2
25	12.100100.01	Bracket, Muffler	1
26	115.190002.00	End Housing	
27	1.16674.0512.2	Flange Bolt M5 × 12	3
28	2.08.073	Flange Bolt/Washer Assembly M6 × 90	4
29	122.190003.00.48	Generator End Cover, Yellow	1
30	1.862.06	Lock Washer Ø6, Toothed	1
31	5.1900.105	Grounding Line 200mm, CSA	1
32	1.6177.1.06	Lock Nut M6, Flange	1
33	1.97.1.06	Washer Ø6	2

#	Part Number	Description	Qty.
34	1.93.06	Lock Washer Ø6	1
35	1.62.06	Butterfly Type Nut M6	1
36	61148.0.6.2	Frame, 490 × 355 × 398 mm	1
37	1.6177.1.08	Lock Nut M8, Flange	10
38	113.201200.00	Motor Mount, Left	1
39	122.201400.01	Rubber, Support	2
40	1.16674.0812	Flange Bolt M8 × 12	2
41	113.201200.01	Motor Mount, Right	1
42	1.5783.0820	Bolt M8 × 20	2
43	203.201400.01	Rubber	2
44	113.201200.02	Motor Mount	2
45	1.6177.1.05	Lock Nut M5, Flange	6
46	113.210002.09	Control Box, CSA	1
47	1.5789.0615.1	Flange Bolt M6 × 15, Black	4
48	12.061200.00.2	Guide Plate, Rope, Black	1
49	1.9074.4.0514.1	Screw/Washer Assembly M5 × 14, Black	4
50	113.200106.00	Protector, Front Cover	1
51	113.22.1.2	Control Panel, Black	1
52	5.1120.027	Receptacle 5-20R, Duplex, CSA	1
53	1.6177.1.04.1	Lock Nut M4, Flange, Black	3
54	5.1870.008	Receptacle Cover, Receptacle 5-20R, Duplex	1
55	5.1200.910	10Amp Circuit Breaker, Push Button, CSA	1
56	5.1430.008	Intelligauge, VFT-2	1
57	5.1010.003.3	Ignition Switch, Red	1
58	5.1860.000	Capacitance	1
59	1.9074.4.0414.1	Screw/Washer Assembly M4 × 14, Black	1
60	122.210003.02	Wire Jacket, Control Box, CSA	1
61	5.1320.012	Sheath, Wire, CSA	1
62	122.210003.04	Plug, End Cover, CSA	1
63	100458.21.10	Wire Assembly	1
64	100458.21	Control Panel Assembly	1

#### **Engine Parts Diagram**




#### **Engine Parts List**

#         Part Number         Description           1         12.091000.01         Air Cleaner Assembly           2         12.061000.03.48         Recoil Assembly, Yellow           3         1.16674.0612         Flange Bolt M6 × 12           4         1.5789.0608         Flange Bolt M6 × 8           5         12.111000.01         Control Assembly           6         12.080100.00.48         Fan Cover, Yellow           7         1.6177.2.12         Flange Nut M12           8         12.080001.00         Pulley Starter           9         12.080001.00         Cooling Fan           10         1.16674.0620         Flange Bolt M6 × 20	1 1 4 3 1 1 1 1 2
2       12.061000.03.48       Recoil Assembly, Yellow         3       1.16674.0612       Flange Bolt M6 × 12         4       1.5789.0608       Flange Bolt M6 × 8         5       12.111000.01       Control Assembly         6       12.080100.00.48       Fan Cover, Yellow         7       1.6177.2.12       Flange Nut M12         8       12.060001.00       Pulley Starter         9       12.080001.00       Cooling Fan	4 3 1 1 1 1 1 2
4       1.5789.0608       Flange Bolt M6 × 8         5       12.111000.01       Control Assembly         6       12.080100.00.48       Fan Cover, Yellow         7       1.6177.2.12       Flange Nut M12         8       12.060001.00       Pulley Starter         9       12.080001.00       Cooling Fan	3 1 1 1 1 1 2
5         12.111000.01         Control Assembly           6         12.080100.00.48         Fan Cover, Yellow           7         1.6177.2.12         Flange Nut M12           8         12.060001.00         Pulley Starter           9         12.080001.00         Cooling Fan	1 1 1 1 1 2
6       12.080100.00.48       Fan Cover, Yellow         7       1.6177.2.12       Flange Nut M12         8       12.060001.00       Pulley Starter         9       12.080001.00       Cooling Fan	1 1 1 1 2
7       1.6177.2.12       Flange Nut M12         8       12.060001.00       Pulley Starter         9       12.080001.00       Cooling Fan	1 1 1 2
8     12.060001.00     Pulley Starter       9     12.080001.00     Cooling Fan	1 1 2
9 12.080001.00 Cooling Fan	1 2
3	2
<b>10</b> 1.16674.0620 Flange Bolt M6 × 20	
1 1 - 1	
<b>11</b> 12.123000.01 Ignition Coil, Shield	1
<b>12</b>   15.120100.00   Flywheel	1
<b>13</b> 2.14.016 Woodruff Key, 5 × 6.5 × 16	1
<b>14</b> 12.080014.00 Air Guide Plate, Back	1
<b>15</b>   12.080014.01   Air Guide Plate, Front	1
16 2.11.009 Oil Seal Ø17 × Ø30 × 6	2
<b>17</b> 1.276.6203 Bearing 6203	1
<b>18</b> 21.120400.00 Diode Assembly	1
<b>19</b> 1.6177.06 Flange Nut M6	4
20 2.08.037 Drain Bolt M10 × 1.25 × 25	2
21 2.03.016 Washer Ø10 × Ø16 × 1.5, Drain Bolt	2
<b>22</b> 12.030100.01 Crankcase	1
23 12.127000.03 Oil Level Sensor	1
<b>24</b> 1.16674.0616 Flange Bolt M6 × 16	2
25 2.03.020.1 Washer Ø6.2 × Ø15 × 0.5, Black	1
<b>26</b> 12.110100.00 Gear, Governor	1
<b>27</b> 12.110013.00 Shaft, Governor Gear	1
<b>28</b> 21.110011.00 Clip, Governor Gear	1
29 12.110012.00 Bushing, Govornor Gear	1
<b>30</b> 12.050100.04 Crankshaft	1
31 21.040020.00 Screw, Valve Adjustment	2
<b>32</b> 21.040021.00 Nut M6 × 0.5, Lock	2
<b>33</b> 1.276.6303 Bearing 6303	1
34 12.030008.01 Gasket, Crankcase Cover	1
<b>35</b> 2.04.002 Dowel Pin Ø8 × 14	4

#	Part Number	Description	Qty.
00	15 001000 00 40	Oil Dipstick Assembly,	4
36	15.031000.00.48	Yellow	1
37	15.030007.00	Cover, Crankcase	1
38	1.5789.0625	Flange Bolt M6 × 25	6
39	12.050200.00	Connecting Rod	1
40	12.050005.02	Piston	1
41	2.09.005	Circlip Ø16 × Ø1	2
42	12.050003.01	Pin, Piston	1
43	11.050303.00	Ring, Oil	1
44	11.050302.00	Ring, Second Piston	1
45	11.050301.00	Ring, First Piston	1
46	12.030009.00	Gasket, Cylinder Head	1
47	15.010100.00	Cylinder Head	1
48	2.15.005 (E6RTC)	Spark Plug E6RTC	1
49	1.5789.0855	Flange Bolt M8 × 55	4
50	21.020002.00	Gasket, Cylinder Head Cover	1
51	15.021000.00	Cover, Cylinder Head	1
52	15.020007.00	Baffle, Wire	1
53	15.020001.00	Breather Tube	1
54	2.01.010	Stud Bolt M8 × 35	2
55	12.041000.02	Camshaft	1
56	15.040013.00	Lifter, Valve	2
57	15.040005.00	Push Rod	2
58	23.040017.00	Oil Seal, Valve	1
59	12.040002.00	Valve, Intake	1
60	12.040006.00	Valve, Exhaust	1
61	12.040003.00	Spring, Valve	2
62	12.040014.00	Retainer, Valve Spring	2
63	15.040004.00	Guide Plate, Push Rod	1
64	83.040010.01	Bolt, Rocker Arm	2
65	2.01.019	Stud Bolt M6 × 89	2
66	12.130002.01	Gasket, Insulator	2
67	12.130001.00	Insulator, Carburetor	1
68	12.131000.01	Carburetor	1 1
	12.131000.02		<u> </u>
69	12.091100.00	Base, Air Cleaner	1
70	12.091001.00	Separator, Air Cleaner	1
71	12.091003.00	Element, Air Cleaner	1
72	12.091200.00	Cover, Air Cleaner	1
73	12.091500.00	Bolt, Air Cleaner	2
74	15.080300.00	Air Guide, Upper	1
75	12.110001.00	Shaft, Governor Arm	1
76	1.896.06	Circlip Ø6	1

#	Part Number	Description	Qty.
77	2.03.019	Washer Ø8.2 × Ø17 × 0.8	1
78	12.110008.00	Pin, Shaft	1
79	12.110003.00	Arm, Governor	1
80	12.110007.21	Spring, Governor	1
81	12.110005.00	Spring, Throttle Return	1
82	12.110006.00	Rod, Governor	1
83	15.040009.00	Rocker Arm	2
84	1.5789.0612	Flange Bolt M6 × 12	5
85	1.5789.0615	Flange Bolt M6 × 15	4
86	15.010000.00	Cylinder Head Assembly	1

#### **Wiring Diagram**



#### **TROUBLESHOOTING**

Problem	Cause	Solution
	No fuel.	Add fuel.
Generator will not start.	Faulty spark plug.	Replace spark plug.
	Unit loaded during start up.	Remove load from unit.
	Low oil lovel	Fill crankcase to the proper level.
Generator will not start;	Low oil level.	Place generator on a flat, level surface.
Generator starts but runs roughly.	Choke in the wrong position.	Adjust choke.
	Spark plug wire loose.	Attach wire to spark plug.
	Out of fuel.	Fill fuel tank.
Generator shuts down during operation.	Low oil level.	Fill crankcase to the proper level. Place generator on a flat, level surface.
Generator cannot supply enough power	Generator is overloaded.	Review load and adjust. See "Connecting Electrical Loads."
or overheating.	Insufficient ventilation.	Check for air restriction. Move to a well ventilated area.
	Cable not properly connected.	Check all connections.
	Connected device is defective.	Replace defective device.
No AC output.	Circuit breaker is open.	Reset circuit breaker
	Loose wiring.	Inspect and tighten wiring connections.
	Other.	Contact the help line.
Generator gallops.	Engine governor defective.	Contact the help line.
Panastad airquit brooker tripping	Overload.	Review load and adjust. See "Connecting Electrical Loads."
Repeated circuit breaker tripping.	Faulty cords or device.	Check for damaged, bare or frayed wires. Replace defective device.

#### For further technical support:

Technical Support Team
Mon-Fri 8:30 AM-5:00 PM (PST/PDT)
Toll Free 1-877-338-0999
support@championpowerequipment.com

#### **WARRANTY\***

CHAMPION POWER EQUIPMENT 3 YEAR LIMITED WARRANTY

#### **Warranty Qualifications**

To register your product for warranty and FREE lifetime call center technical support please visit:

https://www.championpowerequipment.com/register

To complete registration you will need to include a copy of the purchase receipt as proof of original purchase. Proof of purchase is required for warranty service. Please register within ten (10) days from date of purchase.

#### **Repair/Replacement Warranty**

CPE warrants to the original purchaser that the mechanical and electrical components will be free of defects in material and workmanship for a period of three years (parts and labor) from the original date of purchase and 270 days (parts and labor) for commercial and industrial use. Transportation charges on product submitted for repair or replacement under this warranty are the sole responsibility of the purchaser. This warranty only applies to the original purchaser and is not transferable.

## Do Not Return The Unit To The Place Of Purchase

Contact CPE's Technical Service and CPE will troubleshoot any issue via phone or e-mail. If the problem is not corrected by this method, CPE will, at its option, authorize evaluation, repair or replacement of the defective part or component at a CPE Service Center. CPE will provide you with a case number for warranty service. Please keep it for future reference. Repairs or replacements without prior authorization, or at an unauthorized repair facility, will not be covered by this warranty.

#### **Warranty Exclusions**

This warranty does not cover the following repairs and equipment:

#### **Normal Wear**

Products with mechanical and electrical components need periodic parts and service to perform well. This warranty does not cover repair when normal use has exhausted the life of a part or the equipment as a whole.

#### Installation. Use and Maintenance

This warranty will not apply to parts and/or labor if the product is deemed to have been misused, neglected, involved in an accident, abused, loaded beyond the product's limits, modified, installed improperly or connected incorrectly to any electrical component. Normal maintenance is not covered by this warranty and is not required to be performed at a facility or by a person authorized by CPE.

#### **Other Exclusions**

This warranty excludes:

- Cosmetic defects such as paint, decals, etc.
- Wear items such as filter elements, o-rings, etc.
- Accessory parts such as starting batteries, and storage covers.
- Failures due to acts of God and other force majeure events beyond the manufacturer's control.
- Problems caused by parts that are not original Champion Power Equipment parts.

When applicable, this warranty does not apply to products used for prime power in place of a utility.

## Limits of Implied Warranty and Consequential Damage

Champion Power Equipment disclaims any obligation to cover any loss of time, use of this product, freight, or any incidental or consequential claim by anyone from using this product. THIS WARRANTY AND THE ATTACHED U.S. EPA and/or CARB EMISSION CONTROL SYSTEM WARRANTIES (WHEN APPLICABLE) ARE IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.

A unit provided as an exchange will be subject to the warranty of the original unit. The length of the warranty governing the exchanged unit will remain calculated by reference to the purchase date of the original unit.

This warranty gives you certain legal rights which may change from state to state or province to province. Your state or province may also have other rights you may be entitled to that are not listed within this warranty.

#### **Contact Information**

#### **Address**

Champion Power Equipment, Inc. 12039 Smith Ave. Santa Fe Springs, CA 90670 USA www.championpowerequipment.com

#### **Customer Service**

Toll Free: 1-877-338-0999

info@championpowerequipment.com

Fax no.: 1-562-236-9429

**Technical Service** 

Toll Free: 1-877-338-0999

tech@championpowerequipment.com 24/7 Tech Support: 1-562-204-1188

<sup>\*</sup>Except as otherwise stipulated in any of the following enclosed Emission Control System Warranties (when applicable) for the Emission Control System: U.S. Environment Protection Agency (EPA) and/or California Air Resources Board (CARB).

## CHAMPION POWER EQUIPMENT, INC. (CPE) AND THE UNITED STATES ENVIRONMENT PROTECTION AGENCY (U.S. EPA) EMISSION CONTROL SYSTEM WARRANTY

Your Champion Power Equipment (CPE) engine complies with U.S. EPA emission regulations.

#### YOUR WARRANTY RIGHTS AND OBLIGATIONS:

The US EPA AND CPE are pleased to explain the Federal Emission Control Systems Warranty on your 2020 small off-road engine (SORE) and engine powered equipment. New engines and equipment must be designed, built and equipped, at the time of sale, to meet U.S. EPA regulations for small off-road engines (SORE). CPE warrants the emission control system on your small off-road engine (SORE) and equipment for the period of time listed below, provided there has been no abuse, neglect, unapproved modification, or improper maintenance of your equipment.

Your emission control system may include parts such as the carburetor, fuel-injection system, the ignition system, catalytic converter and fuel lines. Also included may be hoses, belts, connectors and other emission related assemblies. Where a warrantable condition exits, CPE will repair your small off-road engine (SORE) at no cost to you including diagnosis, parts and labor.

#### MANUFACTURER'S EMISSION CONTROL SYSTEM WARRANTY COVERAGE:

This emission control system is warranted for two years, subject to provisions set forth below. If, during the warranty period, an emission related part on your engine is defective in materials or workmanship, the part will be repaired or replaced by CPE.

#### **OWNER WARRANTY RESPONSIBILITIES:**

As the small off-road engine (SORE) owner, you are responsible for the performance of the required maintenance listed in your Owner's Manual. CPE recommends that you retain all your receipts covering maintenance on your small off-road engine (SORE), but CPE cannot deny warranty solely for the lack of receipts or for your failure to ensure the performance of all scheduled maintenance.

As the small off-road engine (SORE) owner, you should however be aware that CPE may deny you warranty coverage if your small, off-road engine (SORE) or a part has failed due to abuse, neglect, improper maintenance or unapproved modifications.

You are responsible for presenting your small off-road engine (SORE) to an Authorized CPE service outlet or alternate service outlet as described in (3)(f.) below, CPE dealer or CPE, Santa Fe Springs, Ca. as soon as a problem exists. The warranty repairs should be completed in a reasonable amount of time, not to exceed 30 days.

If you have any questions regarding your warranty rights and responsibilities, you should contact:

Champion Power Equipment, Inc.
Customer Service
12039 Smith Ave.
Santa Fe Springs, CA 90670
1-877-338-0999
tech@championpowerequipment.com

#### **EMISSION CONTROL SYSTEM WARRANTY**

The following are specific provisions relative to your Emission Control System (ECS) Warranty Coverage.

 APPLICABILITY: This warranty shall apply to 1997 and later model year small off-road engines (SORE). The ECS Warranty Period shall begin on the date the new engine or equipment is delivered to its original, end-use purchaser, and shall continue for 24 consecutive months thereafter.

#### 2. GENERAL EMISSIONS WARRANTY COVERAGE

CPE warrants to the original, end-use purchaser of the new engine or equipment and to each subsequent purchaser that each of its small off-road engines (SORE) is:

- 2a. Designed, built and equipped so as to conform to U.S. EPA emissions standards for spark-ignited engines at or below 19 kilowatts.
- 2b. Free from defects in materials and workmanship that cause the failure of a warranted part to be identical in all material respects to the part as described in the engine manufacturer's application for certification for a period of two years.

#### 3. THE WARRANTY ON EMISSION-RELATED PARTS WILL BE INTERPRETED AS FOLLOWS:

- 3a. Any warranted part that is not scheduled for replacement as required maintenance in the Owners Manual shall be warranted for the ECS Warranty Period. If any such part fails during the ECS Warranty Period, it shall be repaired or replaced by CPE according to Subsection "d" below. Any such part repaired or replaced under the ECS Warranty shall be warranted for any remainder of the ECS Warranty Period.
- 3b. Any warranted, emissions-related part which is scheduled only for regular inspection as specified in the Owners Manual shall be warranted for the ECS Warranty Period. A statement in such written instructions to the effect of "repair or replace as necessary", shall not reduce the ECS Warranty Period. Any such part repaired or replaced under the ECS Warranty shall be warranted for the remainder of the ECS Warranty Period.
- 3c. Any warranted, emissions-related part which is scheduled for replacement as required maintenance in the Owner's Manual shall be warranted for the period of time prior to the first scheduled replacement point for that part. If the part fails prior to the first scheduled replacement, the part shall be repaired or replaced by CPE according to Subsection "d" below. Any such emissions-related part repaired or replaced under the ECS Warranty, shall be warranted for the remainder of the ECS Warranty Period prior to the first scheduled replacement point for such emissions-related part.
- 3d. Repair or replacement of any warranted, emissions-related part under this ECS Warranty shall be performed at no charge to the owner at a CPE Authorized Service Outlet.
- 3e. The owner shall not be charged for diagnostic labor which leads to the determination that a part covered by the ECS Warranty is in fact defective, provided that such diagnostic work is performed at a CPE Authorized Service Outlet.
- 3f. CPE shall pay for covered emissions warranty repairs at non-authorized service outlets under the following circumstances:
  - i. The service is required in a population center with a population over 100,000 according to U.S. Census 2000 without a CPE Authorized Service Outlet AND
  - ii. The service is required more than 100 miles from a CPE Authorized Service Outlet. The 100 mile limitation does not apply in the following states: Alaska, Arizona, Colorado, Hawaii, Idaho, Montana, Nebraska, Nevada, New Mexico, Oregon, Texas, Utah and Wyoming.
- 3g. CPE shall be liable for damages to other original engine components or approved modifications proximately caused by a failure under warranty of an emission-related part covered by the ECS Warranty.
- 3h. Throughout the ECS Warranty Period, CPE shall maintain a supply of warranted emission-related parts sufficient to meet the expected demand for such emission-related parts.
- 3i. Any CPE Authorized and approved emission-related replacement part may be used in the performance of any ECS Warranty maintenance or repair and will be provided without charge to the owner. Such use shall not reduce CPE's warranty obligation.
- 3j. Unapproved add-on or modified parts may not be used to modify or repair a CPE engine. Such use voids this ECS Warranty and shall be sufficient grounds for disallowing an ECS Warranty claim. CPE shall not be liable hereunder for failures of any warranted parts of a CPE engine caused by the use of such an unapproved add-on or modified part.

## EMISSION-RELATED PARTS INCLUDE THE FOLLOWING: (using those portions of the list applicable to the engine)

Systems covered by this warranty	Parts Description	
Fuel Metering System	Fuel regulator, Carburetor and internal parts	
Air Induction System	Air cleaner, Intake manifold	
Ignition System	Spark plug and parts, Magneto ignition system	
Exhaust System	Exhaust manifold, catalytic converter	
Miscellaneous Parts	Tubing, Fittings, Seals, Gaskets, and Clamps associated with these listed systems.	
Evaporative Emissions	Fuel Tank, Fuel Cap, Fuel Line (for liquid fuel and fuel vapors), Fuel Line Fittings, Clamps, Pressure Relief Valves, Control Valves, Control Solenoids, Electronic Controls, Vacuum Control Diaphragms, Control Cables, Control Linkages, Purge Valves, Gaskets, Vapor Hoses, Liquid/Vapor Separator, Carbon Canister, Canister Mounting Brackets, Carburetor Purge Port Connector	

#### TO OBTAIN WARRANTY SERVICE:

You must take your CPE engine or the product on which it is installed, along with your warranty registration card or other proof of original purchase date, at your expense, to any Champion Power Equipment dealer who is authorized by Champion Power Equipment, Inc. to sell and service that CPE product during his normal business hours. Alternate service locations defined in Section (3)(f.) above must be approved by CPE prior to service. Claims for repair or adjustment found to be caused solely by defects in material or workmanship will not be denied because the engine was not properly maintained and used.

If you have any questions regarding your warranty rights and responsibilities, or to obtain warranty service, please write or call Customer Service at Champion Power Equipment, Inc.

Champion Power Equipment, Inc.

12039 Smith Ave. Santa Fe Springs, CA 90670 1-877-338-0999

Attn.: Customer Service tech@championpowerequipment.com