

OWNER'S MANUAL & OPERATING INSTRUCTIONS



4000 Starting Watts / 3000 Rated Watts Recoil Start

PORTABLE GENERATOR



46551

SAVE THESE INSTRUCTIONS

Important Safety Instructions are included in this manual.

MADE IN CHINA REV 46551-20130402 10006 Santa Fe Springs Road Santa Fe Springs CA 90670 USA / 1-877-338-0999 www.championpowerequipment.com

AN IMPORTANT MESSAGE ABOUT TEMPERATURE:

Your Champion Power Equipment product is designed and rated for continuous operation at ambient temperatures up to 40°C (104°F). When your product is needed your product may be operated at temperatures ranging from -15°C (5°F) to 50°C (122°F) for short periods. If the product is exposed to temperatures outside this range during storage, it should be brought back within this range before operation. In any event, the product must always be operated outdoors, in a well-ventilated area and away from doors, windows and other vents.

Have questions or need assistance?

Do not return this product to the store!

WE ARE HERE TO HELP!


Visit our website: www.championpowerequipment.com for more info:

- Product Info & Updates
- Tech Bulletins
- Frequently Asked Questions
- Product Registration

– or –

Call our Customer Care Team Toll-Free at:

1-877-338-0999



4000 Starting Watts / 3000 Rated Watts Recoil Start

PORTABLE GENERATOR

TABLE OF CONTENTS

Introduction	Cleaning
Introduction	Adjustments
Portable Power Generator	Maintenance Schedule
Accessories	Generator Maintenance
This Booklet	Storage
Manual Conventions	Generator Storage
Safety Rules	Disconnect the Battery
Controls and Features	Charge the Battery
Generator	Specifications
Power Panel 6	Engine Specifications
Parts Included	Generator Specifications
Wheel Kit	Fuel
Other	Oil
Assembly	Spark Plugs
Remove the Generator from the Shipping Carton 8	Valve Clearance 17
Install the Wheel Kit	Wiring Diagram
Install the Support Leg 8	Parts Diagram
Install the Handle 8	Parts List
Add Engine Oil	Engine Parts Diagram 21
Add Fuel	Engine Parts List
Grounding	Troubleshooting
Operation	Warranty
Generator Location	Warranty Qualifications
Grounding	Repair/Replacement Warranty
Surge Protection	Do Not Return The Unit To
Starting the Engine	The Place Of Purchase
Connecting Electrical Loads	Warranty Exclusions
Stopping the Engine	Normal Wear
Do Not Overload Generator	Installation, Use and Maintenance 24
Capacity	Other Exclusions
Power Management	Limits of Implied Warranty
Maintenance and Storage	and Consequential Damage 24
Engine Maintenance	Contact Information
Oil	Address
Spark Plugs	Customer Service
Air Filter	Technical Service
Spark Arrester	
In line Eucl Eilter 15	

INTRODUCTION

Introduction

Congratulations on your purchase of a Champion Power Equipment generator. CPE designs and builds generators to strict specifications. With proper use and maintenance, this generator will bring years of satisfying service.

Portable Power Generator

This unit is a gasoline engine driven, alternating current (AC) generator. It is designed to supply electrical power for lighting, appliances, tools and similar equipment.

Accessories

Champion Power Equipment manufactures and sells accessories designed to help you get the most from your purchase. To find out more about our covers and power cables, please visit our web site at:

→ www.championpowerequipment.com

This Booklet

Every effort has been made to ensure the accuracy and completeness of the information in this manual. We reserve the right to change, alter and/or improve the product and this document at any time without prior notice.

Record the model and serial numbers as well as date and place of purchase for future reference. Have this information available when ordering parts and when making technical or warranty inquiries.



MANUAL CONVENTIONS

This manual uses the following symbols to help differentiate between different kinds of information. The safety symbol is used with a key word to alert you to potential hazards in operating and owning power equipment. Follow all safety messages to avoid or reduce the risk of serious injury or death.



DANGER indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.

⚠WARNING

WARNING indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.

(I) CAUTION

CAUTION indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury.

CAUTION

CAUTION used without the safety alert symbol indicates a potentially hazardous situation which, if not avoided, may result in property damage.

NOTE

If you have questions regarding your generator, we can help. Please call our help line at 1-877-338-0999

⚠ WARNING

Read this manual thoroughly before operating your generator. Failure to follow instructions could result in serious injury or death.

∕N WARNING

The engine exhaust from this product contains chemicals known to the state of California to cause cancer, birth defects, or other reproductive harm.

\Lambda DANGER

Generator exhaust contains carbon monoxide, a colorless, odorless, poison gas. Breathing carbon monoxide will cause nausea, dizziness, fainting or death. If you start to feel dizzy or weak, get to fresh air immediately.

Operate generator outdoors only in a well ventilated

DO NOT operate the generator inside any building, including garages, basements, crawlspaces and sheds, enclosure or compartment, including the generator compartment of a recreational vehicle. DO NOT allow exhaust fumes to enter a confined area through windows, doors, vents or other

DANGER CARBON MONOXIDE: using a generator indoors CAN KILL YOU IN MINUTES.

A DANGER

Rotating parts can entangle hands, feet, hair, clothing and/or accessories.

Traumatic amputation or severe laceration can result.

Keep hands and feet away from rotating parts. Tie up long hair and remove jewelry. Operate equipment with guards in place. DO NOT wear loose-fitting clothing, dangling drawstrings or items that could become caught.

\land DANGER

Generator produces powerful voltage.

DO NOT touch bare wires or receptacles.

DO NOT use electrical cords that are worn, damaged or frayed.

DO NOT operate generator in wet weather.

DO NOT allow children or unqualified persons to operate or service the generator

Use a ground fault circuit interrupter (GFCI) in damp areas and areas containing conductive material such as metal decking.

Use approved transfer equipment to isolate generator from your electric utility and Notify your utility company before connecting your generator to your power system.

⚠ WARNING

Sparks can result in fire or electrical shock.

When servicing the generator:

Disconnect the spark plug wire and place it where it cannot contact the plug.

DO NOT check for spark with the plug removed. Use only approved spark plug testers.

⚠ WARNING

Running engines produce heat. Severe burns can occur on contact.

Combustible material can catch fire on contact.

DO NOT touch hot surfaces.

Avoid contact with hot exhaust gases.

Allow equipment to cool before touching.

Maintain at least three feet of clearance on all sides to ensure adequate cooling.

Maintain at least five feet of clearance from combustible materials.

⚠ WARNING

Medical and Life Support Uses.

In case of emergency, call 911 immediately. NEVER use this product to power life support devices or life support appliances.

NEVER use this product to power medical devices or medical appliances.

Inform your electricity provider immediately if you or anyone in your household depends on electrical equipment to live.

Inform your electrical provider immediately if a loss of power would cause you or anyone in your household to experience a medical emergency.

\land DANGER

Fuel and fuel vapours are highly flammable and extremely explosive.

Fire or explosion can cause severe burns or death. Unintentional startup can result in entanglement, traumatic amputation or laceration.

When adding or removing fuel:

Turn the generator off and let it cool for at least two minutes before removing the fuel cap. Loosen the cap slowly to relieve pressure in the tank.

Only fill or drain fuel outdoors in a well-ventilated area. DO NOT pump gas directly into the generator at the gas station. Use an approved container to transfer the fuel to the generator.

DO NOT overfill the fuel tank.

Always keep fuel away from sparks, open flames, pilot lights, heat and other sources of ignition. DO NOT light or smoke cigarettes.

When starting the generator:

DO NOT attempt to start a damaged generator. Make certain that the gas cap, air filter, spark plug, fuel lines and exhaust system are properly in place. Allow spilled fuel to evaporate fully before attempting to start the engine.

Make certain that the generator is resting firmly on level ground.

When operating the generator:

DO NOT move or tip the generator during operation. DO NOT tip the generator or allow fuel or oil to spill.

When transporting or servicing the generator:

Make certain that the fuel shutoff valve is in the off position and the fuel tank is empty.

Disconnect the spark plug wire.

When storing the generator:

Store away from sparks, open flames, pilot lights, heat and other sources of ignition.

⚠ WARNING

Operation of this equipment may create sparks that can start fires around dry vegetation.

A spark arrestor may be required. The operator should contact local fire agencies for laws or regulations relating to fire prevention requirements.

⚠ WARNING

Rapid retraction of the starter cord will pull hand and arm towards the engine faster than you can let go. Unintentional startup can result in entanglement, traumatic amputation or laceration.

Broken bones, fractures, bruises or sprains could result.

When starting engine, pull the starter cord slowly until resistance is felt and then pull rapidly to avoid kickback.

DO NOT start or stop the engine with electrical devices plugged in.

(1) CAUTION

Exceeding the generator's running capacity can damage the generator and/or electrical devices connected to it.

DO NOT overload the generator.

Start the generator and allow the engine to stabilize before connecting electrical loads.

Connect electrical equipment in the off position, and then turn them on for operation.

Turn electrical equipment off before stopping the generator.

DO NOT tamper with the governed speed.

DO NOT modify the generator in any way.

(!) CAUTION

Improper treatment or use of the generator can damage it, shorten its life and void your warranty.

Use the generator only for intended uses.

Operate only on level surfaces.

DO NOT expose generator to excessive moisture, dust. or dirt.

DO NOT allow any material to block the cooling slots. If connected devices overheat, turn them off and disconnect them from the generator.


DO NOT use the generator if:

- Electrical output is lost
- Equipment sparks, smokes or emits flames
- Equipment vibrates excessively

CONTROLS AND FEATURES

Read this owner's manual before operating your generator. Familiarize yourself with the location and function of the controls and features. Save this manual for future reference.


Generator



- Fuel Tank 4.0 gallon (15L) capacity fuel tank. (1)
- (2) **Choke Lever** – Used to start the engine.
- (3) Fuel Valve – Turn this valve to the "ON" position to supply fuel to the engine.
- Air Cleaner Protects the engine by filtering dust (4) and debris from the intake air.
- (5) Recoil Starter Used to start the engine.

- Low Oil Sensor Senses the level of oil in the (6) crankcase and shuts the engine down if the level falls too low.
- (7) Oil Filler Cap Check and fill engine oil level.
- (8) Power Panel – See "Power Panel".
- (9) Handle

Power Panel



- (1) **Engine Switch** – Flip the switch to the "On" position and pull the recoil starter to start the generator. Turn to the "Off" position to turn off the generator.
- (2) Circuit Breaker Protects the generator against electrical overload.
- (3) **Voltmeter** – Displays the output voltage of the generator.
- **120V / 30A Twist-Lock** (NEMA L5-30R) May be (4) used to supply electrical power for the operation of 120 Volt AC, 30 Amp, single phase 60 Hz electrical loads.
- **(5) 120V / 20A Duplex (2)** (NEMA 5-20R) May be used to supply electrical power for the operation of 120 Volt AC, 20 Amp, single phase 60 Hz electrical loads.
- (6) Ground Terminal Consult an electrician for local grounding regulations.


CONTROLS AND FEATURES

Parts Included

Your 46551 Gasoline Powered Generator ships with the following parts:

Wheel Kit

_	8 in. Wheel	2
_	Bushing	2
_	Flange Bolt (M10x105 for Wheel)	2
_	Flat Washer 10	2
_	Nut (M10)	2
_	Support Leg w/Vibration Mounts	1
_	Flange Bolt (M8x16 for Support Leg)	2
-	Handle	1
_	Flange Bolt (M8x45 for Handle)	2
_	Nut (M8)	4
0t	her	
_	Oil Funnel	
_	Spark Plug Socket	1



Your generator requires some assembly. This unit ships from our factory without oil. It must be properly serviced with fuel and oil before operation.

If you have any questions regarding the assembly of your generator, call our help line at 1-877-338-0999. Please have your serial number and model number available.

Remove the Generator from the Shipping Carton

- 1. Set the shipping carton on a solid, flat surface.
- 2. Remove everything from the carton except the generator.
- 3. Carefully cut each corner of the box from top to bottom. Fold each side flat on the ground to provide a surface area to install the wheel kit and support leg.


Install the Wheel Kit



The wheel kit is not intended for over-the-road use.


You will need the following tools to install the wheels:

- 17 mm wrench OR adjustable wrench (not included)
- Socket wrench with a 16 mm socket (not included)
- Pliers (not included)
- 1. Before adding fuel and oil, tip the generator on it's side.
- 2. Slide the wheel bolt (M10x105) through the washer, sleeve and wheel.
- 3. Slide the bolt through the mount point on the frame.
- 4. Fasten securely with the M10 nut.
- 5. Repeat steps 2-4 to attach the second wheel.




Install the Support Leg

- 1. Attach the support leg to the generator frame with cap screws (M8x16) and lock nuts (M8).
- Tip the generator slowly so that it rests on the wheels and support leg.



Install the Handle

- 1. Place the handle over the mounting channel on the
- 2. Secure the handle to the frame using the two handle bolts (M8x45).
- 3. Place a lock nut (M8) on the end of each bolt and fasten securely. DO NOT over tighten the lock nuts.



Add Engine Oil


(!) CAUTION

DO NOT attempt to crank or start the engine before it has been properly filled with the recommended type and amount of oil. Damage to the generator as a result of failure to follow these instructions will void your warranty.

♥ NOTE


The recommended oil type is 10W-30 automotive oil.

- 1. Place the generator on a flat, level surface.
- 2. Remove oil fill cap/dipstick to add oil.



- 3. Add up to 0.63 qt (0.6 L) of oil and replace oil fill cap/dipstick. DO NOT OVERFILL.
- 4. Check engine oil level daily and add as needed.

Add Oil Cont'd.



CAUTION

The engine is equipped with a low oil shut-off and will stop when the oil level in the crankcase falls below the threshold level.



NOTE

Check oil often during the break-in period. Refer to the Maintenance section for recommended service intervals.




NOTE

The generator rotor has a sealed, pre-lubricated ball bearing that requires no additional lubrication for the life of the bearing.

Add Fuel

- 1. Use clean, fresh, regular unleaded fuel with a minimum octane rating of 85 and an ethanol content of less than 10% by volume.
- 2. DO NOT mix oil with fuel.
- 3. Clean the area around the fuel cap.
- 4. Remove the fuel cap.
- 5. Slowly add fuel to the tank. DO NOT OVERFILL. Fuel can expand after filling. A minimum of 6.4 mm (1/4 in.) of space left in the tank is required for fuel expansion, more than 6.4 mm (1/4 in.) is recommended. Fuel can be forced out of the tank as a result of expansion if it is overfilled, and can affect the stable running condition of the product. When filling the tank, it is recommended to leave enough space for the fuel to expand.



6. Screw on the fuel cap and wipe away any spilled fuel.

(I) CAUTION

Use regular unleaded gasoline with a minimum octane rating of 85.

Do not mix oil and gasoline.

Fill tank to approximately 6.4 mm (1/4 in.) below the top of the tank to allow for fuel expansion.

DO NOT pump gas directly into the generator at the gas station. Use an approved container to transfer the fuel to the generator.

DO NOT fill fuel tank indoors.

DO NOT fill fuel tank when the engine is running or hot.

DO NOT overfill the fuel tank.

DO NOT light cigarettes or smoke when filling the fuel tank.

⚠ WARNING

Pouring fuel too fast through the fuel screen may result in blow back of fuel at the operator while filling. Add Fuel Cont'd.

◯ NOTE

Our engines work well with 10% or less ethanol blend fuels. When using blended fuels there are some issues worth noting:

- Ethanol-gasoline blends can absorb more water than gasoline alone.
- These blends can eventually separate, leaving water or a watery goo in the tank, fuel valve and carburetor.
- With gravity-fed fuel supplies, this compromised fuel can be drawn into the carburetor and cause damage to the engine and/or potential hazards.
- There are only a few suppliers of fuel stabilizer that are formulated to work with ethanol blend
- Any damages or hazards caused by using improper fuel, improperly stored fuel, and/ or improperly formulated stabilizers, are not covered by manufacture's warranty.

It is advisable to always shut off the fuel supply, run the engine to fuel starvation and drain the tank when the equipment is not in use for more than 30 days.

Grounding

Your generator must be properly connected to an appropriate ground to help prevent electric shock.



Failure to properly ground the generator can result in electric shock.

A ground terminal connected to the frame of the generator has been provided on the power panel. For remote grounding, connect of a length of heavy gauge (12 AWG minimum) copper wire between the generator ground terminal and a copper rod driven into the ground. We strongly recommend that you consult with a qualified electrician to ensure compliance with local electrical codes.

OPERATION

Generator Location

NEVER operate the generator inside any building, including garages, basements, crawlspaces and sheds, enclosure or compartment, including the generator compartment of a recreational vehicle. Please consult your local authority. In some areas, generators must be registered with the local utility. Generators used at construction sites may be subject to additional rules and regulations. Generators should be on a flat, level surface at all times. (Even while not in operation) Generators must have at least five feet of clearance from all combustible material. In addition to clearance from all combustible material, generators must also have at least three feet of clearance on all sides to allow for adequate cooling, maintenance and servicing. Generators should never be started or operated in the back of a SUV, camper, trailer, in the bed of a truck (regular, flat or otherwise), under staircases/stairwells, next to walls or buildings, or in any other location that will not allow for adequate cooling of the generator and/or the muffler. DO NOT contain generators during operation. Allow generators to properly cool before transport or storage. Place the generator in a well-ventilated area. DO NOT place the generator near vents or intakes where exhaust fumes could be drawn into occupied or confined spaces. Carefully consider wind and air currents when positioning generator.

Failure to follow proper safety precautions may void manufacturer's warranty.

⚠ WARNING

Do not operate or store the generator in rain, snow, or wet weather.

Using a generator or electrical appliance in wet conditions, such as rain or snow, or near a pool or sprinkler system, or when your hands are wet, could result in electrocution.

⚠ WARNING

During operation the muffler and exhaust fumes produced will become hot. If adequate cooling and breathing space are not supplied, or if the generator is blocked or contained, temperatures can become extremely heated and may lead to fire.

Grounding

The generator system ground connects the frame to the ground terminals on the power panel. The system ground is connected to the AC neutral wire.

Surge Protection

CAUTION

Voltage fluctuation may impair the proper functioning of sensitive electronic equipment.

Electronic devices, including computers and many programmable appliances use components that are designed to operate within a narrow voltage range and may be affected by momentary voltage fluctuations. While there is no way to prevent voltage fluctuations, you can take steps to protect sensitive electronic equipment.

1. Install UL1449, CSA-listed, plug-in surge suppressors on the outlets feeding your sensitive equipment. Surge suppressors come in single- or multi-outlet styles. They're designed to protect against virtually all short-duration voltage fluctuations.

Starting the Engine

- 1. Make certain the generator is on a flat, level surface.
- 2. Disconnect all electrical loads from the generator. Never start or stop the generator with electrical devices plugged in or turned on.
- 3. Turn the Fuel Valve to the "ON" position.
- 4. Flip the ignition switch to the "ON" position.
- 5. Move the choke lever to the "CHOKE" position.
- 6. Pull the starter cord slowly until resistance is felt and then pull rapidly
- 7. Do not over-choke. As as soon as engine starts, move the choke lever to the "RUN" position.



NOTE

Keep choke lever in "Choke" position for only 1 pull of the recoil starter. After first pull, move choke lever to the "Run" position for up to the next 3 pulls of the recoil starter. Too much choke leads to sparkplug fouling/engine flooding due to the lack of incoming air. This will cause the engine not to start.



■ NOTE

If the engine starts but does not run make certain that the generator is on a flat, level surface. The engine is equipped with a low oil sensor that will prevent the engine from running when the oil level falls below a critical threshold.

Connecting Electrical Loads

- 1. Let the engine stabilize and warm up for a few minutes after starting
- 2. Plug in and turn on the desired 120 Volt AC single phase, 60 Hz electrical loads.
- DO NOT connect 3-phase loads to the generator.
- DO NOT connect 50 Hz loads to the generator.
- DO NOT overload the generator.



◯ NOTE

Connecting a generator to your electric utility company's power lines or to another power source may be against the law. In addition this action, if done incorrectly, could damage your generator and appliances and could cause serious injury or even death to you or a utility worker who may be working on nearby power lines. If you plan to run a portable electric generator during an outage, please notify your electric utility company immediately and remember to plug your appliances directly into the generator. Do not plug the generator into any electric outlet in your home. Doing so could create a connection to the utility company power lines. You are responsible for ensuring that your generator's electricity does not feed back into the electric utility power lines.

If the generator will be connected to a building electrical system, consult your local utility company or a qualified electrician. Connections must isolate generator power from utility power and must comply with all applicable laws and codes.

Stopping the Engine

- 1. Turn off and unplug all electrical loads. Never start or stop the generator with electrical devices plugged in or turned on.
- 2. Let the generator run at no-load for several minutes to stabilize internal temperatures of the engine and generator.
- 3. Turn the Fuel Valve to the "OFF" position.
- 4. Let the engine run until fuel starvation has stopped the engine. This usually takes a few minutes.
- 5. Press the ignition switch to the "OFF" position. **Important:** Always ensure that the Fuel Valve and the Engine Switch are in the "OFF" position when the engine is not in use.



⊋NOTE

If the engine will not be used for a period of two (2) weeks or longer, please see the Storage section for proper engine and fuel storage.

OPERATION

Do Not Overload Generator

Capacity

Follow these simple steps to calculate the running and starting watts necessary for your purposes.

- 1. Select the electrical devices you plan on running at the same time.
- 2. Total the running watts of these items. This is the amount of power you need to keep your items running.
- 3. Identify the highest starting wattage of all devices identified in step 1. Add this number to the number calculated in step 2. Surge wattage is the extra burst of power needed to start some electric driven equipment. Following the steps listed under "Power Management" will guarantee that only one device will be starting at a time.

Power Management

Use the following formula to convert voltage and amperage to watts:

Volts x Amps = Watts

To prolong the life of your generator and attached devices, follow these steps to add electrical load:

- 1. Start the generator with no electrical load attached
- 2. Allow the engine to run for several minutes to stabilize.
- 3. Plug in and turn on the first item. It is best to attach the item with the largest load first.
- 4. Allow the engine to stabilize.
- 5. Plug in and turn on the next item.
- 6. Allow the engine to stabilize.
- 7. Repeat steps 5-6 for each additional item.



Never exceed the specified capacity when adding loads to the generator.

MAINTENANCE AND STORAGE

The owner/operator is responsible for all periodic maintenance.



Never operate a damaged or defective generator.

⚠ WARNING

Tampering with the factory set governor will void your warranty.

↑ WARNING

Improper maintenance will void your warranty.



Maintenance, replacement, or repair of emission control devices and systems may be performed by any non-road engine repair establishment or individual.

Complete all scheduled maintenance in a timely manner. Correct any issue before operating the generator.

NOTE

For service or parts assistance, contact our help line at 1-877-338-0999

Engine Maintenance

To prevent accidental starting, remove and ground spark plug wire before performing any service.

0il


Change oil when the engine is warm. Refer to the oil specification to select the proper grade of oil for your operating environment.

- 1. Remove the oil drain plug with a 12 mm socket and extension.
- 2. Allow the oil to drain completely.
- 3. Replace the drain plug.
- 4. Remove oil fill cap/dipstick to add oil.
- 5. Add 0.63 qt (0.6 L) of oil and replace oil fill cap/dipstick. DO NOT OVERFILL.
- 6. Dispose of used oil at an approved waste management facility.

Oil Cont'd.


NOTE

Once oil has been added, a visual check should show oil about 1-2 threads from running out of the fill hole. If using the dipstick to check oil level, DO NOT screw in the dipstick while checking.



Spark Plugs

- 1. Remove the spark plug cable from the spark plug.
- 2. Use the spark plug tool that shipped with your generator to remove the plug.
- 3. Inspect the electrode on the plug. It must be clean and not worn to produce the spark required for ignition.
- 4. Make certain the spark plug gap is 0.7 0.8 mm or (0.028 - 0.031 in.).



- 5. Refer to the spark plug recommendation in Specifications section when replacing the plug.
- 6. Carefully thread the plug into the engine.
- 7. Use the spark plug tool to firmly install the plug.
- 8. Attach the spark plug wire to the plug.


Air Filter

- 1. Remove the snap-on cover holding the air filter to the assembly.
- 2. Remove the foam element.
- 3. Wash in liquid detergent and water. Squeeze thoroughly dry in a clean cloth.
- 4. Saturate in clean engine oil.
- 5. Squeeze in a clean, absorbent cloth to remove all excess oil.
- 6. Place the filter in the assembly.
- 7. Reattach the air filter cover and snap in place.

MAINTENANCE AND STORAGE

Spark Arrester

- 1. Allow the engine to cool completely before servicing the spark arrester.
- 2. Remove the two (2) screws holding the cover plate which retains the end of the spark arrester to the muffler.
- 3. Remove the spark arrester screen.
- 4. Carefully remove the carbon deposits from the spark arrester screen with a wire brush.
- 5. Replace the spark arrester if it is damaged.
- 6. Position the spark arrester in the muffler and attach with the two screws.



! CAUTION

Failure to clean the spark arrester will result in degraded engine performance.

Cleaning

(!) CAUTION

DO NOT spray engine with water.

Water can contaminate the fuel system.

Use a damp cloth to clean exterior surfaces of the engine. Use a soft bristle brush to remove dirt and oil. Use an air compressor (25 PSI) to clear dirt and debris

Adjustments

The air-fuel mixture is not adjustable. Tampering with the governor can damage your generator and your electrical devices and will void your warranty. CPE recommends that you contact our service line at 1-877-338-0999 for all other service and/or adjustment

Maintenance Schedule

Follow the service intervals indicated in the following maintenance schedule.

Service your generator more frequently when operating in adverse conditions.

Contact our help line at 1-877-338-0999 to locate the nearest Champion Power Equipment certified service dealer for your generator or engine maintenance needs.

Every 8 hours or daily		
Check oil level		
Clean around air intake and muffler		
First 5 Hours		
Change oil		
Every 50 hours or every season		
Clean air filter		
Change oil if operating under heavy load or in hot environments		
Every 100 hours or every season		
Change oil		
Clean/Adjust spark plug		
Check/Adjust valve clearance*		
Clean spark arrester		
Clean fuel tank and filter*		
Every 3 years		
Replace fuel line		

^{*}To be performed by knowledgeable, experienced owners or Champion Power Equipment certified dealers.

from the engine.

MAINTENANCE AND STORAGE

Generator Maintenance

Make certain that the generator is kept clean and stored properly. Only operate the unit on a flat, level surface in a clean, dry operating environment. DO NOT expose the unit to extreme conditions, excessive dust, dirt, moisture or corrosive vapors.

(!) CAUTION

DO NOT use a garden hose to clean the generator.

Water can enter the generator through the cooling slots and damage the generator windings.

Use a damp cloth to clean exterior surfaces of the generator. Use a soft bristle brush to remove dirt and oil.

Use an air compressor (25 PSI) to clear dirt and debris from the generator.

Inspect all air vents and cooling slots to ensure that they are clean and unobstructed.

Storage

The generator should be started at least once every 14 days and allowed to run for at least 20 minutes. For longer term storage, please follow these guidelines.

Generator Storage

- 1. Add a properly formulated fuel stabilizer to the tank.
- 2. Be sure all appliances are disconnected from the generator.
- 3. Run the generator for a few minutes so the treated fuel cycles through the fuel system and carburetor.
- 4. Turn the fuel valve to the "Off" position.
- 5. Let the generator run until fuel starvation has stopped the engine. This usually takes a few minutes.
- 6. The generator needs to cool completely before cleaning and storage.
- 7. Clean the generator according to the maintenance section.
- 8. Change the oil.
- 9. Remove the spark plug and pour about 1/2 ounce of oil into the cylinder. Crank the engine slowly to distribute the oil and lubricate the cylinder.
- 10. Reattach the spark plug.
- 11. Store the unit in a clean, dry place out of direct sunlight.

Generator Storage Cont'd.



NOTE

Our engines work well with 10% or less ethanol blend fuels. When using blended fuels there are some issues worth noting:

- Ethanol-gasoline blends can absorb more water than gasoline alone.
- These blends can eventually separate, leaving water or a watery goo in the tank, fuel valve and carburetor.
- With gravity-fed fuel supplies, this compromised fuel can be drawn into the carburetor and cause damage to the engine and/or potential hazards.
- There are only a few suppliers of fuel stabilizer that are formulated to work with ethanol blend fuels.
- Any damages or hazards caused by using improper fuel, improperly stored fuel, and/ or improperly formulated stabilizers, are not covered by manufacture's warranty.

It is advisable to always shut off the fuel supply, run the engine to fuel starvation and drain the tank when the equipment is not in use for more than 30 days.



\land DANGER

Generator exhaust contains odorless and colorless carbon monoxide gas.

To avoid accidental or unintended ignition of your generator during periods of storage, the following precautions should be followed:

 When storing the generator for short or extended periods of time make sure that the Engine Switch and the Fuel Valve are set in the OFF position.

SPECIFICATIONS

Engine Specifications

_	Model	 	YF168FD-2-01
-	Displacement	 	196cc
-	Type	 	4-Stroke OHV
_	Start Type	 	Recoil

Generator Specifications

-	morator opcomountons
-	Model
-	Rated Wattage
-	Starting Wattage
-	AC Voltage
-	Phase
-	Frequency
-	Fuel Capacity
-	Gross Weight
-	Net Weight
-	Height 20.3 inches (51.5 cm)
-	Width
_	Length

Fuel


Fuel capacity is 4.0 gallons (15 L). Use regular unleaded gasoline with a minimum octane rating of 85 and an ethanol content of less than 10% by volume.

Oil

Use 10W-30 automotive oil. Oil capacity is 0.63 qt (0.6 L).

DO NOT OVERFILL.

Please reference the following chart for recommended oil types for use in the generator.



Spark Plugs

OEM spark plug: NHSP F6RTC

Replacement spark plug: NGK BPR6ES or equivalent Make certain the spark plug gap is 0.7 - 0.8 mm or (0.028 - 0.031 in.).


Maintenance Valve Clearance

- Intake: 0.13 0.17 mm (0.005 0.007 in.)
- Exhaust: 0.18 0.22 mm (0.007 0.009 in.) Note: Tech bulletin regarding the valve adjustment procedure is on www.championpowerequipment.com.


An Important Message About Temperature

Your Champion Power Equipment product is designed and rated for continuous operation at ambient temperatures up to 40°C (104°F). When your product is needed your product may be operated at temperatures ranging from -15°C (5°F) to 50°C (122°F) for short periods. If the product is exposed to temperatures outside this range during storage, it should be brought back within this range before operation. In any event, the product must always be operated outdoors, in a well-ventilated area and away from doors, windows and other vents.

Wiring Diagram




Parts Diagram



#	Part Number	Description	Qty
1	26.402	Engine	
2	122.190005.00	Rubber, Fore-Cover	
3	122.190005.01	Rubber, Fore-Cover	1
4	123.191100.21	Rotor Assembly	1
5	2.08.022	Flange Bolt M8×242	1
6	1.96.08	Washer Ø8	1
7	1.7244.08	Lock Washer Ø8	1
8	123.191200.21	Stator Assembly	1
9	123.191002.01	Stator Cover	1
10	122.190002.00	End Housing	1
11	2.08.065	Flange Bolt M6×168	4
12	1.97.1.06	WasherØ6	4
13	1.93.06	Lock Washer Ø6	8
14	122.190300.00	Carbon Brush Assembly	1
15	122.190004.01	Pinch	1
16	1.93.05	Lock Washer Ø5	3
17	1.5783.0516	Bolt M5×16	3
18	1.97.1.05	WasherØ5	2
19	122.190200.04	AVR	1
20	1.16674.0516	Flange Bolt M5×16	2
21	122.190003.00.48	Generator End Cover	1
22	1.16674.0512.2	Flange Bolt M5×12	3
23	122.190400.00	Terminal Block	1
24	122.190018.00	Bracket, Muffler	1
25	1.16674.0820	Flange Bolt M8×20	3
26	122.190018.01	Bracket, Muffler	1
27	1.5789.0612	Flange Bolt M6×12	11
28	1.9074.4.0514	Bolt And Washer Assembly M5×14	2
29	46.101503.08	Plate,Spark Arrester	1
30	46.101300.08	Arrester Assembly, Spark	1
31	26.101000.00	Muffler Assembly	1
32	23.102000.03.2	Muffler Cover	1
33	1.6175.08	Nut M8	2
34	1.93.08	Lock Washer Ø8	2
35	1.848.08	Washer Ø8	2
36	26.100001.00	Muffler Gasket	1
37	23.090006.21	Holder, Air Cleaner	1
38	1.5789.0608	Flange Bolt M6×8	1
39 40		Pipe,Fuel (5.5in)	2
41	2.06.007	Clamp Fuel Cock	1
41	122.070400.05	Fuel Tank	1
43	122.071000.06.48	Mount Vibration, Fuel Tank	4
44	2.03.004	Washer Ø6	4
45	1.5789.0620.2	Flange Bolt M6×20	4
46	122.072000.02	Fuel Meter Assembly	1
47	1.819.0510	Screw M5×10	2
48	122.070300.02	Fuel Filter	1
0			

#	Part Number	Description	Qty
49	122.070100.03	Fuel Tank Cap	1
50	152.200702.00	Cover, Handle	1
51	122.200701.01.2	Handle	1
52	1.6177.1.08	Nut M8	14
53	1.5789.0845	Flange Bolt M8×45	2
54	6.2.232.318.2	Frame	1
55	122.200800.04.2	Control Panel Defend Board	1
56	122.201200.02	Motor Mount	2
57	122.201200.03	Motor Mount	2
58	1.6182.10	Nut M10	2
59	122.201701.05.48	8in Wheel	2
60	122.200016.01	Bush Ø16ר10.5×58.5	2
61	1.96.10	Washer Ø10	2
62	1.5782.10105	Bolt M10×105	2
63	1.5783.0622.3	Bolt M6×22	1
64	1.6175.06.3	Nut M6	2
65	1.97.1.06.3	WasherØ6	2
66	1.93.06.3	Lock Washer Ø6	2
67	1.862.06	Lock Washer Ø6	2
68	1.6177.1.06	Nut M6	1
69	5.1900.029	Grounding Line	1
70	122.200800.03.2	Control Panel Defend Board	1
71	1.5789.0816	Flange Bolt M8×16	2
72	152.200002.00.2	Support Leg	1
73	152.201400.00	Rubber,Support	2
74	1.5789.0825	Flange Bolt M8×25	2
75	2.08.068.2	Flange Bolt M5×13	4
76	122.01.099.2	Control Panel	1
77	5.1000.004.3	Switch	1
78	5.1400.003	Voltage Meter	1
79	1.848.03.2	Washer Ø3	4
80	1.859.03.2	Lock Washer Ø3	4
81	1.6175.03.2	Nut M3	4
82	5.1120.023	Receptacle L5-30R	1
83	1.9074.4.0414.1	Bolt And Washer Assembly M4×14	6
84	1.6177.1.04.1	Nut M4	6
85	5.1120.027	Receptacle 5-20R	2
86	122.210003.02	Plug	1
87	5.1310.001	Conduit (metal)	1
88	122.210003.04	Plug	1
89	5.1810.000	Over Voltage Protector	1
90	1.823.0514	Screw M5×14	1
91	5.1210.920	AC.20A Breaker	1
92	5.1210.925	AC.25A Breaker	1
93	122.210002.03	Control Box	1
94	1.9074.1.0538.2	Bolt And Washer Assembly M5×38	3
95	122.210003.00	Plug	1

Engine Parts Diagram



	5		-
#	Part Number	Description	Qty
1	1.5789.0608	Flange Bolt M6×8	6
2	22.061100.00.2	Recoil Starter Cover	1
3	21.061005.00	Recoil Starter Spring	1
4	2.10.003	Rope (Ø5×1550)	1
5	21.061001.01	Recoil Starter Reel	1
6	45.060003.00	Spring, Ratchet	2
7	45.060002.00	Starter Ratchet (Iron)	2
8	45.060009.00	Spring,Ratchet Guide	1
9 10	45.060007.00 45.060008.00	Ratchet Guide	1
11	24.040004.00	Screw, Ratchet Guide Guide Plate Push Rod	1
12	1.5789.0612	Flange Bolt M6×12	8
13	24.080100.01.48	Fan Cover	1
14	24.091100.20	Base, Air Cleaner	1
15	21.061300.00	Handle (soft)	1
16	24.130004.20	Gasket, Air Cleaner (No Asbestos)	1
17	22.061000.00	Recoil Assembly	1
18	24.091000.20	Air Cleaner Assembly	1
19	26.131000.20	Carburetor	1
20	2.03.016	Washer, Drain Bolt (Ø10ר16×1.5)	2
21	2.02.006	Nut (M14×1.5)	1
22	21.060001.01	Pulley, Starter	1
23	23.080001.00	Cooling Fan	1
24	24.120100.02	Flywheel (manual Start EPA)	1
25	2.11.001	Oil Seal (Ø25ר41.3×6)	2
26	2.03.020.1	Washer (Ø6.2ר15×0.5)	1
27	21.110100.00	Gear, Governor	1
28	23.130100.20	Choke Lever	1
29	21.110013.00	Shaft, Govorner, Gear	1
30	21.110011.00	Clip, Govorner, Gear	1
31	22.130003.00	Gasket, Carburetor (No Asbestos)	1
32	21.110012.01	Bushing, Govorner Gear (Iron)	1
33	24.130002.00	Gasket, Insulator (No Asbestos)	1
34	23.130001.00	Insulator, Carburetor	
35	23.080600.00	Air Guide, Right Side	1
36	2.01.003	Stud Bolt M6×90	2
37	26.030100.00	Crankcase (200)	1
38	21.127000.01	Oil Level Sensor	1
39	26.010100.00	Cylinder Head (168-2)	1
40	23.050200.00	Connecting Rod Crankshaft (A 200Engine For	1
		Equipment)	2
42	1.276.6205	Bearing 6205 Gasket, Crankcase Cover (No	
43	24.030008.00	Asbestos)	
44	22.031000.00.48	Oil Dipstick Assembly	
45	122.070011.05		
46	23.030007.01	Cover, Crankcase (Engine For Equipment)	1
47	1.5789.0832.0.8	Flange Bolt M8×32 6	
48	23.091002.21	Seal, Air Cleaner 1	
49	23.110006.00	Rod Governor 1	
50	21.110003.00	Arm, Governor 1	
51	1.6177.06	Flange Nut M6	3

S2 21.10001.00 Shaft, Governor Arm 1	#	Part Number	Description	Qtv
53 22.123000.02 Ignition Coll (Shield EPA) 1		1		
54 1.5789.0625 Flange Bolt M6x25 2 55 23.110005.01 Spring, Throttle Return 1 56 23.110007.00 Spring, Governor 1 57 2.08.040 Bolt, Governor Arm (M6x21) 1 58 21.110008.00 Pin, Shaft 1 59 24.080300.00 Control Assembly (Engine For Equipment) 1 60 25.040013.00 Lifter, Valve 2 61 2.04.001 Dowel Pin (Ø9x14) 2 62 26.041000.00 Camshaft (200 EPA) 1 63 2.14.012 Sem.Key (4x7.5x19) 1 64 2.08.037 Bolt, Drain (M10x1.25x25) 2 65 26.050005.00 Piston 1 66 23.05003.00 Wrist Pin 1 67 2.09.001 Circlip (Ø18xØ1) 2 68 26.050302.00 Ring, Second Piston 1 70 26.050301.00 Ring, First Piston 1 71 26.050302.00 Ring, Fi				<u> </u>
55 23.110005.01 Spring, Throttle Return 1				-
56 23.110007.00 Spring, Governor 1 57 2.08.040 Bolt, Governor Arm (M6x21) 1 58 21.110008.00 Pin, Shaft 1 59 24.080300.00 Control Assembly (Engine For Equipment) 1 60 25.040013.00 Liffer, Valve 2 61 2.04.001 Dowel Pin (Ø9x14) 2 62 26.041000.00 Camshaft (200 EPA) 1 63 2.14.012 Sem.Key (4x7.5x19) 1 64 2.08.037 Bolt, Drain (M10x1.25x25) 2 65 26.050005.00 Piston 1 67 2.09.001 Circlip (Ø18xØ1) 2 68 26.050303.00 Ring, Dil 1 70 26.050303.00 Ring, Goll 1 70 26.050303.00 Ring, First Piston 1 71 26.050302.00 Ring, First Piston 1 72 2.04.003 Dowel Pin (Ø10x14) 2 73 23.040002.00 Valve, Intake			_ ~	-
57 2.08.040 Bolt, Governor Arm (M6x21) 1 58 21.110008.00 Pin, Shaft 1 59 24.080300.00 Pin, Shaft 1 60 25.040013.00 Lifter, Valve 2 61 2.04.001 Dowel Pin (Ø9x14) 2 62 26.041000.00 Camshaft (200 EPA) 1 63 2.14.012 Sem.Key (4×7.5×19) 1 64 2.08.037 Bolt, Drain (M10x1.25×25) 2 65 26.050005.00 Piston 1 66 23.050003.00 Wrist Pin 1 67 2.09.001 Circlip (Ø18ר1) 2 68 26.050303.00 Ring, Gil 1 70 26.050303.00 Ring, Second Piston 1 71 26.050303.00 Ring, Second Piston 1 72 26.050300.00 Ring, Second Piston 1 73 23.04003 Dowel Pin (Ø10×14) 2 74 26.050300.00 Gasket, Cylinder Head (168×2) 1<			1 3,	1
58 21.110008.00 Pin, Shaft 1 59 24.080300.00 Control Assembly (Engine For Equipment) 1 60 25.040013.00 Lifter, Valve 2 61 2.04.001 Dowel Pin (Ø9×14) 2 62 26.041000.00 Camshaft (200 EPA) 1 63 2.14.012 Sem.Key (4×7.5×19) 1 64 2.08.037 Bolt, Drain (M10×1.25×25) 2 65 26.050005.00 Piston 1 66 23.050003.00 Wrist Pin 1 67 2.09.001 Circlip (Ø18ר1) 2 68 26.050303.00 Ring, Oil 1 70 26.050302.00 Ring, First Piston 1 71 26.050301.00 Ring, First Piston 1 72 2.04.003 Dowel Pin (Ø10×14) 2 73 23.040002.00 Valve, Intake 1 74 23.040002.00 Valve, Exhaust 1 75 26.080400.01 Air Guide, Lower (200 G)	57	2.08.040		1
Equipment Equi	58	21.110008.00	Pin, Shaft	1
61 2.04.001 Dowel Pin (Ø9×14) 2 62 26.041000.00 Camshaft (200 EPA) 1 63 2.14.012 Sem.Key (4×7.5×19) 1 64 2.08.037 Bolt, Drain (M10×1.25×25) 2 65 26.050005.00 Piston 1 66 23.050003.00 Wrist Pin 1 67 2.09.001 Circlip (Ø18ר1) 2 68 26.050302.00 Ring, Dil 1 70 26.050302.00 Ring, First Piston 1 71 26.030301.00 Ring, First Piston 1 71 26.030301.00 Ring, First Piston 1 71 26.030301.00 Ring, First Piston 1 72 2.04.003 Dowel Pin (Ø10×14) 2 73 23.040002.00 Valve, Intake 1 74 23.040006.00 Valve, Intake 1 75 26.080400.01 Air Guide, Lower (200 G) 1 76 2.15.02 (F6RTC) Spark Plug (F6RTC)	59	24.080300.00	, , ,	1
62 26.041000.00 Camshaft (200 EPA) 1 63 2.14.012 Sem.Key (4x7.5x19) 1 64 2.08.037 Bolt, Drain (M10x1.25x25) 2 65 26.050005.00 Piston 1 66 23.050003.00 Wrist Pin 1 67 2.09.001 Circlip (Ø18xØ1) 2 68 26.050303.00 Ring, Oil 1 70 26.050301.00 Ring, First Piston 1 71 26.030009.00 Gasket, Cylinder Head (168-2) 1 72 2.04.003 Dowel Pin (Ø10x14) 2 73 23.040002.00 Valve, Intake 1 74 23.040006.00 Valve, Exhaust 1 75 26.080400.01 Air Guide, Lower (200 G) 1 76 2.15.002 (F6RTC) Spark Plug (F6RTC) 1 77 1.5789.0855 Flange Bolt M8x55 4 78 23.040017.00 Oil Seal, Valve (Iron) 2 79 21.040003.00 Spring, Valve <td>60</td> <td>25.040013.00</td> <td>Lifter, Valve</td> <td>2</td>	60	25.040013.00	Lifter, Valve	2
63 2.14.012 Sem.Key (4x7.5x19) 1 64 2.08.037 Bolt, Drain (M10x1.25x25) 2 65 26.050005.00 Piston 1 66 23.050003.00 Wrist Pin 1 67 2.09.001 Circlip (Ø18xØ1) 2 68 26.050302.00 Ring, Oil 1 70 26.050301.00 Ring, First Piston 1 71 26.030009.00 Gasket, Cylinder Head (168-2) 1 72 2.04.003 Dowel Pin (Ø10x14) 2 73 23.040002.00 Valve, Intake 1 74 23.040006.00 Valve, Exhaust 1 75 26.080400.01 Air Guide, Lower (200 G) 1 76 2.15.002 (F6RTC) Spark Plug (F6RTC) 1 77 1.5789.0855 Flange Bolt M8x55 4 78 23.040017.00 Oil Seal, Valve (Iron) 2 79 21.040003.00 Spring, Valve 2 80 21.040003.00 Retainer, Exhaust Val	61	2.04.001	Dowel Pin (Ø9×14)	2
64 2.08.037 Bolt, Drain (M10x1.25x25) 2 65 26.050005.00 Piston 1 66 23.050003.00 Wrist Pin 1 67 2.09.001 Circlip (Ø18xØ1) 2 68 26.050303.00 Ring, Oil 1 70 26.050301.00 Ring, First Piston 1 71 26.030009.00 Gasket, Cylinder Head (168-2) 1 72 2.04.003 Dowel Pin (Ø10x14) 2 73 23.040002.00 Valve, Intake 1 74 23.040006.00 Valve, Exhaust 1 75 26.080400.01 Air Guide, Lower (200 G) 1 76 2.15.002 (F6RTC) Spark Plug (F6RTC) 1 77 1.5789.0855 Flange Bolt M8x55 4 78 23.040017.00 Oil Seal, Valve (Iron) 2 80 21.040003.00 Spring, Valve 2 80 21.040001.00 Retainer, Exhaust Valve Spring (up) 1 81 21.040001.00 <th< td=""><td>62</td><td>26.041000.00</td><td>Camshaft (200 EPA)</td><td>1</td></th<>	62	26.041000.00	Camshaft (200 EPA)	1
65 26.050005.00 Piston 1 66 23.050003.00 Wrist Pin 1 67 2.09.001 Circlip (Ø18ר1) 2 68 26.050303.00 Ring, Oil 1 70 26.050301.00 Ring, First Piston 1 71 26.030009.00 Gasket, Cylinder Head (168-2) 1 72 2.04.003 Dowel Pin (Ø10×14) 2 73 23.040002.00 Valve, Intake 1 74 23.040006.00 Valve, Exhaust 1 75 26.080400.01 Air Guide, Lower (200 G) 1 76 2.15.002 (F6RTC) Spark Plug (F6RTC) 1 77 1.5789.0855 Flange Bolt M8×55 4 78 23.040017.00 Oil Seal, Valve (Iron) 2 79 21.040003.00 Spring, Valve 2 80 21.040007.00 Retainer, Exhaust Valve Spring (up) 1 81 21.040001.00 Retainer, Intake Valve Spring (up) 1 82 21.040008.00 <td>63</td> <td>2.14.012</td> <td>Sem.Key (4×7.5×19)</td> <td>1</td>	63	2.14.012	Sem.Key (4×7.5×19)	1
66 23.050003.00 Wrist Pin 1 67 2.09.001 Circlip (Ø18ר1) 2 68 26.050303.00 Ring, Oil 1 69 26.050302.00 Ring, Second Piston 1 70 26.050301.00 Ring, First Piston 1 71 26.030009.00 Gasket, Cylinder Head (168-2) 1 72 2.04.003 Dowel Pin (Ø10x14) 2 73 23.040002.00 Valve, Intake 1 74 23.040006.00 Valve, Exhaust 1 75 26.080400.01 Air Guide, Lower (200 G) 1 76 2.15.002 (F6RTC) Spark Plug (F6RTC) 1 77 1.5789.0855 Flange Bolt M8×55 4 78 23.040017.00 Oil Seal, Valve (Iron) 2 79 21.040003.00 Spring, Valve 2 80 21.040003.00 Retainer, Exhaust Valve Spring (up) 1 81 21.040001.00 Retainer, Intake Valve Spring (up) 1 82 21.	64	2.08.037	Bolt, Drain (M10×1.25×25)	2
67 2.09.001 Circlip (Ø18ר1) 2 68 26.050303.00 Ring, Oil 1 69 26.050302.00 Ring, Second Piston 1 70 26.050301.00 Ring, First Piston 1 71 26.030009.00 Gasket, Cylinder Head (168-2) 1 72 2.04.003 Dowel Pin (Ø10×14) 2 73 23.040002.00 Valve, Intake 1 74 23.040006.00 Valve, Exhaust 1 75 26.080400.01 Air Guide, Lower (200 G) 1 76 2.15.002 (F6RTC) Spark Plug (F6RTC) 1 77 1.5789.0855 Flange Bolt M8×55 4 78 23.040017.00 Oil Seal, Valve (Iron) 2 79 21.040003.00 Spring, Valve 2 80 21.040007.00 Retainer, Exhaust Valve Spring (up) 1 81 21.040001.00 Retainer, Intake Valve Spring (up) 1 82 21.040020.00 Rocker Arm 1 84 22.	65	26.050005.00	Piston	1
68 26.050303.00 Ring, Oil 1 69 26.050302.00 Ring, Second Piston 1 70 26.050301.00 Ring, First Piston 1 71 26.030009.00 Gasket, Cylinder Head (168-2) 1 72 2.04.003 Dowel Pin (Ø10x14) 2 73 23.040002.00 Valve, Intake 1 74 23.040006.00 Valve, Exhaust 1 75 26.080400.01 Air Guide, Lower (200 G) 1 76 2.15.002 (F6RTC) Spark Plug (F6RTC) 1 77 1.5789.0855 Flange Bolt M8x55 4 78 23.040017.00 Oil Seal, Valve (Iron) 2 80 21.040003.00 Retainer, Exhaust Valve Spring (up) 1 81 21.040007.00 Retainer, Exhaust Valve Spring (up) 1 82 21.040008.00 Rotator, Exhaust Valve 1 83 24.040202.00 Shaft, Rocker Arm 1 84 22.040012.00 Screw, Valve Adjustment 2	66	23.050003.00	Wrist Pin	1
69 26.050302.00 Ring, Second Piston 1 70 26.050301.00 Ring, First Piston 1 71 26.030009.00 Gasket, Cylinder Head (168-2) 1 72 2.04.003 Dowel Pin (Ø10x14) 2 73 23.040002.00 Valve, Intake 1 74 23.040006.00 Valve, Exhaust 1 75 26.080400.01 Air Guide, Lower (200 G) 1 76 2.15.002 (F6RTC) Spark Plug (F6RTC) 1 77 1.5789.0855 Flange Bolt M8x55 4 78 23.040017.00 Oil Seal, Valve (Iron) 2 80 21.040003.00 Retainer, Exhaust Valve Spring (up) 1 81 21.040001.00 Retainer, Intake Valve Spring (up) 1 82 21.040002.00 Rotator, Exhaust Valve Walve Spring (up) 1 83 24.04022.00 Shaft, Rocker Arm 1 84 22.040002.00 Rocker Arm, Intake Valve 2 85 22.040012.00 Screw, Valve Adjustment 2<	67	2.09.001	Circlip (Ø18ר1)	2
70 26.050301.00 Ring, First Piston 1 71 26.030009.00 Gasket, Cylinder Head (168-2) 1 72 2.04.003 Dowel Pin (Ø10x14) 2 73 23.040002.00 Valve, Intake 1 74 23.040006.00 Valve, Exhaust 1 75 26.080400.01 Air Guide, Lower (200 G) 1 76 2.15.002 (F6RTC) Spark Plug (F6RTC) 1 77 1.5789.0855 Flange Bolt M8x55 4 78 23.040017.00 Oil Seal, Valve (Iron) 2 79 21.040003.00 Spring, Valve 2 80 21.040007.00 Retainer, Exhaust Valve Spring (up) 1 81 21.040001.00 Retainer, Intake Valve Spring (up) 1 82 21.040002.00 Rotator, Exhaust Valve Spring (up) 1 83 24.040202.00 Shaft, Rocker Arm 1 84 22.040009.00 Rocker Arm, Intake Valve 2 85 22.040012.00 Screw, Valve Adjustment 2 </td <td>68</td> <td>26.050303.00</td> <td>Ring, Oil</td> <td>1</td>	68	26.050303.00	Ring, Oil	1
71 26.030009.00 Gasket, Cylinder Head (168-2) 1 72 2.04.003 Dowel Pin (Ø10×14) 2 73 23.040002.00 Valve, Intake 1 74 23.040006.00 Valve, Exhaust 1 75 26.080400.01 Air Guide, Lower (200 G) 1 76 2.15.002 (F6RTC) Spark Plug (F6RTC) 1 77 1.5789.0855 Flange Bolt M8×55 4 78 23.040017.00 Oil Seal, Valve (Iron) 2 79 21.040003.00 Spring, Valve 2 80 21.040007.00 Retainer, Exhaust Valve Spring (up) 1 81 21.040001.00 Retainer, Intake Valve Spring (up) 1 82 21.040002.00 Rotator, Exhaust Valve 1 83 24.040202.00 Shaft, Rocker Arm 1 84 22.040009.00 Rocker Arm, Intake Valve 2 85 22.040012.00 Screw, Valve Adjustment 2 86 21.040021.00 Nut, Lock 2	69	26.050302.00	Ring, Second Piston	1
72 2.04.003 Dowel Pin (Ø10×14) 2 73 23.040002.00 Valve, Intake 1 74 23.040006.00 Valve, Exhaust 1 75 26.080400.01 Air Guide, Lower (200 G) 1 76 2.15.002 (F6RTC) Spark Plug (F6RTC) 1 77 1.5789.0855 Flange Bolt M8×55 4 78 23.040017.00 Oil Seal, Valve (Iron) 2 79 21.040003.00 Spring, Valve 2 80 21.040007.00 Retainer, Exhaust Valve Spring (up) 1 81 21.040001.00 Retainer, Intake Valve Spring (up) 1 82 21.040008.00 Rotator, Exhaust Valve 1 83 24.040202.00 Shaft, Rocker Arm 1 84 22.040009.00 Rocker Arm, Intake Valve 2 85 22.040012.00 Screw, Valve Adjustment 2 86 21.040021.00 Nut, Lock 2 87 1.971.06 Washer Ø6 2 88	70	26.050301.00	Ring, First Piston	1
73 23.040002.00 Valve, Intake 1 74 23.040006.00 Valve, Exhaust 1 75 26.080400.01 Air Guide, Lower (200 G) 1 76 2.15.002 (F6RTC) Spark Plug (F6RTC) 1 77 1.5789.0855 Flange Bolt M8x55 4 78 23.040017.00 Oil Seal, Valve (Iron) 2 79 21.040003.00 Spring, Valve 2 80 21.040007.00 Retainer, Exhaust Valve Spring (up) 1 81 21.040001.00 Retainer, Intake Valve Spring (up) 1 82 21.040008.00 Rotator, Exhaust Valve 1 83 24.040202.00 Shaft, Rocker Arm 1 84 22.040009.00 Rocker Arm, Intake Valve 2 85 22.040012.00 Screw, Valve Adjustment 2 86 21.040021.00 Nut, Lock 2 87 1.97.1.06 Washer Ø6 2 88 1.6177.1.06 Flange Nut M6 2 89 2	71	26.030009.00	Gasket, Cylinder Head (168-2)	1
74 23.040006.00 Valve, Exhaust 1 75 26.080400.01 Air Guide, Lower (200 G) 1 76 2.15.002 (FGRTC) Spark Plug (FGRTC) 1 77 1.5789.0855 Flange Bolt M8x55 4 78 23.040017.00 Oil Seal, Valve (Iron) 2 79 21.040003.00 Spring, Valve 2 80 21.040007.00 Retainer, Exhaust Valve Spring (up) 1 81 21.040001.00 Retainer, Intake Valve Spring (up) 1 82 21.040008.00 Rotator, Exhaust Valve 1 83 24.040202.00 Shaft, Rocker Arm 1 84 22.0400012.00 Screw, Valve Adjustment 2 85 22.040012.00 Screw, Valve Adjustment 2 86 21.040021.00 Nut, Lock 2 87 1.97.1.06 Washer Ø6 2 88 1.6177.1.06 Flange Nut M6 2 89 26.131017.20 Standard Main Jet 1 90 <	72	2.04.003	Dowel Pin (Ø10×14)	2
75 26.080400.01 Air Guide, Lower (200 G) 1 76 2.15.002 (F6RTC) Spark Plug (F6RTC) 1 77 1.5789.0855 Flange Bolt M8x55 4 78 23.040017.00 Oil Seal, Valve (Iron) 2 79 21.040003.00 Spring, Valve 2 80 21.040007.00 Retainer, Exhaust Valve Spring (up) 1 81 21.040001.00 Retainer, Intake Valve Spring (up) 1 82 21.040008.00 Rotator, Exhaust Valve 1 83 24.040202.00 Shaft, Rocker Arm 1 84 22.040009.00 Rocker Arm, Intake Valve 2 85 22.040012.00 Screw, Valve Adjustment 2 86 21.040021.00 Nut, Lock 2 87 1.97.1.06 Washer Ø6 2 88 1.6177.1.06 Flange Nut M6 2 89 26.131017.20 Standard Main Jet 1 90 24.040201.00 Retainer, Rocker Arm 1 91	73	23.040002.00	Valve, Intake	1
76 2.15.002 (F6RTC) Spark Plug (F6RTC) 1 77 1.5789.0855 Flange Bolt M8x55 4 78 23.040017.00 Oil Seal, Valve (Iron) 2 79 21.040003.00 Spring, Valve 2 80 21.040007.00 Retainer, Exhaust Valve Spring (up) 1 81 21.040001.00 Retainer, Intake Valve Spring (up) 1 82 21.040008.00 Rotator, Exhaust Valve 1 83 24.040202.00 Shaft, Rocker Arm 1 84 22.040009.00 Rocker Arm, Intake Valve 2 85 22.040012.00 Screw, Valve Adjustment 2 86 21.040021.00 Nut, Lock 2 87 1.97.1.06 Washer Ø6 2 88 1.6177.1.06 Flange Nut M6 2 89 26.131017.20 Standard Main Jet 1 90 24.04201.00 Retainer, Rocker Arm 1 91 23.040005.00 Push Rod 2 93 21.02000	74	23.040006.00	Valve, Exhaust	1
77 1.5789.0855 Flange Bolt M8x55 4 78 23.040017.00 Oil Seal, Valve (Iron) 2 79 21.040003.00 Spring, Valve 2 80 21.040007.00 Retainer, Exhaust Valve Spring (up) 1 81 21.040008.00 Rotator, Exhaust Valve Spring (up) 1 82 21.040008.00 Rotator, Exhaust Valve Spring (up) 1 83 24.040202.00 Shaft, Rocker Arm 1 84 22.040009.00 Rocker Arm, Intake Valve 2 85 22.040012.00 Screw, Valve Adjustment 2 86 21.040021.00 Nut, Lock 2 87 1.97.1.06 Washer Ø6 2 88 1.6177.1.06 Flange Nut M6 2 89 26.131017.20 Standard Main Jet 1 90 24.040201.00 Retainer, Rocker Arm 1 91 23.040005.00 Push Rod 2 93 21.020002.01 Gasket, Cylinder Head Cover 1 94	75	26.080400.01	Air Guide, Lower (200 G)	1
78 23.040017.00 Oil Seal, Valve (Iron) 2 79 21.040003.00 Spring, Valve 2 80 21.040007.00 Retainer, Exhaust Valve Spring (up) 1 81 21.040001.00 Retainer, Intake Valve Spring (up) 1 82 21.040008.00 Rotator, Exhaust Valve 1 83 24.040202.00 Shaft, Rocker Arm 1 84 22.040009.00 Rocker Arm, Intake Valve 2 85 22.040012.00 Screw, Valve Adjustment 2 86 21.040021.00 Nut, Lock 2 87 1.97.1.06 Washer Ø6 2 88 1.6177.1.06 Flange Nut M6 2 89 26.131017.20 Standard Main Jet 1 90 24.040201.00 Retainer, Rocker Arm 1 91 23.040010.00 Bolt, Rocker Arm 2 92 23.040005.00 Push Rod 2 93 21.020002.01 Gasket, Cylinder Head Cover 1 94 24	76	2.15.002 (F6RTC)	Spark Plug (F6RTC)	1
79 21.040003.00 Spring, Valve 2 80 21.040007.00 Retainer, Exhaust Valve Spring (up) 1 81 21.040001.00 Retainer, Intake Valve Spring (up) 1 82 21.040008.00 Rotator, Exhaust Valve 1 83 24.040202.00 Shaft, Rocker Arm 1 84 22.040099.00 Rocker Arm, Intake Valve 2 85 22.040012.00 Screw, Valve Adjustment 2 86 21.040021.00 Nut, Lock 2 87 1.97.1.06 Washer Ø6 2 88 1.6177.1.06 Flange Nut M6 2 89 26.131017.20 Standard Main Jet 1 90 24.040201.00 Retainer, Rocker Arm 1 91 23.040010.00 Bolt, Rocker Arm 2 93 21.020002.01 Gasket, Cylinder Head Cover 1 94 24.021000.00 Cylinder Head Cover (CPE) 1 95 23.020001.02 Breather Tube 1 96	77	1.5789.0855	Flange Bolt M8×55	4
80 21.040007.00 Retainer, Exhaust Valve Spring (up) 1 81 21.040001.00 Retainer, Intake Valve Spring (up) 1 82 21.040008.00 Rotator, Exhaust Valve 1 83 24.040202.00 Shaft, Rocker Arm 1 84 22.040009.00 Rocker Arm, Intake Valve 2 85 22.040012.00 Screw, Valve Adjustment 2 86 21.040021.00 Nut, Lock 2 87 1.97.1.06 Washer Ø6 2 88 1.6177.1.06 Flange Nut M6 2 89 26.131017.20 Standard Main Jet 1 90 24.040201.00 Retainer, Rocker Arm 1 91 23.040010.00 Bolt, Rocker Arm 2 92 23.040005.00 Push Rod 2 93 21.020002.01 Gasket, Cylinder Head Cover 1 94 24.021000.00 Cylinder Head Cover (CPE) 1 95 23.020001.02 Breather Tube 1 96 <th< td=""><td>78</td><td></td><td>Oil Seal, Valve (Iron)</td><td></td></th<>	78		Oil Seal, Valve (Iron)	
80 21.040007.00 (up) 1 81 21.040001.00 Retainer, Intake Valve Spring (up) 1 82 21.040008.00 Rotator, Exhaust Valve 1 83 24.040202.00 Shaft, Rocker Arm 1 84 22.040009.00 Rocker Arm, Intake Valve 2 85 22.040012.00 Screw, Valve Adjustment 2 86 21.040021.00 Nut, Lock 2 87 1.97.1.06 Washer Ø6 2 88 1.6177.1.06 Flange Nut M6 2 89 26.131017.20 Standard Main Jet 1 90 24.040201.00 Retainer, Rocker Arm 1 91 23.040010.00 Bolt, Rocker Arm 2 92 23.040005.00 Push Rod 2 93 21.020002.01 Gasket, Cylinder Head Cover 1 94 24.021000.00 Cylinder Head Cover (CPE) 1 95 23.020001.02 Breather Tube 1 96 1.5789.0615 Flange Bolt M6×15 4 97 2.01.010 Stud.Bolt (M8×	79	21.040003.00		2
82 21.040008.00 Rotator, Exhaust Valve 1 83 24.040202.00 Shaft, Rocker Arm 1 84 22.040009.00 Rocker Arm, Intake Valve 2 85 22.040012.00 Screw, Valve Adjustment 2 86 21.040021.00 Nut, Lock 2 87 1.97.1.06 Washer Ø6 2 88 1.6177.1.06 Flange Nut M6 2 89 26.131017.20 Standard Main Jet 1 90 24.040201.00 Retainer, Rocker Arm 1 91 23.040010.00 Bolt, Rocker Arm 2 92 23.040005.00 Push Rod 2 93 21.020002.01 Gasket, Cylinder Head Cover 1 94 24.021000.00 Cylinder Head Cover (CPE) 1 95 23.020001.02 Breather Tube 1 96 1.5789.0615 Flange Bolt M6x15 4 97 2.01.010 Stud.Bolt (M8x35) 2 98 2.06.007 Clip (Ø8xb6) 2 99 24.091200.20 Cover, Air Cleaner			(up)	
83 24.040202.00 Shaft, Rocker Arm 1 84 22.040009.00 Rocker Arm, Intake Valve 2 85 22.040012.00 Screw, Valve Adjustment 2 86 21.040021.00 Nut, Lock 2 87 1.97.1.06 Washer Ø6 2 88 1.6177.1.06 Flange Nut M6 2 89 26.131017.20 Standard Main Jet 1 90 24.040201.00 Retainer, Rocker Arm 1 91 23.040010.00 Bolt, Rocker Arm 2 92 23.040005.00 Push Rod 2 93 21.020002.01 Gasket, Cylinder Head Cover 1 94 24.021000.00 Cylinder Head Cover (CPE) 1 95 23.020001.02 Breather Tube 1 96 1.5789.0615 Flange Bolt M6x15 4 97 2.01.010 Stud.Bolt (M8x35) 2 98 2.06.007 Clip (Ø8xb6) 2 99 24.091200.20 Cover, Air Cleaner				
84 22.040009.00 Rocker Arm, Intake Valve 2 85 22.040012.00 Screw, Valve Adjustment 2 86 21.040021.00 Nut, Lock 2 87 1.97.1.06 Washer Ø6 2 88 1.6177.1.06 Flange Nut M6 2 89 26.131017.20 Standard Main Jet 1 90 24.040201.00 Retainer, Rocker Arm 1 91 23.040010.00 Bolt, Rocker Arm 2 92 23.040005.00 Push Rod 2 93 21.020002.01 Gasket, Cylinder Head Cover 1 94 24.021000.00 Cylinder Head Cover (CPE) 1 95 23.020001.02 Breather Tube 1 96 1.5789.0615 Flange Bolt M6×15 4 97 2.01.010 Stud.Bolt (M8×35) 2 98 2.06.007 Clip (Ø8×b6) 2 99 24.091200.20 Cover, Air Cleaner 1 100 23.091003.21 Element, Air Cleaner<				
85 22.040012.00 Screw, Valve Adjustment 2 86 21.040021.00 Nut, Lock 2 87 1.97.1.06 Washer Ø6 2 88 1.6177.1.06 Flange Nut M6 2 89 26.131017.20 Standard Main Jet 1 90 24.040201.00 Retainer, Rocker Arm 1 91 23.040010.00 Bolt, Rocker Arm 2 92 23.040005.00 Push Rod 2 93 21.020002.01 Gasket, Cylinder Head Cover 1 94 24.021000.00 Cylinder Head Cover (CPE) 1 95 23.020001.02 Breather Tube 1 96 1.5789.0615 Flange Bolt M6x15 4 97 2.01.010 Stud.Bolt (M8x35) 2 98 2.06.007 Clip (Ø8xb6) 2 99 24.091200.20 Cover, Air Cleaner 1 100 23.091003.21 Element, Air Cleaner 1 101 23.091001.21 Separator, Air Cleaner </td <td></td> <td></td> <td></td> <td>-</td>				-
86 21.040021.00 Nut, Lock 2 87 1.97.1.06 Washer Ø6 2 88 1.6177.1.06 Flange Nut M6 2 89 26.131017.20 Standard Main Jet 1 90 24.040201.00 Retainer, Rocker Arm 1 91 23.040010.00 Bolt, Rocker Arm 2 92 23.040005.00 Push Rod 2 93 21.020002.01 Gasket, Cylinder Head Cover 1 94 24.021000.00 Cylinder Head Cover (CPE) 1 95 23.020001.02 Breather Tube 1 96 1.5789.0615 Flange Bolt M6x15 4 97 2.01.010 Stud.Bolt (M8x35) 2 98 2.06.007 Clip (Ø8xb6) 2 99 24.091200.20 Cover, Air Cleaner 1 100 23.091003.21 Element, Air Cleaner 1 101 23.091001.21 Separator, Air Cleaner 1 102 2.03.021.1 Washer (Ø6.4xØ13x1)				
87 1.97.1.06 Washer Ø6 2 88 1.6177.1.06 Flange Nut M6 2 89 26.131017.20 Standard Main Jet 1 90 24.040201.00 Retainer, Rocker Arm 1 91 23.040010.00 Bolt, Rocker Arm 2 92 23.040005.00 Push Rod 2 93 21.020002.01 Gasket, Cylinder Head Cover 1 94 24.021000.00 Cylinder Head Cover (CPE) 1 95 23.020001.02 Breather Tube 1 96 1.5789.0615 Flange Bolt M6×15 4 97 2.01.010 Stud.Bolt (M8×35) 2 98 2.06.007 Clip (Ø8×b6) 2 99 24.091200.20 Cover, Air Cleaner 1 100 23.091003.21 Element, Air Cleaner 1 101 23.091001.21 Separator, Air Cleaner 1 102 2.03.021.1 Washer (Ø6.4ר13×1) 1				-
88 1.6177.1.06 Flange Nut M6 2 89 26.131017.20 Standard Main Jet 1 90 24.040201.00 Retainer, Rocker Arm 1 91 23.040010.00 Bolt, Rocker Arm 2 92 23.040005.00 Push Rod 2 93 21.020002.01 Gasket, Cylinder Head Cover 1 94 24.021000.00 Cylinder Head Cover (CPE) 1 95 23.020001.02 Breather Tube 1 96 1.5789.0615 Flange Bolt M6x15 4 97 2.01.010 Stud.Bolt (M8x35) 2 98 2.06.007 Clip (Ø8xb6) 2 99 24.091200.20 Cover, Air Cleaner 1 100 23.091003.21 Element, Air Cleaner 1 101 23.091001.21 Separator, Air Cleaner 1 102 2.03.021.1 Washer (Ø6.4xØ13x1) 1			· · · · · · · · · · · · · · · · · · ·	-
89 26.131017.20 Standard Main Jet 1 90 24.040201.00 Retainer, Rocker Arm 1 91 23.040010.00 Bolt, Rocker Arm 2 92 23.040005.00 Push Rod 2 93 21.020002.01 Gasket, Cylinder Head Cover 1 94 24.021000.00 Cylinder Head Cover (CPE) 1 95 23.020001.02 Breather Tube 1 96 1.5789.0615 Flange Bolt M6x15 4 97 2.01.010 Stud.Bolt (M8x35) 2 98 2.06.007 Clip (Ø8xb6) 2 99 24.091200.20 Cover, Air Cleaner 1 100 23.091003.21 Element, Air Cleaner 1 101 23.091001.21 Separator, Air Cleaner 1 102 2.03.021.1 Washer (Ø6.4xØ13x1) 1				
90 24.040201.00 Retainer, Rocker Arm 1 91 23.040010.00 Bolt, Rocker Arm 2 92 23.040005.00 Push Rod 2 93 21.020002.01 Gasket, Cylinder Head Cover 1 94 24.021000.00 Cylinder Head Cover (CPE) 1 95 23.020001.02 Breather Tube 1 96 1.5789.0615 Flange Bolt M6×15 4 97 2.01.010 Stud.Bolt (M8×35) 2 98 2.06.007 Clip (Ø8×b6) 2 99 24.091200.20 Cover, Air Cleaner 1 100 23.091003.21 Element, Air Cleaner 1 101 23.091001.21 Separator, Air Cleaner 1 102 2.03.021.1 Washer (Ø6.4ר13×1) 1			<u> </u>	-
91 23.040010.00 Bolt, Rocker Arm 2 92 23.040005.00 Push Rod 2 93 21.020002.01 Gasket, Cylinder Head Cover 1 94 24.021000.00 Cylinder Head Cover (CPE) 1 95 23.020001.02 Breather Tube 1 96 1.5789.0615 Flange Bolt M6x15 4 97 2.01.010 Stud.Bolt (M8x35) 2 98 2.06.007 Clip (Ø8xb6) 2 99 24.091200.20 Cover, Air Cleaner 1 100 23.091003.21 Element, Air Cleaner 1 101 23.091001.21 Separator, Air Cleaner 1 102 2.03.021.1 Washer (Ø6.4ר13×1) 1				-
92 23.040005.00 Push Rod 2 93 21.020002.01 Gasket, Cylinder Head Cover 1 94 24.021000.00 Cylinder Head Cover (CPE) 1 95 23.020001.02 Breather Tube 1 96 1.5789.0615 Flange Bolt M6x15 4 97 2.01.010 Stud.Bolt (M8x35) 2 98 2.06.007 Clip (Ø8xb6) 2 99 24.091200.20 Cover, Air Cleaner 1 100 23.091003.21 Element, Air Cleaner 1 101 23.091001.21 Separator, Air Cleaner 1 102 2.03.021.1 Washer (Ø6.4xØ13x1) 1				
93 21.020002.01 Gasket, Cylinder Head Cover 1 94 24.021000.00 Cylinder Head Cover (CPE) 1 95 23.020001.02 Breather Tube 1 96 1.5789.0615 Flange Bolt M6×15 4 97 2.01.010 Stud.Bolt (M8×35) 2 98 2.06.007 Clip (Ø8×b6) 2 99 24.091200.20 Cover, Air Cleaner 1 100 23.091003.21 Element, Air Cleaner 1 101 23.091001.21 Separator, Air Cleaner 1 102 2.03.021.1 Washer (Ø6.4ר13×1) 1				-
94 24.021000.00 Cylinder Head Cover (CPE) 1 95 23.020001.02 Breather Tube 1 96 1.5789.0615 Flange Bolt M6x15 4 97 2.01.010 Stud.Bolt (M8x35) 2 98 2.06.007 Clip (Ø8xb6) 2 99 24.091200.20 Cover, Air Cleaner 1 100 23.091003.21 Element, Air Cleaner 1 101 23.091001.21 Separator, Air Cleaner 1 102 2.03.021.1 Washer (Ø6.4ר13×1) 1				-
95 23.020001.02 Breather Tube 1 96 1.5789.0615 Flange Bolt M6x15 4 97 2.01.010 Stud.Bolt (M8x35) 2 98 2.06.007 Clip (Ø8xb6) 2 99 24.091200.20 Cover, Air Cleaner 1 100 23.091003.21 Element, Air Cleaner 1 101 23.091001.21 Separator, Air Cleaner 1 102 2.03.021.1 Washer (Ø6.4ר13×1) 1				
96 1.5789.0615 Flange Bolt M6×15 4 97 2.01.010 Stud.Bolt (M8×35) 2 98 2.06.007 Clip (Ø8×b6) 2 99 24.091200.20 Cover, Air Cleaner 1 100 23.091003.21 Element, Air Cleaner 1 101 23.091001.21 Separator, Air Cleaner 1 102 2.03.021.1 Washer (Ø6.4ר13×1) 1				-
97 2.01.010 Stud.Bolt (M8x35) 2 98 2.06.007 Clip (Ø8xb6) 2 99 24.091200.20 Cover, Air Cleaner 1 100 23.091003.21 Element, Air Cleaner 1 101 23.091001.21 Separator, Air Cleaner 1 102 2.03.021.1 Washer (Ø6.4ר13×1) 1				
98 2.06.007 Clip (Ø8×b6) 2 99 24.091200.20 Cover, Air Cleaner 1 100 23.091003.21 Element, Air Cleaner 1 101 23.091001.21 Separator, Air Cleaner 1 102 2.03.021.1 Washer (Ø6.4ר13×1) 1				
99 24.091200.20 Cover, Air Cleaner 1 100 23.091003.21 Element, Air Cleaner 1 101 23.091001.21 Separator, Air Cleaner 1 102 2.03.021.1 Washer (Ø6.4ר13×1) 1				
100 23.091003.21 Element, Air Cleaner 1 101 23.091001.21 Separator, Air Cleaner 1 102 2.03.021.1 Washer (Ø6.4ר13×1) 1			 	
101 23.091001.21 Separator, Air Cleaner 1 102 2.03.021.1 Washer (Ø6.4ר13×1) 1				
		23.091001.21	Separator, Air Cleaner	
103 1.5789.0620 Flange Bolt M6x20 1	102	2.03.021.1		
	103	1.5789.0620	Flange Bolt M6×20	1

TROUBLESHOOTING

Problem	Cause	Solution
Generator will not start	No fuel	Add fuel
	Faulty spark plug	Replace spark plug
	Unit loaded during start up	Remove load from unit
Generator will not start;	Low oil level	Fill crankcase to the proper level
Generator starts but runs roughly		Place generator on a flat, level surface
	Choke in the wrong position	Adjust choke
	Spark plug wire loose	Attach wire to spark plug
Generator shuts down during operation	Out of fuel	Fill fuel tank
	Low oil level	Fill crankcase to the proper level. Place generator on a flat, level surface
Generator cannot supply enough power or overheating	Generator is overloaded	Review load and adjust. See "Power Management"
	Insufficient ventilation	Check for air restriction. Move to a well ventilated area
No AC output	Cable not properly connected	Check all connections
	Connected device is defective	Replace defective device
	Circuit breaker is open	Reset circuit breaker
	Faulty brush assembly	Replace brush assembly (Service Center)
	Faulty AVR (auto voltage regulator)	Replace AVR (Service Center)
	Loose wiring	Inspect and tighten wiring connections
	Other	Contact the help line
Generator gallops	Engine governor defective	Contact the help line
Repeated circuit breaker tripping	Overload	Review load and adjust. See "Power Management"
	Faulty cords or device	Check for damaged, bare or frayed wires. Replace defective device

For further technical support:

Technical Service

Mon - Fri 8:30 AM - 5:00 PM (PST/PDT)

Toll Free: 1-877-338-0999

tech@championpowerequipment.com

WARRANTY

CHAMPION POWER EQUIPMENT 2 YEAR LIMITED WARRANTY

Warranty Qualifications

Champion Power Equipment (CPE) will register this warranty upon receipt of your Warranty Registration Card and a copy of your sales receipt from one of CPE's retail locations as proof of purchase.

Please submit your warranty registration and your proof of purchase within ten (10) days of the date of purchase.

Repair/Replacement Warranty

CPE warrants to the original purchaser that the mechanical and electrical components will be free of defects in material and workmanship for a period of one year (parts and labour) and two years (parts) from the original date of purchase (90 days (parts and labour) and 180 days (parts) for commercial and industrial use). Transportation charges on product submitted for repair or replacement under this warranty are the sole responsibility of the purchaser. This warranty only applies to the original purchaser and is not transferable.

Do Not Return The Unit To The Place Of Purchase

Contact CPE's Technical Service and CPE will troubleshoot any issue via phone or e-mail. If the problem is not corrected by this method, CPE will, at its option, authorize evaluation, repair or replacement of the defective part or component at a CPE Service Center. CPE will provide you with a case number for warranty service. Please keep it for future reference. Repairs or replacements without prior authorization, or at an unauthorized repair facility, will not be covered by this warranty.

Warranty Exclusions

This warranty does not cover the following repairs and equipment:

Normal Wear

Generators need periodic parts and service to perform well. This warranty does not cover repair when normal use has exhausted the life of a part or the equipment as a whole.

Installation, Use and Maintenance

This warranty will not apply to parts and/or labour if this generator is deemed to have been misused, neglected, involved in an accident, abused, loaded beyond the generator's limits, modified, installed improperly or connected incorrectly to any electrical component.

Installation, Use and Maintenance Cont'd.

Normal maintenance such as spark plugs, air filters, adjustments, fuel system cleaning and obstruction due to buildup is not covered by this warranty.

Other Exclusions

This warranty excludes:

- Cosmetic defects such as paint, decals, etc.
- Wear items such as filter elements, o-rings, etc.
- Accessory parts such as starting batteries, and storage covers.
- Failures due to acts of God and other force majeure events beyond the manufacturer's control.
- Problems caused by parts that are not original Champion Power Equipment parts.

This warranty does not apply to generators used for prime power in place of a utility.

Limits of Implied Warranty and Consequential Damage

Champion Power Equipment disclaims any obligation to cover any loss of time, use of this product, freight, or any incidental or consequential claim by anyone from using this generator. THIS WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.

A unit provided as an exchange will be subject to the warranty of the original unit. The length of the warranty governing the exchanged unit will remain calculated by reference to the purchase date of the original unit. This warranty gives you certain legal rights which may change from province to province. Your province may also have other rights you may be entitled to that are not listed within this warranty.

Contact Information

Address

Champion Power Equipment, Inc. **Customer Service** 10006 Santa Fe Springs Rd. Santa Fe Springs, CA 90670 www.championpowerequipment.com

Customer Service

Mon - Fri 8:30 AM - 5:00 PM (PST/PDT)

Toll Free: 1-877-338-0999

info@championpowerequipment.com

Fax no.: 1-562-236-9429

Technical Service

Mon - Fri 8:30 AM - 5:00 PM (PST/PDT)

Toll Free: 1-877-338-0999

tech@championpowerequipment.com 24/7 Tech Support: 1-562-204-1188

Champion Power Equipment, Inc (CPE), Emission Control System Warranty

Your Champion Power Equipment (CPE) engine complies with Environment Canada (EC) emission regulations.

YOUR WARRANTY RIGHTS AND OBLIGATIONS:

CPE is pleased to explain the Emission Control Systems Warranty on your 2013 small off-road engine. New engines must be designed, built and equipped, at the time of sale, to meet EC regulations for small non-road engines. CPE must warrant the emission control system on your small off-road engine for the period of time listed below, provided there has been no abuse, neglect, unapproved modification, or improper maintenance of your small off-road engine.

Your emission control system may include parts such as the carburetor, fuel-injection system, the ignition system, catalytic converter and fuel lines. Also included may be hoses, belts, connectors and other emission related assemblies. Where a warrantable condition exits, CPE will repair your small off-road engine at no cost to you including diagnosis, parts and labor.

MANUFACTURER'S EMISSION CONTROL SYSTEM WARRANTY COVERAGE:

This emission control system is warranted for two years, subject to provisions set forth below. If, during the warranty period, emission related part on your engine is defective in materials or workmanship, the part will be repaired or replaced by CPE.

OWNER WARRANTY RESPONSIBILITIES:

As the small off-road engine owner, you are responsible for the performance of the required maintenance listed in your Owner's Manual. CPE recommends that you retain all your receipts covering maintenance on your small off-road engine, but CPE cannot deny warranty solely for the lack of receipts or for your failure to ensure the performance of all scheduled maintenance.

As the small off-road engine owner, you should however be aware that CPE may deny you warranty coverage if your small, off-road engine or a part has failed due to abuse, neglect, improper maintenance or unapproved modifications.

You are responsible for presenting your small off-road engine to an Authorized CPE service outlet, CPE dealer or CPE, Santa Fe Springs, CA., USA as soon as a problem exists. The warranty repairs should be completed in a reasonable amount of time, not to exceed 30 days.

If you have any questions regarding your warranty rights and responsibilities, you should contact:

Champion Power Equipment, Inc. Customer Service 10006 Santa Fe Springs Road Santa Fe Springs, CA 90670 USA Tel: 1-877-338-0999

tech@championpowerequipment.com

EMISSION CONTROL SYSTEM WARRANTY

The following are specific provisions relative to your Emission Control System Warranty Coverage.

Emission Control System Warranty (ECS Warranty):

1. APPLICABILITY: The ECS Warranty Period shall begin on the date the new engine or equipment is delivered to its original, end-use purchaser, and shall continue for 24 consecutive months thereafter.

2. GENERAL EMISSIONS WARRANTY COVERAGE

CPE warrants to the original, end-use purchaser of the new engine or equipment and to each subsequent purchaser that each of its small off-road engines is:

- a. Designed, built and equipped so as to conform at the time of sale with applicable regulations under the Canadian Environmental Protection Act, 1999 (CEPA 1999).
- b. Free from defects in materials and workmanship that cause the failure of a warranted part to be identical in all material respects to the part as described in the engine manufacturer's application for certification for a period of two years.

3. THE WARRANTY ON EMISSION-RELATED PARTS WILL BE INTERPRETED AS FOLLOWS:

- a. Any warranted part that is not scheduled for replacement as required maintenance in the Owners Manual shall be warranted for the ECS Warranty Period. If any such part fails during the ECS Warranty Period, it shall be repaired or replaced by CPE according to Subsection "d" below. Any such part repaired or replaced under the ECS Warranty shall be warranted for any remainder of the ECS Warranty Period.
- b. Any warranted, emissions-related part which is scheduled only for regular inspection as specified in the Owners Manual shall be warranted for the ECS Warranty Period. A statement in such written instructions to the effect of "repair or replace as necessary", shall not reduce the ECS Warranty Period. Any such part repaired or replaced under the ECS Warranty shall be warranted for the remainder of the ECS Warranty Period.
- c. Any warranted, emissions-related part which is scheduled for replacement as required maintenance in the Owner's Manual shall be warranted for the period of time prior to the first scheduled replacement point for that part. If the part fails prior to the first scheduled replacement, the part shall be repaired or replaced by CPE according to Subsection "d" below. Any such emissions-related part repaired or replaced under the ECS Warranty, shall be warranted for the remainder of the ECS Warranty Period prior to the first scheduled replacement point for such emissions-related part.
- d. Repair or replacement of any warranted, emissions-related part under this ECS Warranty shall be performed at no charge to the owner at a CPE Authorized Service Outlet.
- e. The owner shall not be charged for diagnostic labor which leads to the determination that a part covered by the ECS Warranty is in fact defective, provided that such diagnostic work is performed at a CPE Authorized Service Outlet.
- f. CPE shall be liable for damages to other original engine components or approved modifications proximately caused by a failure under warranty of an emission-related part covered by the ECS Warranty.
- g. Throughout the ECS Warranty Period, CPE shall maintain a supply of warranted emission-related parts sufficient to meet the expected demand for such emission-related parts.
- h. Any CPE Authorized and approved emission-related replacement part may be used in the performance of any ECS Warranty maintenance or repair and will be provided without charge to the owner. Such use shall not reduce CPE's warranty obligation.
- i. Unapproved add-on or modified parts may not be used to modify or repair a CPE engine. Such use voids this ECS Warranty and shall be sufficient grounds for disallowing an ECS Warranty claim. CPE shall not be liable hereunder for failures of any warranted parts of a CPE engine caused by the use of such an unapproved add-on or modified part.

EMISSION-RELATED PARTS INCLUDE THE FOLLOWING: (using those portions of the list applicable to the engine)

Systems covered by this warranty	Parts Description
Fuel Metering System	Fuel regulator, Carburetor and internal parts
Air Induction System	Air cleaner, Intake manifold
Ignition System	Spark plug and parts, Magneto ignition system
Exhaust System	Exhaust manifold, catalytic converter
Miscellaneous Parts	Tubing, Fittings, Seals, Gaskets, and Clamps
	associated with these listed systems.

TO OBTAIN WARRANTY SERVICE:

You must take your CPE engine or the product on which it is installed, along with your warranty registration card or other proof of original purchase date, at your expense, to any Champion Power Equipment dealer who is authorized by Champion Power Equipment, Inc. to sell and service that CPE product during his normal business hours. Claims for repair or adjustment found to be caused solely by defects in material or workmanship will not be denied because the engine was not properly maintained and used.

If you have any questions regarding your warranty rights and responsibilities, or to obtain warranty service, please write or call Customer Service at Champion Power Equipment, Inc.

Champion Power Equipment, Inc. 10006 Santa Fe Springs Road Santa Fe Springs, CA 90670 USA 1-877-338-0999 Attn: Customer Service tech@championpowerequipment.com