



**MOTOMASTER**

## **NON-SKID ROOF PAD**

**040-1582-2**

- 1) Clean the roof of the vehicle.
- 2) Cut the pad to size when using smaller carriers. A pad that extends out from under the carrier will flap in the wind, creating unwanted noise.
- 3) Place the pad on the vehicle's roof (Fig. 1). Place the carrier on the pad and begin packing.



**Fig. 1**

- 4) After use, wipe the pad clean with mild soap and water, let it dry completely, and store it in a plastic bag.

### **1 Year Manufacturer's Limited Warranty**

Made in China

Imported by Trileaf Distribution Trifeuil Toronto, Canada M4S 2B8



**MOTOMASTER**

## **TAPIS DE PROTECTION ANTIDÉRAPANT POUR TOIT**

**040-1582-2**

- 1) Nettoyez le toit du véhicule.
- 2) Découpez le tapis à la dimension nécessaire lors de l'utilisation de plus petits sacs. Un tapis qui s'étend au-delà des sacs va battre dans le vent, créant un bruit indésirable.
- 3) Placez le tapis sur le toit du véhicule (Fig. 1). Placez les sacs sur le tapis et commencez l'emballage.



**Fig. 1**

- 4) Après utilisation, essuyez le tapis avec de l'eau et du savon doux, laissez-le sécher complètement et conservez-le dans un sac en plastique.

**Garantie limitée du fabricant de 1 an**

Fabriquée en Chine

Importé par Trileaf Distribution Trifeuil, Toronto, Canada M4S 2B8