



ROOF RACK SYSTEM | Fit Guide 2016

- SportRack Roof Rack Systems are the all-in-one, ready-to-go bar system that is easy to install
- Includes bars, hooks, feet, locks that are pre-assembled
- Models available for vehicles with no existing roof rack system or with raised factory side rails
- Adjustment tool included for quick and easy installation
- Up to 150 lbs/68 kg load capacity for most sports equipment or cargo
- Adapter available for installation on 2- and 3-door vehicles
- Special Order: If your vehicle is not listed see Sales Associate for special order options

SportRack customer support: 1-800-238-2388

LIFETIME
WARRANTY

Vehicle make, model and year			REF #	CTC part #	Adapter 040-1091 needed
Acura	CL 2DR	01-03	SR1002	040-1077	Y
	CL 2DR	96-00	SR1002	040-1077	Y
	CSX 4DR	06-11	SR1002	040-1077	
	EL 4DR	01-06	SR1010	040-1096	
	EL 4DR	96-00	SR1010	040-1096	
	ILX 4DR	13-16	SR1010	040-1096	
	Integra 3DR	94-01	SR1003	040-1078	Y
	Integra 3DR	90-93	SR1008	040-1083	Y
	Integra 3DR	86-89	SR1004	040-1079	Y
	Integra 4DR	94-01	SR1008	040-1083	
	Integra 4DR	90-93	SR1008	040-1083	
	Legend 2DR	91-96	SR1002	040-1077	Y
	Legend 4DR	91-96	SR1002	040-1077	
	Legend 4DR	86-90	SR1004	040-1079	
	MDX w/ Factory Rack	07-13	SR1099	040-1571	
	RDX w/ Factory Rack	13-16	SR1099	040-1571	
	RDX w/ Factory Rack	07-12	SR1098	040-1570	
	RL 4DR	96-04	SR1002	040-1077	
	SLX 5DR	96-99	SR1002	040-1077	
	TL 4DR	04-08	SR1002	040-1077	
	TL 4DR	99-03	SR1002	040-1077	
	TL 4DR	95-98	SR1008	040-1083	
	TSX 4DR	09-14	SR1010	040-1096	
	TSX 4DR	04-08	SR1002	040-1077	
	TSX Sport Wagon w/ Factory Rack	11-14	SR1099	040-1571	
	Vigor 4DR	92-95	SR1008	040-1083	
Alfa Romeo	164 4dr	88-98	SR1004	040-1079	
AMC	Eagle 5DR	83-88	SR1001	040-1076	
	SE 3DR	87-93	SR1003	040-1078	Y
	SE 4DR	87-93	SR1003	040-1078	
	SE 5DR	87-93	SR1003	040-1078	
Audi	80 / 90 Series 4DR	88-95	SR1002	040-1077	
	100 / 200 Series 4DR	89-91	SR1002	040-1077	
	100 Wagon w/ Factory Rack	88-92	SR1098	040-1570	
	100 Wagon w/ Factory Rack	93-94	SR1098	040-1570	
	200 Wagon	88-92	SR1002	040-1077	
	200 Wagon w/ Factory Rack	93-94	SR1098	040-1570	
	200 Wagon w/ Factory Rack	88-92	SR1098	040-1570	
	4000 4DR	80-88	SR1001	040-1076	
	5000 Wagon w/ Factory Rack	93-94	SR1098	040-1570	
	A4 4DR	02-08	SR1002	040-1077	
	A4 4DR	95-01	SR1002	040-1077	
	A4 Wagon w/ Factory Rack	02-08	SR1098	040-1570	
	A4 Wagon w/ Factory Rack	97-01	SR1098	040-1570	
	A4 Allroad	13-16	SR1099	040-1571	
	A4 Allroad	99-05	SR1098	040-1570	
	A6 4DR	95-97	SR1002	040-1077	

Vehicle make, model and year			REF #	CTC part #	Adapter 040-1091 needed
Audi	A6 Wagon w/ Factory Rack	99-05	SR1099	040-1571	
	A6 Wagon w/ Factory Rack	95-98	SR1098	040-1570	
	Coupe	81-88	SR1001	040-1076	
	S4 4DR	95-01	SR1002	040-1077	
	S4 4DR	92-94	SR1002	040-1077	
	S6 4DR	95-97	SR1002	040-1077	
	S4 Wagon w/ Factory Rack	02-08	SR1098	040-1570	
Austin	S6 Wagon w/ Factory Rack	95-97	SR1098	040-1570	
	Mini 3DR	59-97	SR1001	040-1076	
BMW	3 Series 2DR	92-98	SR1008	040-1083	
	3 Series 2DR	76-91	SR1001	040-1076	
	3 Series 4DR	06-11	SR1002	040-1077	
	3 Series 4DR	99-05	SR1002	040-1077	
	3 Series 4DR	92-98	SR1002	040-1077	
	3 Series 4DR	76-91	SR1001	040-1076	
	3 Series Wagon w/ Factory Rack	00-10	SR1098	040-1570	
	5 Series 4DR	88-95	SR1002	040-1077	
	5 Series 4DR	76-87	SR1001	040-1076	
	5 Series Wagon w/ Factory Rack	2011	SR1098	040-1570	
	5 Series Wagon w/ Factory Rack	04-10	SR1098	040-1570	
	5 Series Wagon w/ Factory Rack	99-03	SR1099	040-1571	
	5 Series Wagon	92-95	SR1002	040-1077	
	6 Series 2DR	77-90	SR1001	040-1076	
	7 Series 4DR	95-01	SR1002	040-1077	
	7 Series 4DR	86-94	SR1002	040-1077	
	X3 w/ Factory Rack	04-10	SR1098	040-1570	
	X5 w/ Factory Rack	14-16	SR1099	040-1571	
	X5 w/ Factory Rack	07-13	SR1099	040-1571	
	X5 w/ Factory Rack	00-06	SR1099	040-1571	
Buick	Allure 4DR	05-08	SR1002	040-1077	
	Century 4DR	97-05	SR1002	040-1077	
	Century 4DR	82-96	SR1002	040-1077	
	Century Wagon	84-96	SR1002	040-1077	
	Century Wagon w/ Factory Rack	84-96	SR1098	040-1570	
	Electra 4DR	85-90	SR1002	040-1077	
	Electra Wagon	77-90	SR1001	040-1076	
	Electra Wagon w/ Raised Rails	77-90	SR1098	040-1570	
	Lacrosse 4DR	05-08	SR1002	040-1077	
	Le Sabre 2DR	86-91	SR1002	040-1077	
	Le Sabre 4DR	92-99	SR1002	040-1077	
	Le Sabre Estate Wagon	77-89	SR1001	040-1076	
	Park Avenue 4DR	91-96	SR1002	040-1077	
	Regal 4DR	97-02	SR1002	040-1077	
	Regal 4DR	88-96	SR1005	040-1080	
	Regal 4DR	78-87	SR1001	040-1076	
	Riviera 2DR	95-99	SR1003	040-1078	
	Riviera 2DR	86-94	SR1005	040-1080	

Vehicle make, model and year			REF #	CTC part #	Adapter 040-1091 needed
Buick	Skyhawk 4DR	82-89	SR1001	040-1076	
	Skyhawk Wagon	82-89	SR1001	040-1076	
	Skyhawk Wagon w/ Factory Rack	82-89	SR1098	040-1570	
	Terraza w/ Raised Rails	05-07	SR1098	040-1570	
Cadillac	Catera	97-01	SR1001	040-1076	
	Eldorado 2DR	92-03	SR1002	040-1077	Y
	Eldorado 2DR	86-91	SR1005	040-1080	
	Seville 4DR	92-04	SR1005	040-1080	
	Seville 4DR	86-91	SR1005	040-1080	
	Seville SLS 4DR	92-04	SR1005	040-1080	
	Seville STS 4DR	92-04	SR1005	040-1080	
	SRX w/ Factory Rack	10-16	SR1099	040-1571	
	SRX w/ Factory Rack	04-09	SR1098	040-1570	
	Astro Van w/ Factory Rack	85-05	SR1099	040-1571	
Chevrolet	Avalanche w/ Raised Rails	07-13	SR1099	040-1571	
	Avalanche w/ Raised Rails	02-06	SR1099	040-1571	
	Aveo 4DR	04-11	SR1002	040-1077	
	Aveo 5DR	04-11	SR1002	040-1077	
	Blazer 3DR	82-94	SR1003	040-1078	
	Blazer 3DR w/ Factory Rack	82-94	SR1098	040-1570	
	Blazer 5DR w/ Factory Rack	95-05	SR1098	040-1570	
	Blazer 5DR	91-94	SR1002	040-1077	
	Blazer 5DR w/ Factory Rack	91-94	SR1098	040-1570	
	Blazer C/K 3DR w/ Factory Rack	92-94	SR1099	040-1571	
	Blazer C/K 5DR w/ Factory Rack	92-94	SR1099	040-1571	
	Camaro	93-02	SR1002	040-1077	
	Camaro T-Top	93-02	SR1002	040-1077	
	Caprice 4DR	77-90	SR1001	040-1076	
	Caprice 4DR w/ Raised Rails	77-90	SR1098	040-1570	
	Caprice Wagon	77-90	SR1001	040-1076	
	Captiva w/ Factory Rack	10-16	SR1098	040-1570	
	Cavalier 2DR	95-05	SR1005	040-1080	Y
	Cavalier 2DR	88-94	SR1001	040-1076	
	Cavalier 4DR	95-05	SR1005	040-1080	
	Cavalier 4DR	82-94	SR1001	040-1076	
	Cavalier Wagon	82-94	SR1001	040-1076	
	Cavalier Wagon w/ Factory Rack	82-94	SR1098	040-1570	
	Cavalier Z24	82-94	SR1001	040-1076	
	Celebrity Wagon w/ Factory Rack	84-89	SR1098	040-1570	
	Colorado	04-12	SR1005	040-1080	
	Corsica 4DR	88-96	SR1005	040-1080	
	Cruze 4DR	11-15	SR1010	040-1096	
	Cruze Eco 4DR	11-15	SR1010	040-1096	
	Impala 4DR	06-13	SR1010	040-1096	
	Impala 4DR	00-05	SR1002	040-1077	
	IROC-Z	93-02	SR1002	040-1077	
	Iroc-Z T-Top	93-02	SR1002	040-1077	

Vehicle make, model and year			REF #	CTC part #	Adapter 040-1091 needed
Chevrolet	Lumina 4DR	95-99	SR1004	040-1079	
	Lumina 4DR	89-94	SR1005	040-1080	
	Malibu 4DR	08-12	SR1002	040-1077	
	Malibu 4DR	04-07	SR1002	040-1077	
	Malibu 4DR	97-03	SR1002	040-1077	
	Malibu Maxx 5DR	04-07	SR1002	040-1077	
	Metro 3DR	98-00	SR1003	040-1078	Y
	Metro 4DR	98-00	SR1003	040-1078	
	Monte Carlo 2DR	00-05	SR1002	040-1077	
	Monte Carlo 2DR	95-99	SR1004	040-1079	Y
	Nova	85-88	SR1003	040-1078	
	Optra 4DR	04-06	SR1002	040-1077	
	Optra 5 5DR	04-08	SR1002	040-1077	
	Optra Wagon	04-08	SR1002	040-1077	
	S-10 King Cab	82-93	SR1003	040-1078	Y
	Sprint 3DR	89-94	SR1004	040-1079	Y
	Sprint 3DR	84-88	SR1003	040-1078	Y
	Sprint 4DR	89-94	SR1004	040-1079	
	Sprint 5DR	89-94	SR1004	040-1079	
	Sprint 5DR	84-88	SR1003	040-1078	
	S-10 Blazer 2DR w/ Raised Rails	85-90	SR1098	040-1570	
	S-10 Blazer 2DR w/ Raised Rails	83-84	SR1098	040-1570	
	Suburban w/ Raised Rails	07-14	SR1099	040-1571	
	Suburban w/ Factory Rack	00-06	SR1099	040-1571	
	Tahoe 4DR w/ Factory Rack	07-14	SR1099	040-1571	
	Tahoe 4DR w/ Factory Rack	00-06	SR1099	040-1571	
	Tracker 3DR	89-98	SR1002	040-1077	
	Tracker 4DR w/ Factory Rack	99-04	SR1098	040-1570	
	Tracker 4DR w/ Raised Rails	96-98	SR1098	040-1570	
	Trax w/ Raised Rails	13-16	SR1098	040-1570	
	Uplander w/ Raised Rails	05-08	SR1098	040-1570	
	Venture w/ Factory Rack	97-05	SR1098	040-1570	
	Z28	93-02	SR1002	040-1077	
	Z28 T-Top	93-02	SR1002	040-1077	
Chrysler	300 4DR	05-10	SR1002	040-1077	
	300C 4DR	05-07	SR1002	040-1077	
	300M 4DR	99-04	SR1005	040-1080	
	Caravan	88-95	SR1001	040-1076	
	Aspen w/ Raised Rails	07-09	SR1099	040-1571	
	Town & Country w/ Factory Rack	08-10	SR1099	040-1571	
	Cirrus 4DR	95-00	SR1004	040-1079	
	Concorde 4DR	93-97	SR1002	040-1077	
	Daytona	84-93	SR1004	040-1079	
	Daytona T-Top	84-93	SR1004	040-1079	
	Dynasty 4DR	88-93	SR1004	040-1079	
	Imperial 4DR	89-93	SR1005	040-1080	
	Intrepid 4DR	98-05	SR1005	040-1080	

Vehicle make, model and year			REF #	CTC part #	Adapter 040-1091 needed
Chrysler	Intrepid 4DR	93-97	SR1002	040-1077	
	Le Baron 2DR	87-95	SR1004	040-1079	
	Le Baron 2DR	82-86	SR1001	040-1076	
	Le Baron 4DR	90-94	SR1004	040-1079	
	Le Baron 4DR	82-88	SR1001	040-1076	
	Le Baron GTS	85-89	SR1004	040-1079	
	LHS 4DR	94-97	SR1002	040-1077	
	Neon 4DR	00-04	SR1004	040-1079	
	New Yorker 4DR	94-97	SR1002	040-1077	
	New Yorker 4DR	88-93	SR1004	040-1079	
	New Yorker Fifth Avenue 4DR	90-93	SR1004	040-1079	
	PT Cruiser	01-10	SR1005	040-1080	
	Reliant 4DR	81-89	SR1001	040-1076	
	Sebring 2DR	95-00	SR1008	040-1083	Y
	Sebring 4DR	01-06	SR1004	040-1079	Y
	Town & Country w/ Factory Rack	96-00	SR1098	040-1570	
	Town & Country	96-01	SR1004	040-1079	
	Town & Country	84-95	SR1001	040-1076	
Daewoo	Lanos 3DR	98-02	SR1002	040-1077	Y
	Lanos 4DR	98-02	SR1002	040-1077	
	Leganza 4DR	99-00	SR1002	040-1077	
	Nubira 4DR	99-00	SR1002	040-1077	
Dodge	2000 GTX 4DR	89-93	SR1002	040-1077	
	Aries 2DR	81-89	SR1001	040-1076	
	Aries 4DR	81-89	SR1001	040-1076	
	Aries Wagon	81-89	SR1001	040-1076	
	Aries Wagon w/ Factory Rack	81-89	SR1098	040-1570	
	Avenger 2DR	95-00	SR1008	040-1083	Y
	Caravan	96-01	SR1004	040-1079	
	Caravan	84-95	SR1001	040-1076	
	Caravan / Grand Caravan w/ Factory Rack	96-00	SR1098	040-1570	
	Caravan / Grand Caravan	96-01	SR1004	040-1079	
	Caravan / Grand Caravan	84-95	SR1001	040-1076	
	Charger	05-10	SR1002	040-1077	
	Charger	83-88	SR1001	040-1076	
	Colt 2DR	93-96	SR1003	040-1078	Y
	Colt 3DR	79-88	SR1005	040-1080	Y
	Colt 4DR	93-96	SR1003	040-1078	
	Colt 4DR	79-88	SR1005	040-1080	
	Colt 100 3DR	89-92	SR1005	040-1080	Y
	Colt 100 4DR	89-92	SR1005	040-1080	
	Colt 200 3DR	89-92	SR1004	040-1079	Y
	Colt Minivan	92-96	SR1001	040-1076	
	Colt Minivan	84-91	SR1001	040-1076	
	Colt Vista 5DR	84-91	SR1001	040-1076	
	Colt Vista 5DR w/ Factory Rack	84-91	SR1098	040-1570	
	Colt Vista Wagon	88-91	SR1001	040-1076	

Vehicle make, model and year			REF #	CTC part #	Adapter 040-1091 needed
Dodge	Dakota	87-96	SR1003	040-1078	
	Daytona 3DR	84-93	SR1004	040-1079	
	Durango w/ Factory Rack	04-09	SR1099	040-1571	
	Dynasty	88-93	SR1004	040-1079	
	Grand Caravan	84-95	SR1001	040-1076	
	Intrepid 4DR	98-02	SR1005	040-1080	
	Intrepid 4DR	93-97	SR1002	040-1077	
	Journey w/ Factory Rack	13-16	SR1099	040-1571	
	Magnum w/ Raised Rails	05-08	SR1098	040-1570	
	Journey w/ Factory Rack	08-12	SR1099	040-1571	
	Lancer 5DR	85-89	SR1004	040-1079	
	Magnum 4DR	05-07	SR1002	040-1077	
	Neon 2DR	94-99	SR1008	040-1083	Y
	Neon 4DR	00-04	SR1004	040-1079	
	Neon 4DR	94-99	SR1008	040-1083	
	Omni	78-90	SR1001	040-1076	
	Raider	87-90	SR1001	040-1076	
	Ram 1500	72-93	SR1001	040-1076	
	Ram 2500	72-93	SR1001	040-1076	
	Ram 3500	72-93	SR1001	040-1076	
	Ram 50 Van	76-93	SR1001	040-1076	
	Shadow 3DR	87-94	SR1004	040-1079	Y
	Shadow 5DR	87-94	SR1004	040-1079	
	Spirit 4DR	88-95	SR1004	040-1079	
	Sport Ram	79-93	SR1001	040-1076	
	Stealth 3DR	91-96	SR1008	040-1083	Y
	Stratus 4DR	95-99	SR1004	040-1079	
	SX 2.0 4DR	03-05	SR1004	040-1079	
Eagle	2000 GTX 4DR	89-93	SR1002	040-1077	
	Alliance 4DR	83-88	SR1001	040-1076	
	Summit 2DR	93-96	SR1003	040-1078	Y
	Summit 3DR	89-92	SR1004	040-1079	Y
	Summit 4DR	93-96	SR1003	040-1078	
	Summit Minivan	92-96	SR1001	040-1076	
	Summit Minivan w/ Factory Rack	92-96	SR1098	040-1570	
	Talon 3DR	90-94	SR1002	040-1077	
	Vision 4DR	93-97	SR1002	040-1077	
	Vista 3DR	89-92	SR1005	040-1080	
	Vista 3DR	89-92	SR1005	040-1080	Y
	Vista 4DR	89-92	SR1005	040-1080	
	Vista Minivan	84-91	SR1001	040-1076	
	Vista Minivan w/ Factory Rack	84-91	SR1098	040-1570	
Ford	Aspire 3DR	94-97	SR1003	040-1078	Y
	Aspire 5DR	94-97	SR1003	040-1078	
	Bronco II	83-90	SR1001	040-1076	
	Edge / Edge Sport	11-14	SR1010	040-1096	

Vehicle make, model and year			REF #	CTC part #	Adapter 040-1091 needed
Ford	Edge / Edge Sport	07-10	SR1010	040-1096	
	Edge / Edge Sport w/ Factory Rack	11-14	SR1099	040-1571	
	Edge / Edge Sport w/ Factory Rack	07-10	SR1099	040-1571	
	Escape w/ Factory Rack	13-16	SR1099	040-1571	
	Escape (Glass Roof) w/ Factory Rack	13-16	SR1099	040-1571	
	Escort 3DR	91-96	SR1003	040-1078	
	Escort 3DR	81-90	SR1001	040-1076	
	Escort 4DR	97-99	SR1003	040-1078	
	Escort 4DR	91-96	SR1003	040-1078	
	Escort 4DR	81-90	SR1001	040-1076	
	Escort 5DR	91-96	SR1003	040-1078	
	Escort 5DR	81-90	SR1001	040-1076	
	Escort Wagon	97-99	SR1002	040-1077	
	Escort Wagon	91-96	SR1002	040-1077	
	Escort Wagon	81-90	SR1001	040-1076	
	EXP	82-88	SR1001	040-1076	
	Festiva 3DR	88-93	SR1003	040-1078	Y
	Fiesta 4DR	11-16	SR1010	040-1096	
	Fiesta 5DR	11-16	SR1010	040-1096	
	Fiesta 5DR	78-86	SR1001	040-1076	
	Five Hundred 4DR	05-07	SR1002	040-1077	
	Focus 3DR	00-07	SR1002	040-1077	Y
	Focus 4DR	12-16	SR1010	040-1096	
	Focus 4DR	08-11	SR1002	040-1077	
	Focus 4DR	00-07	SR1002	040-1077	
	Focus 5DR	12-16	SR1010	040-1096	
	Focus 5DR	08-11	SR1002	040-1077	
	Focus 5DR	00-07	SR1002	040-1077	
	Focus Wagon w/ Raised Rails	2000	SR1098	040-1570	
	Fusion 4DR	13-16	SR1010	040-1096	
	Fusion 4DR	06-12	SR1010	040-1096	
	Mustang 2DR	79-93	SR1003	040-1078	Y
	Mustang 3DR	79-93	SR1003	040-1078	Y
	Probe 3DR	93-98	SR1008	040-1083	Y
	Ranger	83-92	SR1001	040-1076	
	Taurus 4DR	08-09	SR1010	040-1096	
	Taurus 4DR	96-99	SR1002	040-1077	
	Thunderbird	89-97	SR1005	040-1080	Y
	Freestar w/ Raised Rail	04-07	SR1098	040-1570	
	Freestyle w/ Raised Rails	05-07	SR1099	040-1571	
	Taurus X w/ Raised Rails	08-09	SR1098	040-1570	
	Windstar w/ Raised Rails	98-99	SR1099	040-1571	
	Windstar w/ Factory Rack	95-97	SR1099	040-1571	
	ZX3 3DR	00-07	SR1002	040-1077	Y
	ZX5 5DR	00-07	SR1002	040-1077	
Geo	Metro 3DR	95-00	SR1003	040-1078	Y
	Metro 3DR	89-94	SR1004	040-1079	Y

Vehicle make, model and year			REF #	CTC part #	Adapter 040-1091 needed
Geo	Metro 4DR	89-94	SR1004	040-1079	
	Metro 4DR	95-00	SR1003	040-1078	
	Metro 5DR	89-94	SR1004	040-1079	
	Prizm 4DR	88-92	SR1001	040-1076	
	Tracker 3DR	89-97	SR1002	040-1077	
GMC	Canyon	04-12	SR1005	040-1080	
	Envoy w/ Factory Rack	98-00	SR1099	040-1571	
	Jimmy 3DR	82-94	SR1003	040-1078	
	Jimmy 2DR w/ Raised Rails	95-01	SR1098	040-1570	
	Jimmy 5DR	91-94	SR1002	040-1077	
	Jimmy 4DR w/ Factory Rack	95-01	SR1098	040-1570	
	S-15 King Cab	82-93	SR1003	040-1078	Y
	Safari w/ Factory Rack	85-03	SR1099	040-1571	
	Sonoma King Cab	82-93	SR1003	040-1078	Y
	Tracker 3DR	89-98	SR1002	040-1077	
	Yukon 4DR w/ Raised Rails (Except Denali)	07-14	SR1099	040-1571	
	Yukon 4DR w/ Raised Rails (Except Denali)	00-06	SR1099	040-1571	
Honda	Accord 2DR	03-07	SR1002	040-1077	Y
	Accord 2DR	98-02	SR1002	040-1077	Y
	Accord 2DR	94-98	SR1002	040-1077	Y
	Accord 2DR	90-93	SR1002	040-1077	Y
	Accord 2DR	86-89	SR1004	040-1079	Y
	Accord 3DR	86-89	SR1004	040-1079	Y
	Accord 4DR	13-16	SR1010	040-1096	
	Accord 4DR	08-12	SR1010	040-1096	
	Accord 4DR	03-07	SR1002	040-1077	
	Accord 4DR	98-02	SR1002	040-1077	
	Accord 4DR	94-97	SR1002	040-1077	
	Accord 4DR	90-93	SR1002	040-1077	
	Accord 4DR	86-89	SR1004	040-1079	
	Accord Wagon	94-97	SR1002	040-1077	
	Accord Wagon	91-93	SR1002	040-1077	
	Accord Wagon w/ Factory Rack	94-95	SR1098	040-1570	
	Accord Wagon w/ Factory Rack	91-93	SR1098	040-1570	
	Civic 2DR	96-00	SR1003	040-1078	Y
	Civic 2DR	92-95	SR1003	040-1078	Y
	Civic 3DR	96-00	SR1003	040-1078	Y
	Civic 3DR	92-95	SR1003	040-1078	Y
	Civic 4DR	13-15	SR1010	040-1096	
	Civic 4DR	06-12	SR1002	040-1077	
	Civic 4DR	96-00	SR1010	040-1096	
	Civic 4DR	92-95	SR1002	040-1077	
	Civic Wagon w/ Factory Rack	88-91	SR1098	040-1570	
	Crossroad w/ Factory Rack	93-98	SR1099	040-1571	
	Crosstour	10-15	SR1002	040-1077	
	CRV	97-01	SR1003	040-1078	
	CRV w/ Factory Rack	99-01	SR1098	040-1570	
	CRV w/ Factory Rack	97-98	SR1098	040-1570	

Vehicle make, model and year			REF #	CTC part #	Adapter 040-1091 needed
Honda	CRX 3DR	84-87	SR1008	040-1083	Y
	Fit 5DR	09-14	SR1002	040-1077	
	Fit 5DR	07-08	SR1002	040-1077	
	Fit Sport 5DR	09-14	SR1002	040-1077	
	Fit Sport 5DR	07-08	SR1002	040-1077	
	Insight 5DR	10-14	SR1002	040-1077	
	Odyssey	95-98	SR1003	040-1078	
	Odyssey w/ Factory Rack	11-16	SR1099	040-1571	
	Odyssey w/ Factory Rack	05-10	SR1099	040-1571	
	Odyssey w/ Factory Rack	01-04	SR1098	040-1570	
	Odyssey w/ Factory Rack	95-00	SR1098	040-1570	
	Passport	90-97	SR1004	040-1079	
	Passport w/ Factory Rack	98-00	SR1098	040-1570	
	Pilot w/ Factory Rack	09-15	SR1099	040-1571	
	Pilot w/ Factory Rack	02-08	SR1099	040-1571	
	Prelude 2DR	88-91	SR1005	040-1080	Y
Hyundai	Accent 3DR	00-06	SR1003	040-1078	Y
	Accent 3DR	95-99	SR1003	040-1078	Y
	Accent 4DR	12-16	SR1010	040-1096	
	Accent 4DR	06-11	SR1002	040-1077	
	Accent 4DR	00-05	SR1003	040-1078	
	Accent 4DR	95-99	SR1003	040-1078	
	Elantra 4DR	11-16	SR1010	040-1096	
	Elantra 4DR	07-10	SR1002	040-1077	
	Elantra 4DR	01-06	SR1002	040-1077	Y
	Elantra 4DR	96-00	SR1005	040-1080	
	Elantra 4DR	92-95	SR1004	040-1079	
	Elantra Touring Wagon	09-12	SR1002	040-1077	
	Elantra Touring Wagon w/ Factory Rack	09-12	SR1098	040-1570	
	Entourage w/ Factory Rack	07-10	SR1098	040-1570	
	Excel 3DR	86-89	SR1004	040-1079	Y
	Excel 4DR	90-94	SR1004	040-1079	
	Excel 4DR	86-89	SR1005	040-1080	
	Excel 5DR	86-89	SR1004	040-1079	
	Genesis 4DR	09-14	SR1010	040-1096	
	Pony 5DR	77-87	SR1001	040-1076	
	Sonata 4DR	11-14	SR1002	040-1077	
	Sonata 4DR	06-10	SR1002	040-1077	
	Sonata 4DR	94-98	SR1003	040-1078	
	Sonata 4DR	89-93	SR1004	040-1079	
	Stellar 4DR	78-88	SR1001	040-1076	
	Tucson w/ Factory Rack	10-15	SR1099	040-1571	
	Tucson w/ Factory Rack	05-09	SR1098	040-1570	
	Veracruz w/ Raised Rails	07-12	SR1098	040-1570	
Infiniti	EX35 w/ Factory Rack	08-13	SR1098	040-1570	
	EX37 w/ Factory Rack	2013	SR1098	040-1570	
	FX35 w/ Factory Rack	03-13	SR1098	040-1570	
	FX37 w/ Factory Rack	2013	SR1098	040-1570	

Vehicle make, model and year			REF #	CTC part #	Adapter 040-1091 needed
Infiniti	FX45 w/ Factory Rack	03-08	SR1098	040-1570	
	FX50 w/ Factory Rack	09-13	SR1098	040-1570	
	G20 4DR	99-01	SR1005	040-1080	
	G20 4DR	91-96	SR1004	040-1079	
	I30 4DR	96-99	SR1005	040-1080	
	J30 4DR	92-97	SR1003	040-1078	
	Q45 4DR	94-96	SR1002	040-1077	
	Q45 4DR	91-93	SR1002	040-1077	
	QX4	97-03	SR1003	040-1078	
	QX56 w/ Factory Rack	08-10	SR1099	040-1571	
Isuzu	QX70 w/ Factory Rack	14-16	SR1098	040-1570	
	Hombre	96-97	SR1004	040-1079	
	Oasis 5DR	96-98	SR1003	040-1078	
	Pickup	81-95	SR1004	040-1079	
	Rodeo 5DR	90-97	SR1004	040-1079	
	Rodeo 5DR w/ Factory Rack	98-03	SR1098	040-1570	
	Stylus 4DR	92-95	SR1004	040-1079	
	Trooper	92-02	SR1002	040-1077	
Jaguar	Trooper	81-91	SR1001	040-1076	
	Daimler 4DR	88-98	SR1001	040-1076	
	Executif 4DR	88-98	SR1001	040-1076	
	Sovereign 4DR	88-98	SR1001	040-1076	
	Vanden Plas 4DR	88-01	SR1001	040-1076	
	VDP Vanden Plas	82-92	SR1001	040-1076	
	XJ6 4DR	88-98	SR1001	040-1076	
	XJ8 4DR	97-11	SR1001	040-1076	
	XJ12 4DR	88-98	SR1001	040-1076	
	XJR 4DR	95-01	SR1001	040-1076	
Jeep	XJS 2DR	75-96	SR1001	040-1076	
	Cherokee	83-01	SR1001	040-1076	
	Cherokee w/ Factory Rack	83-01	SR1001	040-1076	
	CJ-7	79-95	SR1001	040-1076	
	Comanche	85-94	SR1001	040-1076	
	Cherokee w/ Raised Rails	14-16	SR1098	040-1570	
	Grand Cherokee w/ Factory Rack	05-10	SR1099	040-1571	
	Grand Cherokee w/ Factory Rack	99-04	SR1098	040-1570	
	Grand Wagoneer	84-92	SR1001	040-1076	
	Liberty w/ Factory Rack	02-12	SR1099	040-1571	
	Wagoneer 3DR	83-92	SR1001	040-1076	
	Wagoneer 5DR	83-92	SR1001	040-1076	
	Wrangler (Hard Top)	96-06	SR1001	040-1076	
	Wrangler Unlimited (Hard Top)	96-06	SR1001	040-1076	
Kia	Borrego w/ Factory Rack	09-12	SR1099	040-1571	
	Rio 4DR	01-05	SR1002	040-1077	Y
	Rondo w/ Factory Rack	09-13	SR1098	040-1570	
	Sedona w/ Factory Rack	11-13	SR1098	040-1570	
	Sedona w/ Factory Rack	06-10	SR1098	040-1570	
	Sedona w/ Factory Rack	02-05	SR1098	040-1570	

Vehicle make, model and year			REF #	CTC part #	Adapter 040-1091 needed
Kia	Sephia 4DR	00-01	SR1002	040-1077	
	Sephia 4DR	94-97	SR1002	040-1077	
	Spectra 4DR	02-05	SR1002	040-1077	
	Spectra 5DR	02-03	SR1002	040-1077	
	Sorento w/ Factory Rack	11-15	SR1098	040-1570	
	Sorento w/ Factory Rack	03-09	SR1098	040-1570	
	Sportage w/ Factory Rack	2010	SR1098	040-1570	
	Sportage w/ Factory Rack	05-09	SR1098	040-1570	
Lada	Niva 3DR	76-99	SR1001	040-1076	
	Sagana 4DR	91-99	SR1001	040-1076	
	Samara 3DR	84-99	SR1001	040-1076	
	Samara 5DR	84-99	SR1001	040-1076	
	Signet 4DR	60-94	SR1001	040-1076	
Land Rover	Discovery w/ Factory Rack	94-03	SR1098	040-1570	
	Evoque 5DR w/ Factory Rack	12-16	SR1099	040-1571	
	Freelander w/ Factory Rack	02-05	SR1098	040-1570	
	LR2 w/ Factory Rack	07-14	SR1098	040-1570	
	Range Rover w/ Factory Rack	98-02	SR1099	040-1571	
Lexus	ES 300 4DR	92-96	SR1008	040-1083	
	GS 300 4DR	93-97	SR1005	040-1080	
	GX 470 w/ Factory Rack	03-09	SR1098	040-1570	
	IS300 2DR	01-03	SR1002	040-1077	
	LS 400 4DR	90-94	SR1005	040-1080	
	LX 450 5DR	96-98	SR1001	040-1076	
	RX 330 w/ Factory Rack	04-07	SR1098	040-1570	
	RX 350 w/ Factory Rack	04-07	SR1098	040-1570	
	RX 400h w/ Factory Rack	04-07	SR1098	040-1570	
	SC 300 2DR	92-99	SR1005	040-1080	Y
Lincoln	SC 400 2DR	92-99	SR1005	040-1080	Y
	Aviator w/ Factory Rack	03-05	SR1098	040-1570	
	Mark VIII 2DR	93-98	SR1005	040-1080	Y
	MKX	11-15	SR1010	040-1096	
	MKX	07-10	SR1010	040-1096	
	MKX w/ Factory Rack	11-15	SR1098	040-1570	
	MKX w/ Factory Rack	07-10	SR1098	040-1570	
	MKZ 4DR	06-12	SR1010	040-1096	
Mazda	2 5DR	11-15	SR1010	040-1096	
	3 4DR	10-13	SR1010	040-1096	
	3 4DR	04-09	SR1010	040-1096	
	3 5DR	10-13	SR1010	040-1096	
	3 5DR	04-09	SR1010	040-1096	
	323 3DR	95-97	SR1002	040-1077	
	323 3DR	90-95	SR1002	040-1077	
	323 3DR	86-89	SR1003	040-1078	
	323 4DR	86-89	SR1001	040-1076	
	323 5DR	86-89	SR1003	040-1078	
	323 Wagon	86-89	SR1001	040-1076	
	6 4DR	09-13	SR1010	040-1096	

Vehicle make, model and year			REF #	CTC part #	Adapter 040-1091 needed
Mazda	6 4DR	04-08	SR1010	040-1096	
	6 5DR	04-08	SR1010	040-1096	
	6 Wagon	04-08	SR1010	040-1096	
	6 Wagon w/ Factory Rack	04-08	SR1098	040-1570	
	626 4DR	93-97	SR1002	040-1077	
	626 4DR	88-92	SR1002	040-1077	
	626 4DR	76-89	SR1001	040-1076	
	626 5DR	88-92	SR1002	040-1077	
	626 Cronos 4DR	93-97	SR1002	040-1077	
	929 4DR	92-94	SR1008	040-1083	
	929 4DR	88-91	SR1004	040-1079	
	929 Serenia 4DR	92-94	SR1008	040-1083	
	B2200	85-93	SR1001	040-1076	
	B2200 Cab Plus	85-93	SR1001	040-1076	
	B2600	85-93	SR1001	040-1076	
	B2600 Cab Plus	85-93	SR1001	040-1076	
	CX-5 w/ Factory Rack	13-16	SR1098	040-1570	
	CX-9 w/ Factory Rack	07-16	SR1099	040-1571	
	GLC 3DR	86-89	SR1003	040-1078	
	Miata Hard Top	90-98	SR1008	040-1083	
	Millenia 4DR	95-02	SR1002	040-1077	
	MX-3 Precidia 3DR	92-96	SR1003	040-1078	
	MX-6 2DR	88-92	SR1008	040-1083	Y
	MX-6 Mystere 2DR	93-97	SR1008	040-1083	Y
	Pickup	79-93	SR1001	040-1076	
	Protégé 4DR	99-03	SR1002	040-1077	
	Protégé 4DR	95-98	SR1002	040-1077	
	Protégé5 5DR	02-03	SR1002	040-1077	
	Tribute w/ Factory Rack	08-11	SR1098	040-1570	
	Tribute w/ Factory Rack	01-07	SR1098	040-1570	
Mercedes-Benz	300 Series Wagon w/ Raised Rails	86-97	SR1098	040-1570	
	450 Series	79-89	SR1001	040-1076	
	C Class 4DR	01-03	SR1002	040-1077	Y
	C Class 4DR	94-00	SR1002	040-1077	
	C Class Wagon w/ Factory Rack	01-12	SR1098	040-1570	
	E Class 4DR	96-02	SR1002	040-1077	
	E Class 4DR	85-95	SR1002	040-1077	
	E Class Wagon	94-96	SR1002	040-1077	
	E Class Wagon w/ Factory Rack	11-16	SR1098	040-1570	
	E Class Wagon w/ Factory Rack	04-10	SR1098	040-1570	
	E Class Wagon w/ Factory Rack	98-03	SR1098	040-1570	
	E Class Wagon w/ Factory Rack	94-96	SR1098	040-1570	
	GL Class w/ Factory Rack	06-16	SR1098	040-1570	
	GLE Class w/ Factory Rack	2016	SR1098	040-1570	
	GLK Class w/ Factory Rack	09-15	SR1098	040-1570	
	M Class w/ Factory Rack	12-15	SR1098	040-1570	
	M Class w/ Factory Rack	06-11	SR1098	040-1570	
	M Class w/ Factory Rack	98-05	SR1099	040-1571	

Vehicle make, model and year			REF #	CTC part #	Adapter 040-1091 needed
Mercedes-Benz	S Class 4DR	92-98	SR1002	040-1077	
	Cougar 2DR	98-02	SR1008	040-1083	Y
	Cougar 2DR	89-97	SR1005	040-1080	Y
	Lynx 3DR	81-90	SR1001	040-1076	
	Lynx 5DR	81-90	SR1001	040-1076	
	Lynx Wagon	81-90	SR1001	040-1076	
	Mariner w/ Factory Rack	05-10	SR1098	040-1570	
	Mountaineer w/ Factory Rack	02-04	SR1098	040-1570	
	Milan 4DR	06-10	SR1010	040-1096	
	Sable 4DR	08-09	SR1010	040-1096	
Mercury	Sable 4DR	00-05	SR1002	040-1077	
	Sable 4DR	96-99	SR1002	040-1077	
	Tracer 3DR	91-96	SR1003	040-1078	
	Tracer 3DR	86-89	SR1003	040-1078	
	Tracer 4DR	97-99	SR1003	040-1078	
	Tracer 4DR	91-96	SR1003	040-1078	
	Tracer 4DR	86-89	SR1003	040-1078	
	Tracer 5DR	91-96	SR1003	040-1078	
	Tracer 5DR	86-89	SR1003	040-1078	
	Tracer Wagon	97-99	SR1002	040-1077	
	Tracer Wagon	91-96	SR1002	040-1077	
	3000 GT	91-97	SR1008	040-1083	Y
	Colt 2DR	93-96	SR1003	040-1078	Y
	Colt 3DR	89-92	SR1004	040-1079	Y
	Colt 3DR	79-88	SR1005	040-1080	Y
	Colt 4DR	93-96	SR1003	040-1078	
	Colt 4DR	79-88	SR1005	040-1080	
	Eclipse	90-94	SR1002	040-1077	
	Expo	92-96	SR1001	040-1076	
	Expo w/ Factory Rack	92-96	SR1098	040-1570	
	Galant 4DR	02-03	SR1002	040-1077	Y
	Galant 4DR	98-99	SR1002	040-1077	
	Galant 4DR	94-97	SR1002	040-1077	
	Galant 4DR	88-93	SR1002	040-1077	
	Lancer 4DR	03-07	SR1002	040-1077	
	Lancer 4DR	02-03	SR1002	040-1077	
	Lancer Sportback w/ Factory Rack	2004	SR1099	040-1571	
	Mirage 2DR	97-99	SR1002	040-1077	Y
	Mirage 2DR	93-96	SR1003	040-1078	Y
	Mirage 3DR	89-92	SR1004	040-1079	
Mitsubishi	Mirage 3DR	79-88	SR1005	040-1080	Y
	Mirage 4DR	97-99	SR1002	040-1077	
	Mirage 4DR	93-96	SR1003	040-1078	
	Mirage 4DR	89-92	SR1004	040-1079	Y
	Mirage 4DR	79-88	SR1005	040-1080	
	Montero	83-90	SR1001	040-1076	
	Montero Sport w/ Factory Rack	01-06	SR1099	040-1571	
	Montero Sport w/ Factory Rack	89-00	SR1098	040-1570	

Vehicle make, model and year			REF #	CTC part #	Adapter 040-1091 needed
Mitsubishi	Outlander w/ Factory Rack	11-13	SR1098	040-1570	
	Outlander w/ Factory Rack	07-10	SR1098	040-1570	
	Pickup	83-96	SR1001	040-1076	
	Space Runner	92-99	SR1001	040-1076	
	Space Wagon	92-97	SR1001	040-1076	
	200 SX 2DR	95-98	SR1004	040-1079	
	200 SX 3DR	84-88	SR1005	040-1080	
	240 SX 2DR	95-98	SR1008	040-1083	Y
	300 ZX T-Top	84-89	SR1003	040-1078	
	Altima 4DR	13-16	SR1010	040-1096	
	Altima 4DR	98-01	SR1005	040-1080	
	Altima 4DR	93-97	SR1005	040-1080	
	Axxess 5DR	89-95	SR1004	040-1079	
	Costaud	87-97	SR1004	040-1079	
	Costaud King Cab	87-97	SR1004	040-1079	Y
	Frontier 2DR Standard Cab	98-04	SR1005	040-1080	Y
	Frontier 4DR Crew Cab	00-04	SR1004	040-1079	
	Juke 5DR	11-16	SR1010	040-1096	
	Maxima 4DR	09-12	SR1002	040-1077	
	Maxima 4DR	95-99	SR1005	040-1080	
Nissan	Maxima 4DR	89-94	SR1004	040-1079	
	Maxima 4DR	84-88	SR1001	040-1076	
	Multi 5DR	82-88	SR1004	040-1079	
	Murano w/ Factory Rack	03-14	SR1098	040-1570	
	NX 1600	91-93	SR1003	040-1078	
	NX 1600 T-Top	91-93	SR1008	040-1083	Y
	NX 2000	91-93	SR1003	040-1078	
	NX 2000 T-Top	91-93	SR1008	040-1083	Y
	Pathfinder 5DR	90-96	SR1004	040-1079	
	Pathfinder 5DR	13-16	SR1098	040-1570	
	Pathfinder 5DR	96-04	SR1003	040-1078	
	Pickup	87-97	SR1004	040-1079	
	Pickup King Cab	87-97	SR1004	040-1079	Y
	Pulsar 2DR	83-86	SR1003	040-1078	
	Quest w/ Factory Rack	12-16	SR1099	040-1571	
	Quest w/ Factory Rack	04-11	SR1098	040-1570	
	Rogue w/ Factory Rack	14-16	SR1098	040-1570	
	Rogue w/ Factory Rack	08-13	SR1098	040-1570	
	Rogue Select w/ Factory Rack	14-15	SR1098	040-1570	
	Sentra 2DR	91-95	SR1004	040-1079	Y
	Sentra 2DR	86-90	SR1001	040-1076	
	Sentra 3DR	86-90	SR1001	040-1076	
	Sentra 4DR	07-12	SR1002	040-1077	
	Sentra 4DR	00-06	SR1005	040-1080	
	Sentra 4DR	95-99	SR1004	040-1079	
	Sentra 4DR	91-94	SR1004	040-1079	
	Sentra 4DR	82-90	SR1001	040-1076	
	Sentra 5DR	86-90	SR1001	040-1076	

Vehicle make, model and year			REF #	CTC part #	Adapter 040-1091 needed
Nissan	Sentra Classic 2DR	91-93	SR1001	040-1076	
	Sentra Classic 3DR	91-93	SR1001	040-1076	
	Sentra Classic 4DR	91-93	SR1001	040-1076	
	Sentra Classic 5DR	91-93	SR1001	040-1076	
	Stanza 4DR	90-92	SR1008	040-1083	
	Stanza 4DR	87-89	SR1003	040-1078	
	Stanza 5DR	87-89	SR1005	040-1080	
	Versa 4DR	07-11	SR1002	040-1077	
	Versa 5DR	07-12	SR1002	040-1077	
Oldsmobile	Xterra w/ Raised Rails	00-04	SR1098	040-1570	
	88 4DR	92-99	SR1002	040-1077	
	98 4DR	91-96	SR1002	040-1077	
	Alero 2DR	99-05	SR1004	040-1079	
	Alero 4DR	99-05	SR1004	040-1079	
	Bravada 3DR	82-94	SR1003	040-1078	
	Custom Cruiser Wagon	77-90	SR1001	040-1076	
	Cutlass Ciera 4DR	82-96	SR1002	040-1077	
	Cutlass Cruiser Wagon	84-96	SR1002	040-1077	
	Cutlass Supreme 4DR	89-97	SR1005	040-1080	
	Cutlass Supreme 4DR	78-88	SR1001	040-1076	
	Firenza 2DR	82-88	SR1001	040-1076	
	Firenza 3DR	82-88	SR1001	040-1076	
	Firenza 4DR	82-88	SR1001	040-1076	
	Firenza Wagon	82-88	SR1001	040-1076	
	Intrigue 4DR	98-01	SR1002	040-1077	
	LSS 4DR	96-98	SR1005	040-1080	
	Olds 98	77-84	SR1001	040-1076	
	Optima 3DR	87-93	SR1003	040-1078	Y
	Optima 4DR	87-93	SR1003	040-1078	
	Optima 5DR	87-93	SR1003	040-1078	
	Toronado 2DR	86-89	SR1005	040-1080	Y
	Trofeo 2DR	87-89	SR1005	040-1080	Y
Peugeot	504 4DR	75-95	SR1001	040-1076	
	505 4DR	80-91	SR1001	040-1076	
	505 Wagon	84-91	SR1001	040-1076	
Plymouth	Acclaim 4DR	88-95	SR1004	040-1079	
	Breeze 4DR	96-99	SR1004	040-1079	
	Colt 2DR	93-96	SR1003	040-1078	Y
	Colt 3DR	79-88	SR1005	040-1080	Y
	Colt 4DR	93-96	SR1003	040-1078	
	Colt 4DR	79-88	SR1005	040-1080	
	Colt 100 3DR	89-92	SR1005	040-1080	Y
	Colt 100 4DR	89-92	SR1005	040-1080	
	Colt 200 3DR	89-92	SR1004	040-1079	Y
	Colt Minivan	92-96	SR1001	040-1076	
	Colt Minivan	84-91	SR1001	040-1076	
	Colt Vista	84-91	SR1001	040-1076	
	Duster 3DR	87-94	SR1004	040-1079	Y

Vehicle make, model and year			REF #	CTC part #	Adapter 040-1091 needed
Plymouth	Duster 5DR	87-94	SR1004	040-1079	
	Grand Voyager	96-99	SR1004	040-1079	
	Grand Voyager	88-95	SR1001	040-1076	
	Laser 3DR	84-86	SR1004	040-1079	
	Neon 2DR	94-99	SR1008	040-1083	Y
	Neon 4DR	00-01	SR1004	040-1079	
	Neon 4DR	94-99	SR1008	040-1083	
	Sundance 3DR	87-94	SR1004	040-1079	Y
	Sundance 5DR	87-94	SR1004	040-1079	
	Voyager	96-00	SR1004	040-1079	
Pontiac	Voyager	84-95	SR1001	040-1076	
	2000 2DR	89-94	SR1001	040-1076	
	2000 2DR	82-88	SR1001	040-1076	
	2000 3DR	82-88	SR1001	040-1076	
	2000 4DR	82-94	SR1001	040-1076	
	Acadian 3DR	78-87	SR1001	040-1076	
	Acadian 5DR	78-87	SR1001	040-1076	
	Bonneville 4DR	92-99	SR1002	040-1077	
	Fiero 2DR	84-88	SR1003	040-1078	
	Firebird	93-02	SR1002	040-1077	
	Firebird T-Top	93-02	SR1002	040-1077	
	Firefly 3DR	95-00	SR1003	040-1078	Y
	Firefly 3DR	89-94	SR1004	040-1079	Y
	Firefly 3DR	84-88	SR1003	040-1078	Y
	Firefly 4DR	95-00	SR1003	040-1078	
	Firefly 4DR	89-94	SR1004	040-1079	
	Firefly 4DR	84-88	SR1003	040-1078	
	Firefly 5DR	89-94	SR1004	040-1079	
	Grand Am 2DR	99-05	SR1004	040-1079	
	Grand Am 2DR	99-04	SR1004	040-1079	Y
	Grand Am 4DR	99-05	SR1004	040-1079	
	Grand Prix 2DR	79-87	SR1001	040-1076	
	Grand Prix 4DR	97-08	SR1002	040-1077	
	Grand Prix 4DR	88-96	SR1005	040-1080	
	Le Mans 3DR	87-93	SR1003	040-1078	Y
	Le Mans 4DR	87-93	SR1003	040-1078	
	Le Mans 5DR	87-93	SR1003	040-1078	
	Montana SV6 w/ Factory Rack	05-09	SR1098	040-1570	
	Montana w/ Factory Rack	00-04	SR1098	040-1570	
	Parisienne	83-88	SR1001	040-1076	
	Safari Wagon w/ Factory Rack	1989	SR1098	040-1570	
	Sunbird 2DR	88-94	SR1001	040-1076	
	Sunbird 2DR	82-87	SR1001	040-1076	
	Sunbird 3DR	82-88	SR1001	040-1076	
	Sunbird 4DR	82-94	SR1001	040-1076	
	Sunbird Wagon	82-94	SR1001	040-1076	
	Sunbird Wagon w/ Factory Rack	82-94	SR1098	040-1570	
	Sunfire 2DR	95-04	SR1005	040-1080	Y

Vehicle make, model and year			REF #	CTC part #	Adapter 040-1091 needed
Pontiac	Sunfire 4DR	95-04	SR1005	040-1080	
	Sunrunner 3DR	94-98	SR1002	040-1077	
	Tempest 4DR	88-91	SR1005	040-1080	
	Trans-Am	93-02	SR1002	040-1077	
	Trans-Am T-Top	93-02	SR1002	040-1077	
	Trans Sport w/ Factory Rack	97-99	SR1098	040-1570	
	Wave 5DR	05-07	SR1002	040-1077	
Porsche	Vibe w/ Factory Rack	03-08	SR1098	040-1570	
	911	64-98	SR1001	040-1076	
	911 Clothtop	76-98	SR1001	040-1076	
	911 Targa	76-98	SR1001	040-1076	
	924	75-91	SR1001	040-1076	
	Cayenne w/ Factory Rack	11-16	SR1098	040-1570	
Renault	Cayenne w/ Factory Rack	03-10	SR1098	040-1570	
	5 3DR	72-95	SR1001	040-1076	
	5 5DR	72-95	SR1001	040-1076	
	18 4DR	78-91	SR1001	040-1076	
	Fuego 3DR	83-91	SR1001	040-1076	
Saab	9-2x 5DR	95-05	SR1008	040-1083	Y
	9-3 5DR	99-01	SR1005	040-1080	
	9-3 SportCombi Wagon w/ Factory Rack	06-12	SR1098	040-1570	
	9-4x w/ Factory Rack	10-12	SR1098	040-1570	
	9-5 Wagon w/ Factory Rack	99-12	SR1098	040-1570	
	9-7x w/ Factory Rack	05-09	SR1098	040-1570	
	900 3DR	94-98	SR1005	040-1080	
	900 3DR	78-93	SR1001	040-1076	
	900 5DR	94-98	SR1005	040-1080	
	900 5DR	78-93	SR1001	040-1076	
	9000 4DR	84-97	SR1004	040-1079	
	9000 5DR	84-98	SR1004	040-1079	
Saturn	Aura	08-10	SR1002	040-1077	
	Relay w/ Raised Rails	05-07	SR1098	040-1570	
	Vue W/ Factory Rack	08-10	SR1098	040-1570	
	Vue W/ Factory Rack	06-07	SR1098	040-1570	
Subaru	DL Wagon	85-89	SR1001	040-1076	
	GL 3DR	85-88	SR1001	040-1076	
	GL 4DR	85-89	SR1001	040-1076	
	GL Wagon	85-89	SR1001	040-1076	
	Forester w/ Factory Rack	14-16	SR1098	040-1570	
	Forester w/ Factory Rack	09-13	SR1098	040-1570	
	Impreza 2DR	94-01	SR1008	040-1083	Y
	Impreza 4DR	12-16	SR1010	040-1096	
	Impreza 4DR	08-11	SR1010	040-1096	
	Impreza 4DR	94-01	SR1008	040-1083	
	Impreza 5DR	12-16	SR1010	040-1096	
	Impreza 5DR	08-11	SR1010	040-1096	
	Impreza Outback 5DR	95-05	SR1008	040-1083	Y
	Impreza Wagon	94-05	SR1008	040-1083	Y

Vehicle make, model and year			REF #	CTC part #	Adapter 040-1091 needed
Subaru	Impreza Wagon w/ Raised Rails	02-07	SR1098	040-1570	
	Justy 3DR	87-95	SR1001	040-1076	
	Justy 5DR	87-95	SR1001	040-1076	
	Legacy 4DR	10-14	SR1010	040-1096	
	Legacy 4DR	05-09	SR1008	040-1083	
	Legacy 4DR	00-04	SR1008	040-1083	
	Legacy 4DR	95-99	SR1008	040-1083	
	Legacy 4DR	90-94	SR1008	040-1083	
	Loyale 4DR	90-94	SR1001	040-1076	
	Loyale Wagon	90-94	SR1001	040-1076	
	Outback 4DR	00-01	SR1008	040-1083	
	Outback Wagon w/ Raised Rails	08-09	SR1098	040-1570	
	Outback Wagon w/ Raised Rails	05-07	SR1098	040-1570	
	Tribeca w/ Factory Rack	06-14	SR1098	040-1570	
	WRX / STI Wagon w/ Raised Rails	02-07	SR1098	040-1570	
	XT	85-91	SR1001	040-1076	
	XT6	85-91	SR1001	040-1076	
Suzuki	Aerio 4DR	02-06	SR1002	040-1077	
	Cultus 3DR	84-88	SR1003	040-1078	
	Esteem 4DR	95-02	SR1003	040-1078	
	Forsa 3DR	84-88	SR1003	040-1078	Y
	Forsa 5DR	84-88	SR1003	040-1078	
	Grand Vitara w/ Factory Rack	99-06	SR1098	040-1570	
	Samurai 3DR	83-98	SR1001	040-1076	
	Sidekick 3DR	89-98	SR1002	040-1077	
	Swift 3DR	95-00	SR1003	040-1078	Y
	Swift 3DR	89-94	SR1004	040-1079	Y
	Swift 4DR	89-94	SR1004	040-1079	
	Swift 5DR	89-94	SR1004	040-1079	
	SX4 5DR w/ Factory Rack	07-13	SR1098	040-1570	
	Vitara w/ Factory Rack	99-04	SR1098	040-1570	
Toyota	XL7 w/ Factory Rack	01-06	SR1098	040-1570	
	4Runner 3DR	90-98	SR1005	040-1080	Y
	4Runner 5DR	90-02	SR1004	040-1079	
	4Runner 5DR w/ Factory Rack	10-16	SR1098	040-1570	
	4Runner 5DR w/ Factory Rack	03-09	SR1098	040-1570	
	Camry 2DR	92-96	SR1005	040-1080	Y
	Camry 4DR	12-16	SR1002	040-1077	
	Camry 4DR	07-11	SR1002	040-1077	
	Camry 4DR	97-01	SR1005	040-1080	
	Camry 4DR	92-96	SR1005	040-1080	
	Camry 4DR	87-91	SR1001	040-1076	
	Camry 4DR	82-86	SR1001	040-1076	
	Camry Wagon	87-91	SR1001	040-1076	
	Camry Wagon	92-97	SR1005	040-1080	
	Camry Wagon	82-86	SR1001	040-1076	
	Camry Wagon w/ Factory Rack	92-97	SR1099	040-1571	
	Celica 2DR	86-89	SR1008	040-1083	Y

Vehicle make, model and year			REF #	CTC part #	Adapter 040-1091 needed
Toyota	Celica 3DR	00-05	SR1008	040-1083	Y
	Celica 3DR	90-93	SR1008	040-1083	Y
	Celica 3DR	86-89	SR1008	040-1083	Y
	Celica 3DR	79-85	SR1003	040-1078	
	Corolla 4DR	14-16	SR1010	040-1096	
	Corolla 4DR	09-13	SR1002	040-1077	
	Corolla 4DR	03-08	SR1002	040-1077	
	Corolla 4DR	98-02	SR1008	040-1083	
	Corolla 4DR	93-97	SR1008	040-1083	
	Corolla 4DR	88-92	SR1001	040-1076	
	Corolla 4DR	80-87	SR1001	040-1076	
	Corolla GTS 2DR	85-91	SR1004	040-1079	Y
	Corolla SR5 2DR	85-91	SR1004	040-1079	Y
	Corolla Wagon	93-97	SR1001	040-1076	
	Corolla Wagon	88-92	SR1001	040-1076	
	Corolla Wagon w/ Factory Rack	93-97	SR1098	040-1570	
	Corolla Wagon w/ Factory Rack	88-92	SR1098	040-1570	
	Cressida 4DR	85-88	SR1003	040-1078	
	Echo 2DR	00-05	SR1003	040-1078	Y
	Echo 4DR	00-05	SR1003	040-1078	
	Echo 5DR	04-05	SR1003	040-1078	
	FJ Cruiser w/ Factory Rack	07-14	SR1098	040-1570	
	FX16	87-89	SR1001	040-1076	
	Highlander w/ Factory Rack	10-13	SR1098	040-1570	
	Highlander w/ Factory Rack	08-09	SR1098	040-1570	
	Highlander w/ Factory Rack	01-07	SR1098	040-1570	
	Land Cruiser	93-97	SR1001	040-1076	
	Matrix w/ Factory Rack	03-08	SR1098	040-1570	
	MR-2	90-97	SR1003	040-1078	
	MR-2	85-89	SR1001	040-1076	
	Paseo 2DR	91-97	SR1008	040-1083	Y
	Pickup	79-89	SR1001	040-1076	
	Pickup Xtra Cab	89-95	SR1004	040-1079	Y
	Previa w/ Factory Rack	91-98	SR1098	040-1570	
	Prius 5DR	10-15	SR1002	040-1077	
	Prius 5DR	04-09	SR1002	040-1077	
	Rav 4 3DR	95-00	SR1002	040-1077	Y
	Rav 4 5DR	01-05	SR1002	040-1077	
	Rav 4 5DR	95-00	SR1002	040-1077	
	Rav 4 w/ Factory Rack	06-12	SR1098	040-1570	
	Rav 4 w/ Factory Rack	01-05	SR1098	040-1570	
	Sequoia w/ Factory Rack	08-16	SR1099	040-1571	
	Sequoia w/ Factory Rack	01-07	SR1099	040-1571	
	Sienna w/ Factory Rack	04-09	SR1098	040-1570	
	Sienna w/ Factory Rack	98-03	SR1098	040-1570	
	Solara 2DR	99-03	SR1008	040-1083	Y
	Supra 3DR	86-93	SR1008	040-1083	Y
	Tacoma 2DR	96-00	SR1005	040-1080	Y

Vehicle make, model and year			REF #	CTC part #	Adapter 040-1091 needed
Toyota	Tacoma 4DR Double Cab	01-04	SR1005	040-1080	
	Tercel 2DR	95-99	SR1003	040-1078	Y
	Tercel 2DR	91-94	SR1008	040-1083	Y
	Tercel 2DR	86-90	SR1003	040-1078	
	Tercel 3DR	86-90	SR1003	040-1078	
	Tercel 4DR	95-99	SR1003	040-1078	
	Tercel 4DR	91-99	SR1003	040-1078	
	Tercel 4DR	88-90	SR1001	040-1076	
	Tercel 4DR	80-87	SR1001	040-1076	
Volkswagen	Tercel 5DR	86-90	SR1003	040-1078	
	Venza w/ Factory Rack	09-15	SR1098	040-1570	
	Yaris 4DR	07-12	SR1002	040-1077	
	Yaris 5DR	06-15	SR1002	040-1077	
	Corrado 3DR	90-95	SR1003	040-1078	
	Dasher 4DR w/ Raised Rails	74-81	SR1098	040-1570	
	Dasher Wagon w/ Raised Rails	74-81	SR1098	040-1570	
	Fox 2DR	87-94	SR1001	040-1076	
	Fox 4DR	87-94	SR1001	040-1076	
	Fox 5DR	87-94	SR1001	040-1076	
	GLI 4DR	11-14	SR1010	040-1096	
	GLI 4DR	05-10	SR1010	040-1096	
	GTI 5DR	10-14	SR1010	040-1096	
	GTI 5DR	06-09	SR1010	040-1096	
	Golf 3DR	85-92	SR1001	040-1076	
	Golf 5DR	10-14	SR1010	040-1096	
	Golf 5DR	85-92	SR1001	040-1076	
	Golf R 5DR	12-13	SR1010	040-1096	
	Golf Wagon w/ Factory Rack	10-15	SR1098	040-1570	
	Golf SportWagen w/ Factory Rack	2016	SR1098	040-1570	
	Jetta 4DR	11-16	SR1010	040-1096	
	Jetta 4DR	05-10	SR1010	040-1096	
	Jetta 4DR	85-92	SR1001	040-1076	
	Jetta SportWagen w/ Factory Rack	09-15	SR1098	040-1570	
	Jetta Wagon w/ Raised Rails	06-08	SR1098	040-1570	
	Jetta Wagon w/ Raised Rails	01-05	SR1098	040-1570	
	Passat 4DR	90-97	SR1002	040-1077	
	Passat Wagon	90-97	SR1002	040-1077	
	Passat Wagon w/ Factory Rack	07-10	SR1098	040-1570	
	Passat Wagon w/ Factory Rack	98-08	SR1098	040-1570	
	Passat Wagon w/ Factory Rack	90-97	SR1098	040-1570	
	Quantum	82-88	SR1001	040-1076	
	Quantum 4DR w/Raised Rails	82-88	SR1098	040-1570	
	Rabbit 5DR	06-09	SR1010	040-1096	
	Routan w/ Factory Rack	09-10	SR1099	040-1571	
	Tiguan w/ Factory Rack	12-16	SR1098	040-1570	
	Tiguan w/ Factory Rack	08-11	SR1098	040-1570	
	Touareg w/ Factory Rack	08-10	SR1099	040-1571	
	Touareg w/ Factory Rack	04-07	SR1099	040-1571	

Vehicle make, model and year			REF #	CTC part #	Adapter 040-1091 needed
Volkswagen	Westfalia Camper	65-92	SR1001	040-1076	
	S80 4DR	99-03	SR1002	040-1077	
	S90 4DR	98-99	SR1001	040-1076	
	200 Series 4DR	74-93	SR1001	040-1076	
	200 Series Wagon	74-93	SR1001	040-1076	
	200 Series Wagon w/ Factory Rack	74-93	SR1098	040-1570	
	700 Series 2DR	83-92	SR1001	040-1076	
	700 Series 4DR	83-92	SR1001	040-1076	
	700 Series Wagon	83-92	SR1001	040-1076	
	700 Series Wagon w/ Factory Rack	83-92	SR1098	040-1570	
	850 Wagon	93-97	SR1010	040-1096	
	850 Wagon w/ Factory Rack	93-97	SR1099	040-1571	
	900 Series 4DR	91-98	SR1001	040-1076	
	900 Series Wagon	91-97	SR1001	040-1076	
	V40 w/ Raised Rails	00-04	SR1098	040-1570	
	V50 Wagon w/ Factory Rack	05-11	SR1098	040-1570	
	V70 Wagon	98-00	SR1010	040-1096	
	V70 Wagon w/ Factory Rack	98-10	SR1098	040-1570	
	V70 XC w/ Factory Rack	98-04	SR1098	040-1570	
Volvo	V90 Wagon	98-00	SR1001	040-1076	
	XC70 w/ Factory Rack	01-09	SR1098	040-1570	
	XC90 w/ Factory Rack	2016	SR1099	040-1571	
	XC90 w/ Factory Rack	03-15	SR1098	040-1570	