



16,000 mAh POWER BANK WITH LED DISPLAY User Manual

Model No. 035-5547-8

SAFETY INFORMATION

IMPORTANT: RETAIN FOR FUTURE REFERENCE AND READ CAREFULLY!

Read this manual carefully before using the product. Follow all safety instructions to avoid damage caused by improper use. Should this product be transferred to a third person, this manual must be included.

WARNING!

- Make sure your connected device is firmly and securely fastened.
- Follow all applicable local laws and regulations concerning the use of a mobile device.
- The USB port is not designed for transferring data. Do not connect external data storage products or any data transfer cables to the USB port.
- DANGER! Never let children play with packaging materials and this product.

This product is not a toy! Store the product and any accessories out of the reach of children.

- Do not disassemble the unit or replace the battery.
- Do not throw device into fire or water.
- Do not use the product in extremely hot, humid or corrosive environments to avoid damage.
- Avoid excessive drops, abrasions and punctures.
- The product does not support simultaneous charging and discharging.

SPECIFICATIONS:

Micro USB Input: 5 V/2 A

Type-C Input: 5 V/2.4 A

Type-C and USB A Output: 5 V/3 A max.


Battery Capacity: 16,000 mAh/59.2 Wh Polymer battery

PACKAGE CONTENTS:

1. 16,000 mAh power bank
2. Micro USB charging cable
3. User manual



Micro USB cable




OPERATION INSTRUCTION:

• Input:

When the product is out of power or the battery is low, charge the product. You can use a standard USB charging cable with Micro USB connector to connect this product, and plug the USB A into a minimum 5 V, 2 A charging device such as a car charger, household appliances, etc., to charge the product.

• Output:

1. Insert the USB charging cable USB A end into Output.
2. Plug the other end of the cable into a terminal such as a mobile phone.
3. Press the switch button and the power is discharged to charge the terminal such as a mobile phone.



- Use of switches

Press the switch once to turn on the product; the battery indicator will light up. It will now be in standby state and other devices can be charged. When the unit is in standby state, press the switch twice in succession to turn off the power.

TIPS: In standby state, if you do not perform other operations, the charger will automatically shut down after about 35 seconds. If you need to use it again, please press the switch again.

This Class B digital apparatus complies with Canada ICES-003.
CAN ICES-3(B)/NMB-3(B)



Product must be recycled or disposed of properly. Dispose of as per the requirements of your local municipality.

Made in China

Imported by Trileaf Distribution Toronto, Canada M4S 2B8