



12 V Bluetooth® FM Transmitter

Model no. 035-7155-8

SAFETY INFORMATION

IMPORTANT, RETAIN FOR FUTURE REFERENCE AND READ CAREFULLY!

Read this manual carefully before using the product. Follow all safety instructions to avoid damage caused by improper use. Should this product be transferred to a third person, this manual must be included.

WARNING!

- Make sure your connected device is firmly and securely fastened. Route all cables so that they will not interfere with driving.
- Follow all applicable local laws and regulations concerning the use of a mobile device while driving.
- Do not operate the device connected to the car transmitter while driving.
- Do not use if this product or your car's 12 V outlet (cigarette lighter socket) is damaged.
- The USB port is not designed for transferring data. Do not connect to external data storage products or any data transfer cables to the USB port.
- DANGER! RISK OF SUFFOCATION! Never let children play with packaging materials and this product. This product is not a toy! Store the product and any accessories out of the reach of children.
- CAUTION! Altering or tampering with the car transmitter presents an increased risk of injury. Such behaviour voids the warranty.

- Persons with limited physical, sensory or mental aptitude or lack of knowledge may use this product only under supervision or after receiving detailed instructions.
- DANGER! An incorrectly or carelessly installed car transmitter can impede safety while driving. Place the car transmitter where you can easily reach it and where it does not obstruct your view of the street. Make sure the car transmitter is installed securely to prevent it from falling while driving.
- DANGER! Objects installed near an airbag can be hurtled with high velocity in the event of the airbag being triggered, and thus cause severe injuries. Never install the car transmitter near an airbag.
- Do not make any notes or search for telephone numbers while driving. This distracts you from the traffic situation.
- Do not tug on the cable to unplug. Hold the plug itself to plug in or unplug.

INTENDED APPLICATION

An FM transmitter is a portable device that plugs into the headphone jack or proprietary output port of a portable audio or video device. The sound is then broadcasted through the transmitter, and plays through an FM broadcast band frequency. Purposes for an FM transmitter include playing music from a device through a car stereo, or any radio.

This product is intended for:


- ⇒ Charging smartphones, MP3/MP4 players, GPS, etc. with USB port
- ⇒ Playback of smartphone and MP3/MP4 player playlists through the car stereo
- ⇒ Hands-free calling: receive calls through the car stereo

This product is compatible with iPhone 4S/4/3GS/3G/5/5S/6/6S/7/7 plus/8/8 plus, iPod touch /iPod classic, MP3/MP4 players, other smartphones, GPS or devices with USB socket.

Unpacking

- Carefully remove all packaging materials and keep for future use.
- Inspect the product carefully to make sure no breakage or damage occurred during shipping.

Parts List



No.	Description
1.	CH FM key
2.	Telephone answering, song play/pause button
3.	Last song/down volume
4.	Next song/Up volume
5.	USB port (5V-2.1A charging)
6.	Digital display
7.	12V outlet (cigarette lighter) connector

Button operation

1. "CH" Key: when you need to adjust the frequency, short press "CH" key to enter the frequency state, (when the light is flashing), press the up/down key to adjust the adaptable frequency.
2. "▶/⏸/⏹" button:
 - a) When you have a call, short press this button to answer the call, long press this button to reject the call; During conversation, shortly press this button to hang up the phone.
 - b) When playing the music, short press this button to switch between play and pause.

3. "⏮" key: the last song/volume minus, when playing music, short press for the last song; long press for the volume reduction.
4. "⏭" key: the next song/volume plus, when playing music, short press for the next song; long press for the volume increase.

Bluetooth® connection method of operation:

1. Plug FM transmitter into the cigarette lighter of the vehicle directly.
2. Please pair the Bluetooth® device before using. It only needs to be paired one time at the beginning and will be connected automatically next time. Search the Bluetooth® on your phone, and select "FM0356145" to connect (no password needed).

OPERATION

Charging Mobile Devices

1. Plug FM transmitter into the 12 V cigarette lighter of the vehicle directly.
2. Connect your mobile device to the car transmitter using:
USB cable (not provided) for a smartphone.
Micro-USB cable (not provided) for an MP3/MP4 player.

Attention!

IMPORTANT! Disconnect the product when the engine is turned off for extended periods of time. In some cars, the power is not cut off after the engine is turned off. If the product is left connected, the car battery may discharge.

Playback of Audio Playlists

1. Please pair the Bluetooth® device as specified.
2. Short press "CH" key (1) to enter the frequency state, (when the light is flashing), press the up/down(3)/(4) key to select the optimal radio FM frequency
3. Set the same frequency on the car stereo
4. Now the car transmitter is ready to transmit the audio signal to the car stereo.

"Hands-free" Calling

1. Please pair the Bluetooth® device as specified.
2. Short press "CH" key (1) to enter the frequency state, (when the light is flashing), press the up/down(3)/(4) key to select the optimal radio FM frequency
3. Set the same frequency on the car stereo
4. When the call comes, the playing music will pause. Press the answer key (2) to answer the call, and then you'll hear the voice of the caller through the car radio. When the call concludes, the music will automatically resume playing.
5. During conversations, short press the "CH" to change the hands-free calling into cellphone, press "CH" again to turn the calling back to the hands-free calling again.

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Shenzhen Daza Innovation Technology Co.,Ltd. is under licence. Other trademarks and trade names are those of their respective owners.

FREQUENTLY ASKED QUESTIONS

Question: My music is playing, but there seems to be a lot of static.

Answer:

1. Please adjust the frequency to find the optimal one to play your audio files through the car stereo.
2. Tune your car stereo to the same frequency shown on the LCD display (6).

Question: My car radio only scans occupied FM stations.

Answer: Many car radios are by default set to scan only occupied FM stations. Most of these radios can be switched to manual tuning (consult your car radio instructions on how to do this). By tuning, you can go forward and backward to every station.

TECHNICAL SPECIFICATIONS

Power supply: 12 V

Output voltage: 5 V 2.1 A

Frequency range: 88.1 - 107.9 MHz (0.1 MHz/step)

MAINTENANCE AND SERVICE

Care

- Clean the product with a soft, dry cloth. Do not use aggressive solvents or detergents.
- Never submerge the product in water or any other liquid.
- Store the product in a clean, dry place, away from dust and moisture.

Warranty

This product carries a 1 year warranty.

This unit carries an exchange warranty only against defects in workmanship and materials when accompanied by proof of purchase. There are no replacement parts. Malfunctions due to abuse, misuse, or accidental damage are not covered by warranty.

035-7155-8

Made in China

Imported by TRILEAF DISTRIBUTION TORONTO, CANADA M4S 2B8

IC

This Class B digital apparatus complies with Canadian RSS-210.

This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

IC ID#: 23495-03571558

Product must be recycled or disposed of properly. Dispose of as per the requirements of your local municipality.

