ALL PURPOSE CANOPY

10'X20'X9'6"(3.04X6.08X2.9m) 6-Leg

INSTRUCTION MANUAL

Model No.:37-1107-6





CAUTION!

Please read and understand this manual before any assembly or use of this product.

Before beginning assembly of the product, make sure all parts are present. Compare parts with packaging contents list. If any part is missing, or if you have any questions, contact the vendor's customer service department at;

1-866-567-4089 (Monday-Friday 8:00am-7:00pm EST) (Saturday 9:00am - 7:00pm EST)

DO NOT RETURN TO STORE!

Version:03 Last updated: December 2012


TABLE OF CONTENTS


Important safety instructions	2
Intended use	2
Parts list	3
Assembly preparation	3
Assembly 4	
Maintenance and care	8
Limited warranty	8

IMPORTANT SAFETY INSTRUCTIONS



- To reduce the risk of serious injury, read the following safety instructions before assembling and using the product.
- No responsibility is accepted for damages or injuries resulting from improper installation or noncompliance with these instructions.
- Please note that the Manufacturer has no control over the elements such as wind, heavy snow or rain. The Manufacturer cannot control the location or soil conditions into which the canopy is placed. The Manufacturer, without control of the elements, location or soil conditions, cannot be held responsible for damages caused by the shed to other items or damages to the shed itself.
- This product is a temporary structure and is not recommended as a permanent structure.
- Choose your canopy's location carefully. Install your canopy on flat horizontal ground only.
- . Ensure enough clearance around the product. Before assembling the product, find level ground not less than 6' (1.8 m) away from any structures or obstructions, such as fences, garages, houses, etc.





- Get an overview of all parts before attempting installation. Make sure all components are present.
- Do not use this product in environments for which it is not intended (i.e. extreme cold, high winds, extreme heat, heavy rainfall, etc.).
- Always wear safety glasses when assembling this product. Wear gloves when working with tubing to prevent cuts or abrasions.
- Any assembly or maintenance on the product must be carried out by adults only.
- Make sure you have the necessary manpower when assembling or moving the product.
- Keep children and pets away while setting up the product.
- . CAUTION! Always keep children under close supervision while they are using this product or are in its vicinity. Never leave children unattended.
- Proper anchoring, keeping the cover tight and free of snow and debris is the responsibility of the consumer. Damages caused by improper anchoring are not included in the warranty.
- WARNING! Keep all flames and heat sources away from this fabric canopy. The fabric will burn if left in continuous contact with a flame source.
- This canopy is NOT meant to hold heavy snow or ice loads. Snow or ice accumulation may cause your canopy to collapse. To avoid overload, brush snow and ice from the roof with a broom or mop.
- Do not use hard-edged tools or instruments, such as rakes or shovels, to remove snow. These may puncture the cover.
- NEVER clear the roof of snow or debris from inside the shed to avoid collapse, damage to property, personal injury and/or death.
- Remove accumulated water from the roof immediately or disassemble the canopy in order to avoid any damage.
- Do not use alkaline detergents for cleaning. It will damage the polycarbonate material. Soap and warm water are recommended.

IMPORTANT! READ CAREFULLY AND RETAIN FOR FUTURE REFERENCE

INTENDED USE

This temporary canopy is intended to offer protection from damages caused by the sun, light rain, light snow, tree sap, bird and animal excrements. Do not use it to shield goods from high winds, heavy snow or ice storms. Only use it for its intended use.







NO	Description	Drawing	Qty.
1	39" Straight Tube	<u> </u>	6
2	40 1/4"Swedged Tube		24
3	24" Rafter Tube	()+++	6
4	40 5/8" Straight Cross Tube	() ±++	6
5	3-Way Connectors		6
6	4-Way Connectors		3
7	Base Fastening Stake		12
8	Foot Plate		6
9	Roof Tarp	6	1
10	Ball Tie Down	00	20
11	Rope 40'		1
12	Rope Fastening Stake		4
#	Owner's Manual		1

[&]quot;#"Indicates a non-illustrated part

ASSEMBLY PREPARATION

- Place all parts from the packaging box in a cleared area and arrange them on the ground in front of you.
- Remove all packaging materials and place them back in the box. Do not dispose of the packaging materials until assembly is complete.
- Check for completeness and transport damages. In case of damages or incomplete delivery, please call our toll-free number 1-866-567-4089 for assistance.



WARNING!

- Do not place the product under trees from which hard fruit such as apples, walnuts or heavy pine cones, etc., may fall. The cover only protects against normal leaves and light debris, whereas large branches or other falling items may puncture or tear the cover material.
- Keep children away during assembly. This product contains small parts which can be swallowed by children.
- Do not attempt to assemble the product if any parts are missing.
- At least 2 people are needed to complete the assembly as some of the steps require heavy lifting.



Tools required for assembly (not included)



Please read instructions fully before beginning assembly.


Step 1

• Unpack and check the contents of the box. Make sure that you have all the parts described in the below parts list.

Step 2

• Layout all the frame parts as shown in Diagram A


Diagram A



Step3

• Combine all parts as shown in Diagram B to form he peak of the canopy frame.


Diagram B



Step 4

• Add the (2) eaves on each side as shown in Diagram C

Diagram C




Note: Make sure all pipes are connected tightly, use rubber mallet to help when necessary

PARTS LIST


Step 5

• As shown below in diagram D insert the 6 legs part #1 to 4-way connectors part #6 and 3-way connectors part #5. And remember the hole on part #1 should be on Top side.




Step 6

• As shown below in Diagram E place the cover over the frame with the eyelets facing down. To provent the cover from blowing away by the wind, fix the four corner of the cover by Bangee Cord(10) on the frame.



For each corner of the Roof Tarp (9). (See Diagram F)

- a. Connect the Tarp Corner Hook to the hole on the inside corner of the Straight Tube (1).
- b.Pull the end of the Rope snug and tie it off.




ASSEMBLY

Step 7

• Then insert the rest 6 legs into the legs Part#1as shown in Diagram G.


Diagram G



• Starting at the four corners, secure the cover by inserting the Ball Tie Downs into the eyelets. Wrapping the cord around the tube and hook it cover the ball.(See Diagram H)

Note: Pls set the Ball Tie Down symmetrically


Diagram H



Step 8


• Insert the (6) legs into the (6) Foot Plates(#8).

Diagram I



• When you are sure that every foot plate is just in the right place, please connect the plates to the ground by using the 12pcs Base Fastening Stakes(#7),each plate 2 stakes.

(Refer to below diagram)




ASSEMBLY

Step 9


• Insert the (4) Base Fastening Stake(Part#12) into the ground and tie ropes from the Stake to the frame corners tees as shown in Diagram J. Then you get this Canopy ready for use.

Note: Pls cut rope 40' (Part #11) into 4 pieces, 10 'per piece.

Diagram J



PRODUCT DIAGRAM



CLEANING AND MAINTENANCE

- DO NOT apply any polishing or protective products to the roof tarp and panels, or use harsh abrasives, bleach or cleansers. The
 roof tarp and panels can be easily cleaned with mild soap and water. Handle mildew and mould stains with mild soap.
- Periodically check the anchors, the tension of rope and all hardware to ensure the stability of the canopy during use. Be sure that
 the cover kept tight.

Dismantling and storage

- Dismantle the canopy in reverse order of the setup.
- Always dismantle the canopy completely! A partially dismantled canopy is not stable enough to withstand wind and weather and can be damaged or cause damage.
- Before storing, please make sure that the canopy is completely dry and clean. Fold the material carefully along the seams.
- Do not wrap the poles and anchors in the fabric, as they may damage it.
- Select a storage place that is dry and well ventilated to reduce the risk of mildew and mould stains. If pockets of water (large amounts
 of water on the roof), snow or ice should form, remove immediately or dismantle the canopy to prevent any damage.
- Store your canopy in a cool, dry location between seasons to prolong the service life of all components. Components are not equally
 durable and may require replacement over time at different intervals.
- Always keep these instructions together with the canopy!

LIMITED WARRANTY

This product is guaranteed for 1 year from the date of original retail purchase against defects in materials and workmanship.

Subject to the conditions and limitations described below, this product must be returned with proof of purchase within the stated warranty period, and, if covered under this warranty, will be replaced (fully or partially with the same model or one of equal value or specification) at the Manufacturer's option. Liability is restricted to repair or replacement only and does not include any related labour costs of installation, or any costs related to dismantling, repair or transportation.

These warranties are subject to the following conditions and limitations:

- a) A bill of sale verifying the purchase and purchase date must be provided.
- b) This warranty will not apply to any product or part thereof which is worn or broken or which has become inoperative due to abuse, misuse, accidental damage, neglect or lack of proper installation, operation or maintenance (as outlined in the applicable owner's manual or operating instructions), or which is being used for industrial, professional, commercial or rental purposes.
- c) This warranty will not apply to normal wear and tear or to expendable parts or accessories that may be supplied with the product which are expected to become inoperative or unusable after a reasonable period of use.
- d) This warranty will not apply to routine maintenance and consumable items such as the cover, ratchets, webbed belts, nuts, bolts, etc.
- e) This warranty will not apply where damage is caused by repairs made or attempted by others (i.e. persons not authorized by the manufacturer).
- f) This warranty will not apply to any product that was sold to the original purchaser as a reconditioned or refurbished product (unless otherwise specified in writing).
- g) This warranty will not apply to any product or part thereof if any part from another manufacturer is installed therein or any repairs or alterations have been made or attempted by unauthorized persons.
- h) This warranty will not apply to normal deterioration of the exterior finish, such as, but not limited to, scratches, dents, paint chips, or to any corrosion or discolouring by heat, cold, abrasive and chemical cleaners.
- i) This warranty will not apply to component parts sold by and identified as the product of another company, which shall be covered under the other product manufacturer's Warranty, if any.

Additional Limitations

This warranty applies only to the original purchaser and may not be transferred. Neither the retailer nor the manufacturer shall be liable for any other expense, loss or damage, including, without limitation, any indirect, incidental, consequential or exemplary damages arising in connection with the sale, use or inability to use this product.

Notice to Consumer

This warranty gives you specific legal rights, and you may have other rights, which may vary from province to province. The provisions contained in this warranty are not intended to limit, modify, take away from, disclaim or exclude any statutory warranties set forth in any applicable provincial or federal legislation.