

model no. 046-0584-2

Mastercraft®

GARAGE DOOR OPENER

EXTENSION RAIL KIT

8' (2.44 m)

IMPORTANT:

Before using the extension rail kit, read and understand this owner's guide.

INSTRUCTION

MANUAL

2

model no. 046-0584-2 | contact us 1-800-689-9928

PACKAGE CONTENTS

Rail Extension Section

Hook

Belt Assembly

WARNING:

To reduce the risk of severe injury or death, disconnect electrical power to the garage door opener before servicing or repairing.

3

Mastercraft

UNINSTALL THE OPENER

1. Pull the red trolley release handle to disengage the opener from the door.

2. Unplug the opener from the AC outlet. Uninstall the opener from the header bracket and mounting bracket.

3. Place the opener on the floor.

4

model no. 046-0584-2 | contact us 1-800-689-9928

DISASSEMBLE THE RAIL AND BELT

1. Loosen the turnbuckle on the rail to release the belt.

2. Remove the old belt.

3. Uninstall the screws from the sprocket assembly and motor unit.

4. Disassemble the rail sections from the motor unit.

5. Uninstall the stop bolt from the rail.

6. Detach the sprocket assembly from the rail.

NOTE:

\* Keep the nuts and bolts, they will be used again later.

5

Mastercraft

ASSEMBLE THE EXTENSION RAIL

1. Attach the extension rail to the last rail section.

2. Install the trolley assembly and attach the sprocket assembly to the rail.

3. Grasp the end of the new belt and pass the belt through the slot of the rail front end. Ensure the belt goes around on the idler pulley properly.

4. Attach the belt to the turnbuckle.

6

model no. 046-0584-2 | contact us 1-800-689-9928

ASSEMBLE THE RAIL TO THE OPENER

1. Attach the extended rail assembly to the opener. Secure the rail and sprocket assembly to the motor unit with screws.

2. Insert a bolt to the stop bolt hole and secure it with nut.

3. Wrap the belt around the sprocket. The sprocket must engage the belt.

4. Tighten the turnbuckle by rotating the turnbuckle only.

5. To avoid twisting the belt, insert the hook (provided) to the belt and then place on the rail.

6. Hold the hook and hand tighten the turnbuckle by rotating the turnbuckle.

7. Remove the hook after tightening the belt tension properly.

NOTE:

Too much or too little tension will cause excessive noise.

8

Mastercraft

ATTACH SPROCKET COVER

1. Squeeze the cover slightly and insert the 2 tabs on the cover in the slots on the motor unit.

WARNING

Always keep hand clear of sprocket and chain while operating opener.

Securely attach sprocket cover before operating.

9

Mastercraft

INSTALL THE OPENER

Refer to the Owner's Manual to complete the re-installation of your garage door opener.

1. Re-connect the safety beam sensors and wall console to the garage door opener.

PROGRAMMING

Refer to the Owner's Manual to setup the Travel Limit and Open/Close Force.

10

model no. 046-0584-2 | contact us 1-800-689-9928

WARRANTY

WARRANTY

This Mastercraft product carries a 6 (six) years LIMITED warranty against defects in workmanship and materials. This product is not guaranteed against wear or breakage due to misuse and /or abuse.

Made in China

Imported for Mastercraft Canada Toronto, Canada M4S 2B8

