

# BATTERY CASE

## OPERATING INSTRUCTIONS






### TOLL FREE: 1-888-670-6684

IMPORTANT: Please read this manual carefully before beginning assembly of this product. Keep this manual for future reference.

## INSTALLATION

1. Remove all unnecessary packaging from the product. This product comes attached with a "Try Me" connector that turns on the product when you press on its button. Remove the "Try Me" connector before first use (**Fig. 1**).
  - a. Unplug the "Try Me" connector from the battery box.
  - b. Push the rubber stub to cover the "Try Me" connector port.
2. You will find the battery control box on the back side of this product.
3. Unclip the buckles of the battery box and open the battery cover (**Fig. 1**).
4. Insert 3 new AA batteries (batteries not included). Match the polarity shown in the case (**Fig. 2**).
5. Close the battery cover and lock the buckles (**Fig. 3**).

**Fig. 1****Fig. 2****Fig. 3**

## FEATURES

### Light Functions:

#### 1. STEADY ON with Timer:


Press the control button once. The lights will be on and the timer function will be activated. The lights will stay lit for 6 hours before turning off automatically and will remain off for the next 18 hours. The lights will turn on again automatically after 18 hours.

#### 2. STEADY ON without Timer:

Press the control button once more. The lights will be on with the timer function turned off.

#### 3. OFF:

Press the control button once again to turn the lights off.



## ⚠️ WARNING

1. For indoor use only.
2. Do not cover this product with any material when in use.
3. Use only AA-size (LR06) batteries in the battery box.
4. Clean the battery contacts prior to battery installation.
5. Batteries are to be inserted with the correct polarity.
6. Do not mix old and new batteries.
7. Do not mix alkaline, standard (carbon-zinc), lithium, or rechargeable (NiCd, NiMH or other type) batteries.
8. Remove batteries from the product when not used for an extended period of time, or when depleted.
9. Dispose of used batteries properly.
10. Non-rechargeable batteries are not to be recharged.
11. Keep small parts and batteries away from children.
12. Do not expose light set to moisture.
13. Never allow any plastic part of this control box to come in contact with any source of heat or flame.
14. Do not dispose of batteries in fire. Batteries may explode or leak.
15. Batteries are not included with this product.
16. Do not mix alkaline, standard (carbon-zinc), or rechargeable batteries. Do not dispose of batteries in fire. Batteries may explode or leak. Do not ingest battery.
17. Batteries must be recycled or disposed of properly. Dispose of as per the requirements of your local municipality.

## USER SERVICE INSTRUCTIONS


### Bulb Replacement

Step 1. Remove the batteries.

Step 2. Release the locking tab. Pull out the bulb together with the lamp base from the holder.



Step 3. Place a new bulb provided (3.6 V / 0.072 W LED type lamps) into the lamp holder and push in to lock. Close the locking tab.



(Image for reference only)

This product carries a one (1) year warranty against defects in workmanship and materials. Trileaf Distribution agrees to replace a defective product, within the stated warranty period, when returned to the place of purchase with proof of purchase. This product is not guaranteed against wear or breakage due to misuse and/or abuse.

Made in China

Imported by:

Trileaf Distribution Trifeuil Toronto, Canada M4S 2B8

## ⚠️ WARNING

**INGESTION HAZARD:**  
This product contains a button cell or coin battery.

## ⚠️ AVERTISSEMENT

**RISQUE D'INGESTION :**  
Cet article contient une pile bouton ou une pile plate.