



## 4 1/2' Crumpit Tree

Product No. 051-5312-6

**Need help? Give us a call!**  
**We're here for you.**



Toll-free:

**1-877-483-6759**

**IMPORTANT:** Please read this manual carefully before beginning assembly of this product. Keep this manual for future reference.


## TREE ASSEMBLY INSTRUCTIONS

Congratulations on purchasing your new tree.


Carefully follow the instructions below to quickly and easily set up your new tree.

1. Before you start to assemble your tree, choose an appropriate location near a wall outlet.
2. First assemble the tree stand and place on a level surface. (See Fig. A.)

**Fig. A — Tree Stand**




### Fig. B — Tree and Light Assembly



**Tree Electrical Rating**  
(for indoor use only)  
Input: AC 120 V, 60 Hz, 0.2 A  
Output: DC 28 V, 0.11 A

- Each tree section is numbered with a tag. Please identify all sections before assembling.
- Assemble the tree from the bottom to the top. Start by inserting the bottom section into the assembled stand. Make sure the pole is firmly inserted and secured into the stand.
- Connect the light strings as per the colour labels indicated in **Fig. B** and insert green labelled plug into the wall outlet. Your entire tree should now be lit.

6. Shape the tree from the bottom to the top. Start with the branches farthest from the pole – fan out as shown in **Fig. C**, and continue until the entire tree is shaped.



7. After shaping the entire tree following the previous step, slightly upsweep all branch tips for a uniform look. Shift branches to fill any gaps. Your Christmas tree is now complete and ready to be decorated.

## STORAGE INSTRUCTIONS

1. Unplug cord from the wall outlet first and then remove all ornaments and decorations.
2. Disassemble the tree from the top to the bottom. Start with the tree top and gently lift straight up to remove from section below and fold all branches toward the pole.
3. In case of difficulty separating the tree pole (trunk), apply a small amount of lubricant at the joint and rotate the upper pole in both directions. Lift up the upper pole again.
4. Continue by gently lifting each section straight up from the section below, and fold all branches toward the pole until the bottom section is removed from the tree stand.
5. Carefully place all tree sections into shipping box and tape it shut.
6. When not in use, please store your tree in a cool, dry place away from sunlight. Exposing your tree to excessive heat or humidity may damage your tree.
7. Keep out of reach of pets and children.

## TROUBLESHOOTING TIPS

### **If the tree does not illuminate / some bulbs do not light or flicker:**

1. Check to make sure that all plugs and poles are properly and firmly connected as indicated in **Fig. B** and assembly instructions.
2. Disconnect from power source, then check for loose, broken or missing light bulbs and replace as needed.

## CAUTION

1. To reduce the risk of fire and electric shock:
  - a) Use only the power supply that was provided with this product;
  - b) Do not install on trees having needles, leaves or branch covering of metal or materials which look like metal; and
  - c) Do not mount or support strings in a manner that can cut or damage wire insulation.
2. Use only the adaptor supplied with this product. Using a different adaptor will damage the lights and may cause fire or electric shock hazards.

## SPARE PARTS

This tree includes spare bulbs.

If extra parts are needed, please contact our customer service centre.

## Warranty

This For LIVING® product carries a one (1) year warranty against defects in workmanship and materials. Trileaf Distribution agrees to replace the defective product free of charge within the stated warranty period, when returned by the original purchaser with proof of purchase. This product is not guaranteed against wear or breakage due to misuse and/or abuse.