

CANVAS^{TM/MC}



RADIANT MAGNETIC LED SPOTLIGHT SET

PRODUCT NO. 052-1722-2

FIRST TIME USE

To turn on, press the ON/OFF switch on the underside of the light. Choose desired brightness level by using the remote control.

The light contains a big magnet inside and 4 pcs small magnet outside on the bottom and can be affixed to any flat, magnetic surface.



OPERATION INSTRUCTIONS

REMOTE CONTROL:

Remove the insulation strip ① before using for the first time.

L1: 50 lm light output with up to 14 hours of working time.

L2: 30 lm light output with up to 21 hours of working time.



L3: 20 lm light output with up to 30 hours of working time.

L4: 10 lm light output with up to 60 hours of working time.

To prevent unintended power loss, the light has a maximum continuous runtime and will turn off automatically after 6 hours. It can be turned on again by using the remote control.

ON/OFF BUTTON


ON/OFF button on the bottom of the light can also be used to control the light. Short press for power on, long press for power off. While spot light is on, short press again to adjust the light's brightness.




IMPORTANT: Please read this manual carefully before beginning assembly of this product. Keep this manual for future reference.

BATTERY

If the battery is depleted, use the Micro USB cable (included) to re-charge. During charging, the light indicator will show red colour. Once fully charged, the light indicator will show green colour.



If the battery can't be charged or if fully charged but does not work as before, replace the battery. Remove screws and replace with same type rechargeable battery (3.7 V 18650, 2000 mAh). See image below.



WARNING

Do not dispose of batteries in the regular trash, municipal waste stream or by fire as batteries may leak or explode. Do not open, short circuit, or mutilate batteries as injury may occur. Preserve our environment by recycling batteries or disposing of them in accordance with local, provincial, and federal regulations. Do not mix old and new batteries. Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel cadmium or nickel metal hydride) batteries.

This product carries a one (1) year warranty against defects in workmanship and materials. CANVAS Canada agrees to replace a defective product, within the stated warranty period, when returned to the place of purchase with proof of purchase. This product is not guaranteed against wear or breakage due to misuse and/or abuse.

CAN ICES-005(B)/NMB-005(B).

Made in China

Imported by Trileaf Distribution Trifeuil Toronto, Canada M4S 2B8

CANVAS™



JEU DE PROJECTEURS À DEL MAGNÉTIQUES RAYONNANTS

N° DE MODÈLE 052-1722-2

PREMIÈRE UTILISATION

Pour allumer, appuyez sur le bouton marche/arrêt sous le luminaire. Choisissez le niveau de luminosité souhaité à l'aide de la télécommande.

Le luminaire contient un grand aimant à l'intérieur et 4 petits aimants à l'extérieur sur le bas. Il peut être fixé à n'importe quelle surface plate magnétique.



CONSIGNES D'UTILISATION

TELECOMMANDE :

Retirez la bande isolante ① avant de l'utiliser pour la première fois.

L1 : 50 lm de sortie lumineuse avec jusqu'à 14 heures de temps de fonctionnement.


L2 : 30 lm de sortie lumineuse avec jusqu'à 21 heures de temps de fonctionnement.

L3 : 20 lm de sortie lumineuse avec jusqu'à 30 heures de temps de fonctionnement.

L4 : 10 lm de sortie lumineuse avec jusqu'à 60 heures de temps de fonctionnement.

Pour éviter toute panne de courant, le luminaire comprend un temps d'exécution continu maximal et s'éteint automatiquement après 6 heures.

Il peut être allumé à nouveau en utilisant la télécommande.



BOUTON MARCHE ②/BOUTON ARRÊT ③


Le bouton marche/arrêt au bas du luminaire peut également être utilisé pour contrôler le luminaire. Appuyez brièvement pour la mise sous tension, appuyez longuement pour éteindre. Pendant que le luminaire est allumé, appuyez à nouveau brièvement pour ajuster la luminosité de la lumière.




IMPORTANT : Veuillez lire attentivement ce guide avant de procéder à l'assemblage de ce produit. Conservez ce guide à titre de référence.

PILE

Si la pile est épuisée, utilisez le câble Micro USB (inclus) pour recharger. Pendant la recharge, le voyant lumineux s'allume en rouge. Une fois complètement rechargé, le voyant lumineux s'allume en vert.



Si la pile ne peut pas être chargée ou si elle est complètement chargée mais ne fonctionne pas comme avant, remplacez la pile. Retirez les vis et remplacez la pile par une pile rechargeable du même type (3,7 V 18650, 2 000 mAh). Consultez l'illustration ci-dessous.



AVERTISSEMENT

Ne jetez pas les piles dans les ordures ménagères, les circuits de traitement de déchets municipaux ou dans le feu, car les piles peuvent fuir ou exploser.

N'ouvrez pas, ne court-circuitez pas, ne modifiez pas les piles, car cela pourrait entraîner des blessures. Veuillez aider à préserver notre environnement en recyclant les piles ou en les éliminant conformément aux réglementations locales, provinciales et fédérales.

Ne mélangez pas des piles neuves avec des piles usagées.

GARANTIE

Cet article comprend une garantie de un (1) an contre les défauts de fabrication et de matériau(x). CANVAS Canada consent à remplacer l'article défectueux sans frais au cours de la période de garantie convenue s'il est retourné au magasin où vous l'avez acheté accompagné de la preuve d'achat. Exclusion : usure ou bris causés par un usage abusif ou inapproprié.

CAN ICES-005(B)/NMB-005(B).

Fabriqué en Chine

Importé par Trileaf Distribution Trifeuil Toronto, Canada M4S 2B8