


CANVAS™

BRIER FIRE POT

PRODUCT NO. 059-7877-4



ASSEMBLY INSTRUCTIONS



HAVING TROUBLE?

TOLL-FREE:

1-888-670-6684

IMPORTANT: Please read this manual carefully before beginning assembly of this product. Keep this manual for future reference.

CANVAS™

INSPIRED BY CANADA



We believe in the power of décor and its ability to make up the fabric of your home.

That's why **CANVAS™** collections draw **inspiration from Canadians and the way they live.**



From on-trend furniture pieces to holiday décor and all your outdoor living essentials, **CANVAS™** makes it easy to refresh your space to reflect **your unique style and the way you live every day.**

We would love to hear from you and welcome your thoughtful feedback. Visit our website at **canadiantire.ca** to tell us about your experience, and share your photos with us using **#myCANVASstyle.**

Show us how you bring **CANVAS™** products to life. We can't wait to see!



TABLE OF CONTENTS

Table of Contents	3
Important Safety Instruction	3
Instructions for Use	4
Caring for Your Item	5
Warranty	5



WARNING! TO REDUCE THE RISK OF SERIOUS INJURY, READ THE FOLLOWING SAFETY INSTRUCTIONS BEFORE ASSEMBLING AND USING THE PRODUCT.

- Use only single-use cans of gel fuel or burner fuel in garden burners. Never use other fuel (lamp oil, petrol, methylated spirits, paraffin, etc.) in the burner due to risk of explosion or serious injury.
- Do not refill canister. Remove used canister and replace with a new one. Clean up any spills immediately.
- Garden burners are to be used outdoors. Consider the area surroundings before lighting the burner. Gel will burn more quickly in windy conditions.
- The garden burner must be placed on a stable, heat-resistant, and non-flammable foundation. Flammable materials and fabrics must be at least 3' (1 m) away from the flames at all times.
- Do not lean over the gel burner while lit.
- Do not put the burner in a location where it can be easily knocked over.
- Keep away from children and pets.
- Do not move burner while lit. Allow burner to completely cool before moving.




WARNING: EXTREME CAUTION

Please read all directions included before use.

- Keep out of reach of children and pets.
- Never touch metal parts while hot.
- Use only single use cans of gel fuel or burner fuel in garden burners.
- Do not add fuel while lit or still hot.
- Keep flammable objects away from flame.
- Never use garden burner to light other objects such as cigarettes.
- Do not smoke gel fuel.
- Never leave unattended while lit or hot.



INSTRUCTIONS FOR USE



STEP 1

Place entire gel fuel can into opening in burner, open lid of gel canister and ignite. Use long matches or a barbeque lighter. Never use short matches or cigarette lighters to light the gel.

STEP 2

To extinguish flame, place snuffer over the entire opening.



CAUTION

- Do not move burner while lit. Allow burner to completely cool before moving.
- Do not leave unattended while burning or hot.
- Do not refill canister. Remove used canister and replace with a new one. Clean up any spills immediately.
- Note: Please refer to gel fuel canister instructions and warnings.
- In the event of accidental gel fuel consumption, call your local poison control centre immediately.
- Keep gel fuel away from eyes.

CARING FOR YOUR ITEM

To clean garden burner, let it cool completely, then soak the unit for 30 minutes in warm soapy water, then rinse. Do not use any abrasive surfaces to clean unit as this may cause damage to the surface.

ASSEMBLY TROUBLESHOOTING



**BEFORE RETURNING
YOUR PRODUCT**

**HAVING TROUBLE?
LET US HELP YOU!**

**TOLL-FREE:
1-888-670-6684**

If you have questions regarding your product or require warranty assistance, please call our customer service helpline.



**CALL US,
WE CAN HELP**

WARRANTY INFORMATION



1-YEAR LIMITED WARRANTY

This CANVAS™ product carries a one (1) year warranty against defects in workmanship and materials. Trileaf Distribution agrees to replace the defective product free of charge within the stated warranty period, when returned by the original purchaser with proof of purchase. This product is not guaranteed against wear or breakage due to misuse and/or abuse.

PRODUCT NO. 059-7877-4

Made in China

Imported by Trileaf Distribution Trifeuil Toronto, Canada M4S 2B8

CANVAS™

INSPIRED BY CANADA

