



Electric Blower

model no. 060-3890-8




Intertek

3084514

Conforms to UL STD 1017

Certified to CAN/CSA STD.

C22.2 No. 147-M90



Toll-free: 1-866-523-5218

IMPORTANT:

Read and follow all safety rules and operating instructions before using this product.

Instruction Manual



model no. 060-3890-8 | contact us: 1.866.523.5218

Specifications	2
Know Your Blower	3
Exploded View	4
Parts List	5
Assembly	6
Operation	8
Maintenance	10
Troubleshooting	11
Symbols	12
Electrical Information	13
Important Safety Instructions	15
General Safety Rules	17
Warranty	18


ELECTRIC BLOWER

Type	Corded
Voltage	120 V~60 Hz
Amp	8 A
Max Air Speed	160 MPH
Max Air Volume	160 CFM 4.5 m ³ /min
Weight	4 lb (1.8 kg)



model no. 060-3890-8 | contact us: 1.866.523.5218

1. ON/OFF switch
2. Blower tube
3. Cord retainer
4. Plug



Know Your Blower


KNOW YOUR BLOWER

The safe use of this product requires an understanding of the information on the tool and in this operator's manual as well as a knowledge of the project you are attempting. Before use of this product, familiarize yourself with all operating features and safety rules.

BLOWER TUBE: The blower tube can be easily installed on the blower without any additional tools.

CORD RETAINER: A convenient cord retainer helps keep the extension cord connection secure during blower operation.

SINGLE SPEED: This blower is equipped with a single-speed motor.





model no. 060-3890-8 | contact us: 1.866.523.5218

Item	Description	QTY
1	Blower tube	1
2	Right motor housing assembly	1
3	Motor assembly	1
4	Wire	1
5	Micro-switch	1
6	Switch button	1
7	Built-in plug	1
8	Left motor housing	1
9	Shaft spacer	1
10	Heat output fan blade	1
11	Fan blade	1
12	Pressure pad	3
13	Nut	1



model no. 060-3890-8 | contact us: 1.866.523.5218

UNPACKING

This product requires assembly.

- Carefully remove the product and any accessories from the box. Make sure that all items listed in the packing list are included.
- Inspect the product carefully to make sure no breakage or damage occurred during shipping.
- Do not discard the packing material until you have carefully inspected and satisfactorily operated the product.
- If any parts are damaged or missing, please call customer service for assistance.

PACKING LIST

Blower
Blower Tube
Operator's Manual



WARNING: Do not use this product if any parts on the Packing List are already attached to your product when you unpack it. Parts on this list are not attached to the product by the manufacturer and require customer installation. Use of a product that may have been improperly assembled could result in serious personal injury.




model no. 060-3890-8 | contact us: 1.866.523.5218

ASSEMBLING THE BLOWER TUBE

Slide blower tube forward until the lock button clicks into the top of the tube.

1. Air outlet
2. Lock button
3. Blower tube



Assembly



WARNING: If any parts are damaged or missing do not operate this product until the parts are replaced. Use of this product with damaged or missing parts could result in serious personal injury.



WARNING: Do not attempt to modify this product or create accessories not recommended for use with this product. Any such alteration or modification is misuse and could result in a hazardous condition leading to possible serious personal injury.





WARNING: Do not connect to power supply until assembly is complete. Failure to comply could result in accidental starting and possible serious personal injury.

APPLICATIONS

You may use this product for the purposes listed below:

- Clearing leaves and other yard debris from your lawn.
- Keeping decks, patios, garages and driveways free from leaves, pine needles and other debris.

STARTING/STOPPING THE BLOWER



1. Cord retainer
2. Loop
3. Plug
4. Extension cord

- Attach the outlet end of an extension cord to the plug on the rear of the blower.

NOTE: Use only an approved outdoor extension cord as described previously in this manual.

- Route the extension cord through the side of the loop located on the rear of the blower housing and place underneath the cord retainer.
- To start the blower, move the power switch to the **ON** position.
- To stop the blower, move the power switch to the **OFF** position.



model no. 060-3890-8 | contact us: 1.866.523.5218

OPERATING THE BLOWER

- To keep from scattering debris, blow around the outer edges of a debris pile. Never blow directly into the centre of a pile.
- To reduce sound levels, limit the number of pieces of equipment used at any one time.
- Use rakes and brooms to loosen debris before blowing. In dusty conditions, slightly dampen surfaces if water is available.
- Watch out for children, pets, open windows, or freshly washed cars, and blow debris safely away.
- Hold the blower with the handle in your right hand.
- Operate power equipment at reasonable hours only — not early in the morning or late at night when people might be disturbed. Comply with the times listed in local ordinances.
- After using blowers or other equipment, CLEAN UP! Dispose of debris properly.



Operation



WARNING: Do not allow familiarity with products to make you careless. Remember that a careless fraction of a second is sufficient to inflict serious injury.



WARNING: Always wear eye protection with side shields marked to comply with ANSI Z87.1, along with hearing protection. Failure to do so could result in objects being thrown into your eyes, resulting in possible serious injury.



WARNING: Do not use any attachments or accessories not recommended by the manufacturer of this product. The use of attachments or accessories not recommended can result in serious personal injury.



model no. 060-3890-8 | contact us: 1.866.523.5218

GENERAL MAINTENANCE

Avoid using solvents when cleaning plastic parts. Most plastics are susceptible to damage from various types of commercial solvents and may be damaged by their use. Use clean cloths to remove dirt, dust, oil, grease, etc.

STORAGE (1 MONTH OR LONGER)

- Clean all foreign materials from the blower.
- Store indoors in a place that is out of reach of children. Keep away from corrosive agents such as garden chemicals and de-icing salts.



WARNING: When servicing, use only identical replacement parts. Use of any other parts may create a hazard or cause product damage.



WARNING: Always wear eye protection with side shields marked to comply with ANSI Z87.1, along with hearing protection. Failure to do so could result in objects being thrown into your eyes, resulting in possible serious injury.



WARNING: Before inspecting, cleaning or servicing the machine, unplug the power cord and wait for all moving parts to stop. Failure to follow these instructions can result in serious personal injury or property damage.



model no. 060-3890-8 | contact us: 1.866.523.5218

PROBLEM	CAUSE	REMEDY
Motor fails to start when switch is turned on.	Power cord is not plugged in or connection is loose. Household circuit breaker is tripped.	Plug in the power cord. Check circuit breaker.



WARNING: Do not, at any time, let brake fluids, gasoline, petroleum-based products, penetrating oils, etc., come into contact with plastic parts. Chemicals can damage, weaken or destroy plastic, which may result in serious personal injury.



Some of the following symbols may be used on this product. Please study them and learn their meaning. Proper interpretation of these symbols will allow you to operate the product effectively and safely.

Symbol	Name	Designation/Explanation
V	Volts	Voltage
A	Amperes	Current
Hz	Hertz	Frequency (cycles per second)
W	Watts	Power
min	Minutes	Time
	Alternating Current	Type of current
	Direct Current	Type or a characteristic of current
	Class II Construction	Double-insulated construction
	Wet Conditions Alert	Do not expose to rain or use in damp locations.
	Read the Operator's Manual	To reduce the risk of injury, user must read and understand operator's manual before using this product.
	Eye and Hearing Protection	Wear eye and hearing protection when operating this equipment.
	Safety Alert	Precautions that involve your safety.

Symbol	Name	Designation/Explanation
	Long Hair	Failure to keep long hair away from the air inlet could result in personal injury.
	Loose Clothing	Failure to keep loose clothing from being drawn into air intake could result in personal injury.
	Keep Bystanders Away	Keep all bystanders at least 50' (15 m) away.
	Blower Tubes	Do not operate without tubes in place.



model no. 060-3890-8 | contact us: 1.866.523.5218

DOUBLE INSULATION

Double insulation is a concept in safety in electric power tools, that eliminates the need for the usual three-wire grounded power cord. All exposed metal parts are isolated from the internal metal motor components with protecting insulation. Double-insulated tools do not need to be grounded.

NOTE: Servicing of a product with double insulation requires extreme care and knowledge of the system and should be performed only by a qualified service technician. For service, we suggest you return the tool to your nearest authorized service centre for repair. Always demand that original factory replacement parts be used when servicing.

ELECTRICAL CONNECTION

This product has a precision-built electric motor. It should be connected to a **power supply that is 120 V, AC only (normal household current), 60 Hz**. Do not operate this product on direct current (DC). A substantial voltage drop will cause a loss of power and the motor will overheat. If your product does not operate when plugged into an outlet, double-check the power supply.

GFCI

Ground Fault Circuit Interrupter (GFCI) protection should be provided on the circuit(s) or outlet(s) to be used for the product. Receptacles are available having built-in GFCI protection and may be used for this measure of safety.

GUIDELINES FOR USING EXTENSION CORDS

USE THE PROPER EXTENSION CORD. Make sure your extension cord is in good condition. When using an extension cord, be sure to use one heavy enough to carry the current your product will draw. An undersized cord will cause overheating. The table below shows the correct size to use depending on cord length and nameplate ampere rating. If in doubt, use the next heavier gauge. The smaller the gauge number, the heavier the cord.



WARNING: The double-insulated system is intended to protect the user from shock resulting from a break in the tool's internal insulation. Observe all normal safety precautions to avoid electrical shock.



Minimum Gauge for Extension Cords (AWG)
(when using 120 V only)

Ampere Rating		Total Length of Cord in Feet (metres)			
More Than	Not More Than	25' (7.6 m)	50' (15 m)	100' (30.4 m)	150' (45.7 m)
0	6	18	16	16	14
6	10	18	16	14	12
10	12	16	16	14	12
12	16	14	12	Not Recommended	

Make sure your extension cord is properly wired and in good electrical condition. Always replace a damaged extension cord or have it repaired by a qualified person before use. Keep extension cords away from sharp objects, excessive heat and damp or wet areas. Use a separate electrical circuit for your tools. This circuit should comprise a wire of at least 12 gauge and should be protected with a 15 A time-delayed fuse. Before connecting the motor to the power line, make sure the switch is in the OFF position and the electric current is identical to that stamped on the motor nameplate. Running at a lower voltage will damage the motor.



WARNING: Although this tool is double insulated, the extension cord and receptacle must still be grounded while in use to protect the operator from electric shock.



WARNING: Check extension cords before each use. If damaged, replace immediately. Never use product with a damaged cord. Touching the damaged area could cause electric shock, resulting in serious injury.



model no. 060-3890-8 | contact us: 1.866.523.5218

READ THESE INSTRUCTIONS BEFORE USING THIS BLOWER

- Do not operate power tools in explosive atmospheres, such as in the presence of flammable liquids, gases, or dust. Power tools create sparks that can ignite the dust or fumes.
- To reduce the risk of electric shock, this tool has a polarized plug (one blade is wider than the other) and will require the use of a polarized extension cord. The plug will fit into a polarized extension cord only one way. If the plug does not fit fully into the extension cord, reverse the plug. If the plug still does not fit, obtain a correctly polarized extension cord. A polarized extension cord will require the use of a polarized wall outlet. This plug will fit into the polarized wall outlet only one way. If the plug does not fit fully into the wall outlet, reverse the plug. If the plug still does not fit, contact a qualified electrician to install the proper wall outlet. Do not change the equipment plug, extension cord receptacle, or extension cord plug in any way.
- Avoid body contact with grounded surfaces such as pipes, radiators, ranges, and refrigerators. There is an increased risk of electric shock if your body is grounded.
- Don't expose power tools to rain or wet conditions. Water entering a power tool will increase the risk of electric shock.
- Do not handle plug or tool with wet hands.
- Use outdoor extension cords marked W-A, W, SW-A, SOW-A, STW-A, STOW-A, SJW-A, SJTW-A, or SJTOW-A. These cords are rated for outdoor use and reduce the risk of electric shock.
- Never allow children to operate the equipment. Never allow adults to operate the equipment without proper instruction.
- Wear eye protection with side shields marked to comply with ANSI Z87.1, as well as hearing protection, when operating this product.
- Always use face or dust mask if operation is dusty.
- Use extra care when cleaning on stairs.
- Do not leave appliance plugged in. Unplug from outlet when not in use and before servicing.
- Do not expose to rain. Store indoors.
- Use only as described in this manual. Use only manufacturer's recommended attachments.
- Keep hair, loose clothing, fingers and all body parts away from openings and moving parts.
- Wear heavy, long pants, long sleeves, boots and gloves. Avoid loose garments or jewellery that could get caught in moving parts of the machine or its motor.



WARNING: READ AND UNDERSTAND ALL INSTRUCTIONS. Failure to follow all instructions listed below may result in electric shock, fire, and/or serious personal injury.



model no. 060-3890-8 | contact us: 1.866.523.5218

Important Safety Instructions

- Do not force tool. Use the correct tool for your application. The correct tool will do the job better and safer at the rate for which it is designed.
- Do not operate the equipment while barefoot or when wearing sandals or similar lightweight footwear. Wear protective footwear that will protect your feet and improve your footing on slippery surfaces.
- Do not use on steps, a ladder, rooftop, tree or other unstable support. Stable footing on a solid surface enables better control of the blower in unexpected situations.
- Secure long hair so it is above shoulder level to prevent entanglement in any moving parts.
- Keep firm footing and balance. Do not overreach. Overreaching can result in loss of balance.
- Turn off all controls before unplugging.
- Do not allow this tool to be used as a toy. Close attention is necessary when used by or near children.
- Avoid accidental starting. Be sure the power switch is not on before plugging in. Turn off power switch before unplugging.
- Do not use tool if switch does not turn it on or off. Any tool that cannot be controlled with the switch is dangerous and must be repaired.
- Do not use with damaged plug. If tool is not working as it should or has been dropped, damaged, left outdoors, or dropped into water, return it to an authorized service centre.
- Do not leave the tool when plugged in. Unplug from the power outlet when not in use, before servicing, and before storing the tool. Such preventative safety measures reduce the risk of starting the tool accidentally.
- Keep all bystanders, children and pets at least 50' (15 m) away.
- Do not operate this tool when you are tired, ill, upset or under the influence of alcohol, drugs, or medication.
- Do not operate in poor lighting.
- Keep all parts of your body away from any moving parts and all hot surfaces of the tool.
- Do not put any object into openings. Do not use with any opening blocked. Keep openings free of dust, lint, hair and anything that may reduce airflow.
- Check the work area before each use. Remove all objects that can be thrown or become entangled in the machine, such as rocks, broken glass, nails, wire or string.
- Never use blower near fires, fireplaces, hot ashes, barbecue pits, etc., which may cause fire to spread.
- Do not pull or carry by cord, use cord as a handle, close a door on a cord, or pull cord around sharp edges or corners. Do not run appliance over cord. Keep cord away from heated surfaces.
- Do not unplug by pulling on cord. To unplug, grasp the plug, not the cord.
- Do not handle plug or appliance with wet hands.
- Use only identical manufacturer's replacement parts and accessories. Use of any other parts may create a hazard or cause product damage.
- In a double-insulated appliance, two systems of insulation are provided instead of grounding. No grounding means is provided on a double-insulated appliance, nor should a means for grounding be added to the appliance. Servicing a double-insulated appliance requires extreme care and knowledge of the system and should be done only by qualified a service person. Replacement parts for a double-insulated appliance must be identical to the parts they replace.
- For household use only.



model no. 060-3890-8 | contact us: 1.866.523.5218

- Make sure your extension cord is in good condition. When using an extension cord, be sure to use one heavy enough to carry the current your product will draw. A wire gauge size (A.W.G.) of at least 14 is recommended for an extension cord 50' (15 m) or less in length. If in doubt, use the next heavier gauge. The smaller the gauge number, the heavier the cord. An undersized cord will cause a drop in line voltage, resulting in loss of power and overheating.
- Do not point the blower nozzle in the direction of people or pets.
- Never place blower on any surface, except a hard, clean surface, when motor is running. Gravel, sand and other debris can be picked up by the air inlet and thrown at the operator or bystanders, causing possible serious injuries.
- Never run the unit without the proper equipment attached. Always ensure the blower tubes are installed.
- When not in use, blower should be stored indoors in a dry, locked place—out of the reach of children.
- Maintain tool with care. Keep fan area clean for best and safest performance. Follow instructions for proper maintenance.
- Do not attempt to clear clogs from tool without first unplugging it.
- Do not pull or carry by cord, use cord as a handle, or pull cord around sharp edges or corners. Keep cord away from heated surfaces.
- Do not unplug by pulling on cord. To unplug, grasp the plug, not the cord.
- To reduce the risk of electric shock, do not expose to rain, do not use on wet surfaces. Store indoors.
- If the power supply cord is damaged, it must be replaced only by the manufacturer or by an authorized service centre to avoid risk.
- Protect your lungs. Wear a face or dust mask if the operation is dusty. Following this rule will reduce the risk of serious personal injury.
- Save these instructions. Refer to them frequently and use them to instruct others who may use this power tool. If you lend someone this power tool, lend these instructions also.



model no. 060-3890-8 | contact us: 1.866.523.5218

TWO-YEAR LIMITED WARRANTY

For TWO YEARS from the date of purchase within Canada, YARDWORKS CANADA will, at its option, repair or replace for the original purchaser, free of charge, any part or parts found to be defective in material or workmanship.

This warranty does not cover:

1. Any part that has become inoperative due to misuse, commercial use, abuse, neglect, accident, improper maintenance, or alteration; or
2. The unit, if it has not been operated and/or maintained in accordance with the owner's manual; or
3. Normal wear, except as noted below;
4. Routine maintenance items such as lubricants, blade sharpening;
5. Normal deterioration of the exterior finish due to use or exposure.

Full 120-Day Warranty on Normal Wear Parts:

Normal wear parts are defined as blade adaptors, blades, grass bags and tires. These parts are warranted to the original purchaser to be free from defects in material and workmanship for a period of 120 days from the date of retail purchase.

How to Obtain Service:

Warranty service is available by calling the toll-free helpline, at 1-866-523-5218. The factory will not accept the return of a complete unit unless prior written permission has been extended by YARDWORKS CANADA.

Transportation Charges:

Transportation charges for the movement of any power equipment unit or attachment are the responsibility of the purchaser. The purchaser must pay transportation charges for any part submitted for replacement under this warranty unless such return is requested in writing by YARDWORKS CANADA.

Other Warranties:

All other warranties, express or implied, including any implied warranty of merchantability, is limited in its duration to that set forth in this express limited warranty. The provisions as set forth in this warranty provide the sole and exclusive remedy of YARDWORKS CANADA obligations arising from the sale of its products.

YARDWORKS CANADA will not be liable for incidental or consequential loss or damage.

Made in China. Imported by YardWorks Canada.
Toronto, Canada M4S 2B8