

RESIN RACK



NEED HELP WITH ASSEMBLY OR MISSING PARTS?

DO NOT RETURN TO STORE CALL US AT: 1-800-661-6721

SAFETY GUIDELINES

Read and understand the owner's manual before assembly. It contains important safety information as well as instructions for operating and maintaining the product.

IMPORTANT! RETAIN INSTRUCTIONS FOR FUTURE REFERENCE AND READ CAREFULLY.

WARNING


To reduce the risk of serious injury, read the following safety instructions before assembling and using the product.

- This product is intended for domestic use only.
- This product should be positioned on a level surface.
- Any assembly or maintenance of the product should be carried out by adults only.
- Arrange for necessary labour when assembling and moving the shelf.
- Use a slightly damp cloth and mild soap to clean the shelf.
- Do not stand or climb on the shelving for any reason.

Serious or fatal injuries can occur from the product tipping over. To prevent the unit from tipping over, it must be permanently attached to the wall. Depending on the type of wall, different types of anchors and screws may be required. Weight should be evenly distributed on each shelf. Load the shelving unit from the bottom shelf up. Heavier items should be stored on the lower shelves.

Do not exceed the following weight limits for the product:

- Maximum load for each shelf: 150 lb (68 kg)
- Maximum load for the unit: 750 lb (340 kg)



ÉTAGÈRE EN RÉSINE



BESOIN D'AIDE POUR L'ASSEMBLAGE OU POUR DES PIÈCES MANQUANTES?

NE RETOURNEZ PAS AU MAGASIN TÉLÉPHONEZ-NOUS AU : 1 800 661-6721

CONSIGNES DE SÉCURITÉ

Veillez lire et bien comprendre le guide d'utilisation avant de procéder à l'assemblage; il contient des renseignements importants en matière de sécurité ainsi que des directives d'utilisation et d'entretien du produit.

IMPORTANT : À LIRE ATTENTIVEMENT ET À CONSERVER.

MISE EN GARDE

Pour réduire les risques de blessures, veuillez lire les directives de sécurité ci-dessous avant d'assembler et d'utiliser le produit.

- Ce produit est destiné à un usage domestique seulement.
- Ce produit doit être placé sur une surface plane et de niveau.
- L'assemblage et l'entretien de ce produit doivent être faits par des adultes seulement.
- Prévoyez un nombre suffisant de personnes pour l'assemblage et le déplacement de l'étagère.
- Utilisez un chiffon humide et du savon doux pour nettoyer l'étagère.
- Ne montez pas ni ne grimpez sur l'étagère, pour quelque raison que ce soit.

Des blessures graves ou mortelles peuvent survenir en cas de basculement. Pour prévenir ce risque, l'étagère doit être fixée au mur adjacent de façon permanente. Veuillez utiliser des vis et pièces d'ancrage qui conviennent au type de mur. Le poids doit être également distribué sur chaque tablette. Chargez d'abord les tablettes du bas, puis celles du haut; les articles plus lourds doivent être placés sur les tablettes inférieures.

Ne pas dépasser les limites de poids suivantes :

- Charge maximale pour chaque tablette : 68 kg (150 lb)
- Charge maximale pour l'étagère entière : 340 kg (750 lb)

DANGER

CRUSH HAZARD

TO AVOID TIP-OVER, THIS EQUIPMENT MUST BE SECURELY ANCHORED.



DANGER


RISQUE D'ÉCRASEMENT

POUR ÉVITER LE RENVERSEMENT, CETTE ÉTAGÈRE DOIT ÊTRE FIXÉE AU MUR.

PARTS LIST

1. Top Cap		x 4
2. Foot Cap		x 4
3. Pole		x 16
4. Shelf		x 5
5. Wall Bracket		x 2 (screws and anchors not included)

If any parts are missing or damaged, or if you have any questions concerning assembly or use, we are here to help. Before returning the product to store, please contact our customer service advisors toll free at 1-800-689-9928.



LISTE DES PIÈCES

1. Embout de haut		x 4
2. Embout de pied		x 4
3. Poteau		x 16
4. Tablette		x 5
5. Support mural		x 2 (vis et pièces d'ancrage non comprises)

S'il manque des pièces ou si certaines sont endommagées, ou si vous avez des questions concernant l'assemblage ou l'utilisation du produit, nous sommes là pour vous aider. Avant de retourner le produit où il a été acheté, communiquez avec un conseiller de notre service à la clientèle au numéro sans frais le 1 800 661-6721 ou par courriel à service@accenthome.com.

BEFORE YOU BEGIN FOR QUICK AND EASY 3D ASSEMBLY INSTRUCTIONS

DOWNLOAD THE FREE APP



SCAN FOR BILT® 3D INSTRUCTIONS



SCANNÉ POUR LES INSTRUCTIONS 3D PAR BILT®

AVANT DE COMMENCER

POUR DES INSTRUCTIONS D'ASSEMBLAGE 3D FACILES ET RAPIDES

TÉLÉCHARGER L'APPLICATION GRATUITE




ASSEMBLY

PRÉPARATION:

Assembly of the product should be done on a clean and level surface. Remove all items from their packaging and ensure that you have all of the parts listed or required.


STEP 1:

Slide one pole through each of the corners on the first shelf. Push firmly until they engage. Turn the partially assembled shelf on its side and insert a foot cap into the base of each of the four poles. Return the unit so it is right-side up and its feet are touching the ground.



STEP 2:

Take the next shelf and guide the poles from the partially assembled unit through the corners. Push the shelf firmly and evenly into place. Slide a new pole through each of the corners of the shelf into the top of the poles of the partially assembled unit. Repeat this step for the rest of the shelves.




STEP 3:

When the assembly of the product is complete, insert the four top caps included into the top of each pole.

STEP 4:

Position the product in the desired location, on a level surface and against the wall where it will be permanently attached. Secure one wall bracket around each of the rear poles beneath the top shelf. If there is any space between the shelving unit and the wall, use shims to ensure the product is horizontal and level once it is attached to the wall.

NOTE: Two screws are required for each wall bracket. If attaching to drywall, secure the brackets to wooden studs. For brick or cement, appropriate anchors are recommended to ensure the screws stay securely fastened. Depending on the type of wall, different types of screws and anchors may be required. For that reason, no screws are included.



ASSEMBLAGE

PRÉPARATION :

L'assemblage de ce produit doit être fait sur une surface propre et de niveau. Retirez toutes les pièces de l'emballage et vérifiez qu'il n'en manque aucune.

ÉTAPE 1 :

Insérez un poteau dans chacun des quatre coins de la première tablette. Pressez fermement afin de bien fixer les quatre poteaux en place. Tournez l'étagère partiellement assemblée sur le côté et insérez un embout de pied à la base de chaque poteau, puis remettez l'étagère debout.

ÉTAPE 2 :

Prenez la deuxième tablette et disposez-la de sorte que les poteaux de l'étagère partiellement assemblée s'insèrent dans les quatre coins de la tablette. Appuyez fermement sur la tablette afin qu'elle soit bien droite. Insérez quatre autres poteaux dans l'étagère partiellement assemblée. Répétez cette étape pour les autres tablettes.

ÉTAPE 3 :

Une fois l'étagère assemblée, insérez un embout à l'extrémité de chacun des poteaux.

ÉTAPE 4 :

Placez l'étagère à l'endroit voulu, sur un plancher de niveau et contre le mur auquel elle sera fixée de façon permanente. Installez un support mural autour de chacun des deux poteaux arrière, sous la tablette supérieure. S'il y a un espace entre l'étagère et le mur, utilisez des cales pour assurer que l'étagère sera bien à l'horizontale et de niveau lorsqu'elle sera fixée au mur.

REMARQUE : Deux vis sont requises pour chaque support mural. Si le mur est fait de cloisons sèches, il est recommandé de fixer les supports à des montants en bois. S'il est en briques ou en ciment, des pièces d'ancrage appropriées sont recommandées pour assurer que les vis restent en place. Les vis et ancrages doivent correspondre au type de mur, voilà pourquoi les vis ne sont pas fournies.

WARRANTY

This product carries a one (1) year warranty against defects in workmanship and materials. At its discretion, Trileaf Distribution agrees to have any defective part(s) repaired or replaced free of charge, within the stated warranty period, when returned by the original purchaser with proof of purchase. This product is not guaranteed against wear or breakage due to misuse and/or abuse.

MADE IN CANADA WITH DOMESTIC AND IMPORTED MATERIALS

Mastercraft Canada Toronto, Canada M4S 2B8

GARANTIE

Cet article comprend une garantie d'un (1) an contre les défauts de fabrication et de matériaux. Distribution Triféuil consent, à sa discrétion, à réparer ou remplacer gratuitement toute pièce défectueuse lorsque celle-ci est retournée avec la preuve d'achat par l'acheteur original, au cours de la période de garantie convenue. Exclusion : usure ou bris causés par un usage abusif ou inapproprié.

FABRIQUÉ AU CANADA AVEC DES PIÈCES CANADIENNES ET IMPORTÉES

Mastercraft Canada Toronto, Canada M4S 2B8