


# CANVAS<sup>TM/MC</sup>

## CAMDEN STORAGE CABINET

---

MODEL NO. 068-9592-6



### ASSEMBLY INSTRUCTIONS



**HAVING TROUBLE?**

**TOLL-FREE:**

**1-888-670-6684**

IMPORTANT: Please read this manual carefully before beginning assembly of this product. Keep this manual for future reference.

# CANVAS™

INSPIRED BY CANADA



We believe in the power of décor and its ability to make up the fabric of your home.

That's why **CANVAS™** collections draw **inspiration from Canadians and the way they live.**

From on-trend furniture pieces to holiday décor and all your outdoor living essentials, **CANVAS™** makes it easy to refresh your space to reflect **your unique style and the way you live every day.**

We would love to hear from you and welcome your thoughtful feedback. Visit our website at **canadiantire.ca** to tell us about your experience, and share your photos with us using **#myCANVASstyle.**

Show us how you bring **CANVAS™** products to life. We can't wait to see!

## TABLE OF CONTENTS



Parts List .....	4
Before You Begin Assembly .....	9
Step-by-step Guide .....	10
Technical Data .....	24
Caring for Your Item .....	25
Warranty .....	25




**WARNING! TO REDUCE THE RISK OF SERIOUS INJURY, READ THE FOLLOWING SAFETY INSTRUCTIONS BEFORE ASSEMBLING AND USING THE PRODUCT.**

- Please read and understand this entire manual before attempting to assemble, operate, or install the product.
- Follow all warning labels.
- Any assembly or maintenance of the product must be carried out by adults only.
- Some parts may contain sharp edges. Wear protective gloves if necessary.
- To prevent damage, place all parts on a level surface during assembly. Add a layer of protective surface if needed.
- Due to the nature of steel, surface oxidation (rusting) will occur if this protective coating is scratched. This is a natural process. To minimize this condition, it is recommended that care be taken when assembling and handling the product in order to prevent the paint from being scratched.

## TOOLS REQUIRED



















**NOTE:** Do not over-drill.  
Be aware of over-drilling.









No. 2 Cross-head screwdriver  
Tip shown actual size.

2 people


## PARTS LIST

ITEM	DESCRIPTION	THUMBNAIL	QUANTITY
1	Top		1
2	Left side panel		1
3	Right side panel		1
4	Bottom panel		1
5	Fixed shelf		1
6	Fixed shelf		1
7	Middle partition		1
8	Top apron		1
9	Long lower rail		2
10	Short lower rail		2
11	Feet		4
12	Drawer front		2
13	Left drawer side		2
14	Right drawer side		2
15	Drawer back		2
16	Drawer bottom		2

## PARTS LIST

















ITEM	DESCRIPTION	THUMBNAIL	QUANTITY
17	Adjustable shelf		2
18	Left back panel		1
19	Right back panel		1
20	Left door		1
21	Right door		1
22	Plastic clip		1

## EXPLODED PARTS










Warning: Before assembly, please check all accessories in the hardware box, and ensure no parts are missing.

## HARDWARE LIST

ITEM	DESCRIPTION	THUMBNAIL	QUANTITY
A	Cam bolt		38
B	Cam lock		38
C	Wood dowels		32
D	Screw		8
E	Screw		6
F	Magnetic catch		4
G	Metal plate		4
H	Screw		25
I	Handle		2
J	Handle bolt		4
K	Left extension rail		2
L	Right extension rail		2
M	Right extension slide		2
N	Right extension slide		2
O	Screw		28
P	Screw		8

## HARDWARE LIST

ITEM	DESCRIPTION	THUMBNAIL	QUANTITY
<b>Q</b>	Hinge		6
<b>R</b>	Screw		36
<b>S</b>	Shelf support		8
<b>T</b>	Screw		4
<b>U</b>	Anti-tip bracket		1
<b>V</b>	Wall anchor		1
<b>W</b>	Screw		1



## BEFORE YOU BEGIN ASSEMBLY


### MAKE SURE ALL PARTS ARE PRESENT

Compare all pieces to the parts and hardware lists, and make sure you have all tools required for assembly.




### ASSEMBLE IN A CLEARED AREA

Place all parts from the box on the floor in front of you on a clean, dry, level surface to protect the product as it is being built.




### REMOVE PACKAGING MATERIALS

Place packing materials back in the box. Do not dispose of packing materials until assembly is complete.










### READ EACH STEP CAREFULLY

Make sure you understand each step. If you have any questions, contact CANVAS™ customer service at 1-888-670-6684 (toll free).




## STEP-BY-STEP GUIDE

### STEP 1





<b>12</b> x2	<b>4</b> x1	<b>9</b> x2	<b>10</b> x2	<b>11</b> x4	<b>A</b> x20	<b>C</b> x8
						

Insert twenty cam bolts **A** into the bottom panel **4**, feet **11** and drawer fronts **12**. Insert eight wood dowels **C** into the long lower rails **9** and short lower rails **10**. Tighten all cam bolts.



## STEP-BY-STEP GUIDE

### STEP 2


<b>11</b> x4	<b>A</b> x4	<b>B</b> x12	<b>E</b> x4
			

Attach the feet **11** to the long lower rails **9** and short lower rails **10** as shown. Insert eight cam locks **B** into the long lower rails **9** and short lower rails **10**. Tighten all cam locks.

Attach the bottom **4** to the long lower rails **9**, short lower rails **10** and feet **11**. Insert four cam bolts **A** into the long lower rails **9** and tighten.








Flip the base over and insert four cam bolts **A** and four screws **E** into the bottom **4** surface.

Tighten all cam bolts and screws.



## STEP-BY-STEP GUIDE

### STEP 3


<b>2</b> x1	<b>3</b> x1	<b>7</b> x1	<b>A</b> x12	<b>K</b> x2	<b>L</b> x2	<b>O</b> x16
						

Insert twelve cam bolts **A** into the left side panel **2** and right side panel **3**.

Insert eight screws **O** through the left extension rail **K** into the left side panel **2** and the right side of the middle partition **7**.









Insert eight screws **O** through the right extension rail **L** into the right side panel **3** and the left side of the middle partition **7**.

Tighten all cam bolts and screws.



## STEP-BY-STEP GUIDE

### STEP 4

<b>5</b> x1	<b>6</b> x1	<b>7</b> x1	<b>A</b> x2	<b>B</b> x2	<b>C</b> x2	<b>D</b> x8	<b>F</b> x4
							

Insert two cam bolts **A** and two wood dowels **C** into the fixed shelf **6**.


Tighten both cam bolts.

Attach the middle partition **7** to the fixed shelf **6**.

Insert two cam locks **B** into the middle partition **7**.





Insert eight screws **F** through the magnetic catch **F** into the bottom **4** and fixed shelf **5**.

Tighten all cam locks and screws.




## STEP-BY-STEP GUIDE

### STEP 5

<b>1</b> x1	<b>8</b> x1	<b>B</b> x6	<b>C</b> x8
			

Insert eight wood dowels **C** into the top **1**, top apron **8**, fixed shelf **5** and fixed shelf **6**.

Attach the left side panel **2** to the top **1**, top apron **8**, fixed shelf **5** and fixed shelf **6**. Insert six cam locks into the top **1**, fixed shelf **5** and fixed shelf **6**. Tighten all cam locks.



Proper orientation of cam lock.

## STEP-BY-STEP GUIDE

### STEP 6

**B x6**



**C x8**





Insert eight wood dowels **C** into the top **1**, top apron **8**, fixed shelf **5** and fixed shelf **6**.

Attach the right side panel **3** to the top **1**, top apron **8**, fixed shelf **5** and fixed shelf **6**.

Insert six cam locks into the top **1**, fixed shelf **5** and fixed shelf **6**.


Tighten all cam locks.



Proper orientation of cam lock.

## STEP-BY-STEP GUIDE

### STEP 7





Insert six wood dowels **C** into the left side panel **2**, right side panel **3** and middle partition **7**.

Attach the bottom **4** to the left side panel **2**, right side panel **3** and middle partition **7**.

Insert six cam locks **B** into the left side panel **2**, right side panel **3** and middle partition **7**.

Tighten all cam locks.







Proper orientation of cam lock.



## STEP-BY-STEP GUIDE

### STEP 8

<b>18</b> x1	<b>19</b> x1	<b>22</b> x1	<b>R</b> x36
			

Slide plastic clip **22** between left back panel **18** and right back panel **19**. Attach the left back panel **18**, right back panel **19** and plastic clip **22** to the back of cabinet as shown.

Insert thirty-six screws **R** through the left back panel **18** and right back panel **19** into the top **1**, left side panel **2**, right side panel **3**, bottom **4**, fixed shelf **5** and fixed shelf **6**.


Tighten all screws.



**Warning!**











Please make sure that the backs are attached securely. All screws must be driven into the parts straight and tightened firmly. Failure to do so could cause instability, product collapse, and/or serious injury.

Before attaching the back panel, be sure that the unit is at 90°.




## STEP-BY-STEP GUIDE

### STEP 9


<b>12</b> x2	<b>13</b> x2	<b>14</b> x2	<b>15</b> x2	<b>16</b> x2	<b>B</b> x8	<b>P</b> x8
						
<b>M</b> x2	<b>N</b> x2	<b>O</b> x12				
						

Attach the left drawer sides **13** and right drawer sides **14** to the drawer fronts **12**. Insert eight cam locks **B** into the left drawer sides **13** and right drawer sides **14**. Insert the drawer bottom **16** into the groove around the bottom of the drawer fronts **12**, left drawer sides **13** and right drawer sides **14**. Insert eight screws **P** through the left drawer sides **13** and right drawer sides **14** into the drawer back **15**. Insert six screws **O** through the rails **M** into the left drawer sides **13**. Insert six screws **O** through the rails **N** into the right drawer sides **14**. Tighten all cam locks and screws.



## STEP-BY-STEP GUIDE



### STEP 10



Insert eight shelf supports **S** into the left side panel **2**, right side panel **3** and middle partition **7**.

Insert drawers into the cabinet by lining up the rails on the drawers with the rail on the cabinet.









Place the adjustable shelves **17** on the shelf supports **S** according to your needs.



If you want to use the flat side of shelves, please assemble as per option 1.  
If you want slats spaced for bottle storage, please assemble as per option 2.

## STEP-BY-STEP GUIDE

### STEP 11


<b>20</b> x1	<b>21</b> x1	<b>G</b> x4	<b>H</b> x12	<b>I</b> x2	<b>J</b> x4	<b>Q</b> x6	<b>T</b> x4
							

Insert four screws **T** through the metal plates **G** into the left door **20** and right door **21**.

Insert four handle bolts **J** through the left door **20** and right door **21** into the handles **I**.

Insert twelve screws **H** through the hinges **Q** into the left door **20** and right door **21**.

Tighten all bolts and screws.




## STEP-BY-STEP GUIDE

### STEP 12

**H** x12





Fasten the hinges to the left side panel **2** and right side panel **3**.  
Insert twelve screws **H** through the hinges **Q** into the left side panel **2** and right side panel **3**.  
Tighten all screws.



## STEP-BY-STEP GUIDE

### STEP 13

Adjust the screws and doors as shown to make sure the door can be opened and closed perfectly.



**To adjust the vertical height:**





Loosen screws "A" and adjust door. Tighten screws "A".

**To adjust sideways:**


Loosen screws "B" and adjust door. Tighten screws "B".

## STEP-BY-STEP GUIDE

### STEP 14

H x1	U x1	V x1	W x1
			

Insert one screw **H** through the anti-tip bracket **U** into the top **1**. Using the anti-tip bracket **U** as a guide, mark one spot on the wall. Drill a hole at the mark and hammer one wall anchor **V** into the wall. Fasten the anti-tip bracket **U** to the wall by screwing one screw **H** into the wall anchor **V**. Tighten all screws.




Drill a 3/16" (5 mm) diameter hole in the wall. Tap the wall anchor (V) into the hole until it is flush.



#### Warning!

This unit **must** be anchored to a stud or wall, as shown. Failure to do so could cause severe injury.

## TECHNICAL DATA



## SPECIFICATIONS

### ASSEMBLED DIMENSIONS (W x D x H)

31 1/2 x 15 5/16 x 64 1/4"

80 x 38.9 x 163.1 cm

### ASSEMBLED WEIGHT

113 lb 5 oz

51.39 kg

### MAXIMUM WEIGHT CAPACITY (Each fixed shelf)

25 lb

11.4 kg

### MAXIMUM WEIGHT CAPACITY (Each drawer and adjustable shelf)

10 lb

4.5 kg

### MAXIMUM WEIGHT CAPACITY (Bottom)

15 lb

6.8 kg



## ASSEMBLY TROUBLESHOOTING



**BEFORE RETURNING  
YOUR PRODUCT**

**HAVING TROUBLE?  
LET US HELP YOU!**

**TOLL-FREE:  
1-888-670-6684**

If you have questions regarding your product or require warranty assistance, please call our customer service helpline.



**CALL US;  
WE CAN HELP**

## CARING FOR YOUR ITEM

**1**

**Weight Capacity:**

- Do not exceed maximum weight capacity of 25 lb (11.4 kg) on each fixed shelf.
- Do not exceed maximum weight capacity of 10 lb (4.5 kg) on each drawer and adjustable shelf.
- Do not exceed maximum weight capacity of 15 lb (6.8 kg) on bottom.
- Do not place anything on top surface of the unit.

**2**

**Furniture tipping over can be dangerous. To reduce your risk:**

- Do not stand on, sit on or climb this unit.
- Do not sit on top of unit.
- For indoor use only.
- Always place the unit on a flat, level surface.
- Regularly tighten all hardware to ensure unit is secure and stable.

**3**

**Wipe clean with a damp cloth.**

**4**

**Avoid direct sunlight.**

## WARRANTY INFORMATION



### **1-YEAR LIMITED WARRANTY\***

This CANVAS™ product carries a one (1) year warranty against defects in workmanship and materials. Trileaf Distribution agrees to replace the defective product free of charge within the stated warranty period, when returned by the original purchaser with proof of purchase. This product is not guaranteed against wear or breakage due to misuse and/or abuse.

**PRODUCT NO. 068-9592-6**

Made in China

Imported by Trileaf Distribution Trifeuil Toronto, Canada M4S 2B8

# CANVAS™

INSPIRED BY CANADA

