


CANVAS^{TM/MC}

BALA CORNER CHAIR

PRODUCT NO. 088-0601-2

MODEL NO. YD-BALAC



ASSEMBLY INSTRUCTIONS



HAVING TROUBLE?

TOLL-FREE:

1-888 -670 -6684

IMPORTANT: Please read this manual carefully before beginning assembly of this product. Keep this manual for future reference.

CANVAS™

INSPIRED BY CANADA



We believe in the power of décor and its ability to make up the fabric of your home.

That's why **CANVAS™ collections draw inspiration from Canadians and the way they live.**

From on-trend furniture pieces to holiday décor and all your outdoor living essentials, **CANVAS™** makes it easy to refresh your space to reflect **your unique style and the way you live every day.**

We would love to hear from you and welcome your thoughtful feedback. Visit our website at **canadiantire.ca** to tell us about your experience, and share your photos with us using **#mycanvasstyle**.

Show us how you bring **CANVAS™** products to life. We can't wait to see!

TABLE OF CONTENTS


Parts List	4
Hardware List	6
Step-by-step Guide	7
Caring for Your Item	11
Warranty	11




WARNING! TO REDUCE THE RISK OF SERIOUS INJURY, READ THE FOLLOWING SAFETY INSTRUCTIONS BEFORE ASSEMBLING AND USING THE PRODUCT.

- Maximum weight limit: 250 lb (113.3 kg) per chair.
- Please read and understand this entire manual before attempting to assemble, operate, or install the product.
- Any assembly or maintenance of the product must be carried out by adults only.
- Some parts may contain sharp edges. Wear protective gloves if necessary.
- To prevent damage, place all parts on a level surface during assembly. Add a layer of protective surface if needed.
- Due to the nature of steel, surface oxidation (rusting) will occur if this protective coating is scratched. This is a natural process. To minimize this condition, it is recommended that care be taken when assembling and handling the product in order to prevent the paint from being scratched.

TOOLS REQUIRED









Torque Wrench "D1" + Hex Bit "D2"




2 people





PARTS LIST

ITEM	DESCRIPTION	THUMBNAIL	QUANTITY
1	Arm panel		1
2	Back panel		1
3	Seat panel		1
4	Left back cushion		1
5	Right back cushion		1
6	Seat cushion		1

EXPLODED PARTS



HARDWARE LIST






ITEM	DESCRIPTION	THUMBNAIL	QUANTITY
A	M6x50 mm bolt		7
B	Washer		14
C	Nut		7
D1/D2/D3	Tools		1
E	Clip		2

STEP-BY-STEP GUIDE

STEP 1



Place the back panel **2** onto a non-abrasive surface, such as a carpet.

Insert the hook on back panel **2** into arm panel **1** as illustrated by the picture below on the right. Fasten the arm panel **1** to the back panel **2** with bolts **A**, washers **B** and nuts **C**. Do not tighten bolts.

1 x1 	2 x1 
A x1 	B x2 
C x1 	


NOTE:

Do not tighten screws all the way until you have assembled the chair. Once assembly is complete, tighten each screw.





STEP 2

Fasten the seat panel **3** to the arm panel **1** with bolts **A**, washers **B** and nuts **C**.



NOTE:

Do not tighten screws all the way until you have assembled the chair. Once assembly is complete, tighten each screw.










STEP-BY-STEP GUIDE

STEP 3

Fasten the seat panel **3** to the back panel **2** with bolts **A**, washers **B** and nuts **C**. Secure all of the bolts using wrenches **D1**, **D2** and **D3**.



Make sure that all of the bolts have been tightened completely.

A x2 	B x4 
C x2 	D1 x1 
D2 x1 	D3 x1 




STEP 4

Turn the chair to an upright position. Place cushions **4**, **5** and **6** onto the chair.



Securing Clips



Please use the clips to connect and secure each section together. Use of the clips is optional and dependent upon the user's personal preference.

CARING FOR YOUR ITEM

1

Always keep children under close supervision while they are using or around this product. Never leave children unattended.

2

This product is intended for domestic, outdoor use only.

3

Do not light any fires below or near the product.

4

Check all nuts and bolts periodically for tightness. When required, tighten them again.

5

We recommend the use of furniture covers when not in use.

CLEANING: Wash frame and wicker parts with mild soap and water, rinse thoroughly, and dry completely. Do not use bleach, acid, or other solvents on the frame or wicker parts.

- The cushion may be washed on the surface only by using mild soap and water or commercial foaming upholstery cleaner if necessary. If washed, rinse well and hang to dry. Do not machine wash or dry.

OFF SEASON: Clean and dry before storing in a dry, sheltered area.

WARRANTY INFORMATION



5-YEAR LIMITED WARRANTY*

This CANVAS product carries a five (5) year warranty against defects in workmanship and materials on the frame and a one (1) year warranty for the remaining parts. Trileaf Distribution agrees to replace a defective product free of charge within the stated warranty period, when returned by the original purchaser with proof of purchase. This product is not guaranteed against wear or breakage due to misuse and/or abuse.

PRODUCT NO. 088-0601-2

Made in China

Imported by Trileaf Distribution Trifeuil Toronto, Canada M4S 2B8

CANVAS™

INSPIRED BY CANADA

