




for
LIVING[®]

Essex Gazebo

Walls and Netting

Product No. 088-1053-0

Model No. A111700200



Assembly Instructions

Toll-free: 1-877-483-6759

IMPORTANT: Please read this manual carefully before beginning assembly of this product.
Keep this manual for future reference.

Production Number: xxxxxxxx

W

P001300064

Walls – 1 (made of 4 panels)



GG

P005100264

Plastic Ring – 104 + 5 Spare





X

P001200127

Netting – 1 (made of 4 panels)






IMPORTANT: RETAIN FOR FUTURE REFERENCE, AND READ CAREFULLY




STEP 1: Open the walls and unzip to separate the 4 panels


STEP 2: Assembly of walls




Install the walls on the outer track of the curtain rail

To correctly attach panels, please be sure to match up the small numbers at top of walls (1 + 1; 2 + 2; 3 + 3; 4 + 4) where the zipper seam is located.






STEP 3: Open the netting and unzip to separate the 4 panels

Attach plastic rings to the netting grommets. Divide rings on each quadrant so 7 are on the longer side of gazebo, and 6 are on the shorter side of gazebo.




STEP 4: Assembly of netting



Install the walls on the outer track of the curtain rail

To correctly attach panels, please be sure to match up the small numbers at top of walls (1 + 1; 2 + 2; 3 + 3; 4 + 4) where the zipper seam is located.



Dimensions (L x W x H)	Wall 128.34" x 83.85"	Netting 128.93" x 85.43"
	Wall 326 x 213 cm	Netting 327.5 x 217 cm
Product weight	8.3 kg	
	18.3 lb	

This product carries a one (1) year warranty against defects in workmanship and materials. Trileaf Distribution agrees to replace the defective product free of charge within the stated warranty period, when returned by the original purchaser with proof of purchase. This product is not guaranteed against wear or breakage due to misuse and/or abuse.