
### CANVAS

### **SUMMERHILL SOFA**

PRODUCT NO. YD-6PCK MODEL NO. 088-2030-8



### **ASSEMBLY INSTRUCTIONS**



**HAVING TROUBLE?** 

**TOLL-FREE:** 

1-888 -670 -6684

IMPORTANT: Please read this manual carefully before beginning assembly of this product. Keep this manual for future reference.





We believe in the power of décor and its ability to make up the fabric of your home.

That's why CANVAS® collections draw inspiration from Canadians and the way they live.

From on-trend furniture pieces to holiday décor and all your outdoor living essentials, CANVAS® makes it easy to refresh your space to reflect your unique style and the way you live every day.

We would love to hear from you and welcome your thoughtful feedback. Visit our website at **canadiantire.ca** to tell us about your experience, and share your photos with us using **#mycanvasstyle**.

Show us how you bring **CANVAS**® products to life. We can't wait to see!

### **TABLE OF CONTENTS**


Parts List	4
Hardware List	6
Step-by-step Guide	7
Caring for Your Item	20
Warranty	20




WARNING! TO REDUCE THE RISK OF SERIOUS INJURY, READ THE FOLLOWING SAFETY INSTRUCTIONS BEFORE ASSEMBLING AND USING THE PRODUCT.

- Maximum weight limit: 750 lb (340.9kg) per sofa.
- Please read and understand this entire manual before attempting to assemble, operate, or install the product.
- Any assembly or maintenance of the product must be carried out by adults only.
- Some parts may contain sharp edges. Wear protective gloves if necessary.
- To prevent damage, place all parts on a level surface during assembly. Add a layer of protective surface if needed.
- Due to the nature of steel, surface oxidation (rusting) will occur if this protective coating is scratched. This is a natural process. To minimize this condition, it is recommended that care be taken when assembling and handling the product in order to prevent the paint from being scratched.

### **TOOLS REQUIRED**






Torque Wrench "C1" + Hex Screw "C2"

2 people

### **PARTS LIST**

ITEM	DESCRIPTION	THUMBNAIL	QUANTITY
1	Chair frame		1
2	Seat panel		1
3	Middle Leg		1
4	Left seat cushion		1
5	Middle seat cushion		1
6	Right seat cushion		1
7	Back cushion		2
8	Middle back cushion		1



### **HARDWARE LIST**

ITEM	DESCRIPTION	THUMBNAIL	QUANTITY
A	M6x20 mm bolt		11
В	Washer		11
C1/C2	Tools	C1 -	

### STEP 1


Place the chair frame  ${\bf 1}$  onto a non-abrasive surface, such as a carpet.


Fasten the seat panel **2** to front of the chair frame **1** by using bolts **A** and washers **B**. Do not tighten bolts.

# 1 X1 2 X1 A X4 B X4

### NOTE:


Do not tighten screws all the way until you have assembled the sofa. Once assembly is complete, tighten each screw.






### STEP 2

Fasten the seat panel 2 to back of the chair frame 1 by using bolts **A** and washers **B**. Tighten all the bolts by wrench C1 and C2.







### STEP 3

Fasten the middle leg  $\bf 3$  to the seat panel  $\bf 2$  by using bolts  $\bf A$  and washers  $\bf B$ . Secure all of the bolts by using wrench  $\bf C1$  and  $\bf C2$ .


Make sure that all of the bolts have been tightened completely.






### STEP 4

Turn the chair to anupright position. Place cushions 4, 5, **6**, **7** and **8** onto the chair.






### CANVAS

### SUMMERHILL COFFEE TABLE

PRODUCT NO. YD-6PCK MODEL NO. 088-2030-8



### **ASSEMBLY INSTRUCTIONS**



### **HAVING TROUBLE?**

TOLL-FREE:

1-888-670 -6684

IMPORTANT: Please read this manual carefully before beginning assembly of this product. Keep this manual for future reference.





We believe in the power of décor and its ability to make up the fabric of your home.

That's why CANVAS® collections draw inspiration from Canadians and the way they live.

From on-trend furniture pieces to holiday décor and all your outdoor living essentials, CANVAS® makes it easy to refresh your space to reflect your unique style and the way you live every day.

We would love to hear from you and welcome your thoughtful feedback. Visit our website at **canadiantire.ca** to tell us about your experience, and share your photos with us using **#mycanvasstyle**.

Show us how you bring **CANVAS**® products to life. We can't wait to see!

### **TABLE OF CONTENTS**


Parts List	14
Hardware List	16
Step-by-step Guide	17
Caring for Your Item	20
Warranty	20




WARNING! TO REDUCE THE RISK OF SERIOUS INJURY, READ THE FOLLOWING SAFETY INSTRUCTIONS BEFORE ASSEMBLING AND USING THE PRODUCT.

- Maximum weight limit: 100 lb (45kg) per table.
- Please read and understand this entire manual before attempting to assemble, operate, or install the product.
- Any assembly or maintenance of the product must be carried out by adults only.
- Some parts may contain sharp edges. Wear protective gloves if necessary.
- To prevent damage, place all parts on a level surface during assembly. Add a layer of protective surface if needed.
- Due to the nature of steel, surface oxidation (rusting) will occur if this protective coating is scratched. This is a natural process. To minimize this condition, it is recommended that care be taken when assembling and handling the product in order to prevent the paint from being scratched.

### **TOOLS REQUIRED**






Torque Wrench "C1" + Hex Screw "C2"

2 people

### **PARTS LIST**

ITEM	DESCRIPTION	THUMBNAIL	QUANTITY
1	Table top		1
2	Base		1
3	Leg		4
4	Glass		1




### **HARDWARE LIST**


ITEM	DESCRIPTION	THUMBNAIL	QUANTITY
A	M6x30 mm bolt		12
В	Washer		12
C1/C2	Tools	C1 -	

### STEP 1

Place the base 2 onto a non-abrasive surface, such as a carpet.


Fasten the legs **3** to the base **2** by using bolts **A** and washers **B**. Do not tighten bolts.






### NOTE:


Do not tighten screws all the way until you have assembled the cooffee table Once assembly is complete, tighten each screw.



### STEP 2

Fasten the table top 1 to the legs 3 by using bolts A and washers **B**. Secure all of the bolts by using wrenches **C1** and C2. Make sure that all of the bolts have been tightened completely.







### STEP 3

### REQUIRES PART 1 and 4

Place glass **4** onto the table top **1**.





### **CARING FOR YOUR ITEM**



Always keep children under close supervision while they are using or around this product. Never leave children unattended.



This product is intended for domestic outdoor use only.



Do not light any fires below or near the product.



Check all nuts and bolts periodically for tightness. When required, tighten them again.



We recommend the use of furniture covers when not in use.

(FURNITURE) CLEANING: Wash frame and wicker parts with mild soap and water, rinse thoroughly, and dry completely. Do not use bleach, acid, or other solvents on the frame or wicker parts.

 The cushion may be washed on the surface only by using mild soap and water or commercial foaming upholstery cleaner if necessary. If washed, rinse well and hang to dry. Do not machine wash or dry.

**OFF SEASON:** Clean and dry before storing in a dry, sheltered area.

### WARRANTY INFORMATION



### 5 YEARS LIMITED WARRANTY\*

This CANVAS product carries a five (5) year warranty against defects in workmanship and materials on the frame and 1 year warranty for the remaining parts. Trileaf Distribution agrees to replace a defective product free of charge within the stated warranty period, when returned by the original purchaser with proof of purchase. This product is not guaranteed against wear or breakage due to misuse and/or abuse.

PRODUCT NO. 088-2030-8

Made in China

Imported by Trileaf Distribution Trifeuil Toronto, Canada M4S 2B8

### **CARING FOR YOUR ITEM**

	GAZEBO	FURNITURE	UMBRELLA	
	Always keep children under close supervision while they are using or around this product. Never leave children unattended.			
	This product is intended for domestic outdoor use only.			
Use & Care	Do not light any fires below or near the product.			
Instructions	Check all nuts and bolts periodically for tightness. When required, tighten them again.			
	Do not shake, lean or climb on it.	We recommend the use of furniture covers when not in use.	Always close and secure the product when not in use and in the event of inclement weather.	
Cleaning	Use a mild detergent solution, rinse with water, and allow to air dry. Do not use acetone, abrasive, or other special detergents as they would be harmful to the product's finish.	Wash frame and wicker parts with mild soap and water, rinse thoroughly, and dry completely. Do not use bleach, acid, or other solvents on the frame or wicker parts.  The cushion may be washed on the surface only by using mild soap and water or commercial foaming upholstery cleaner if necessary. If washed, rinse well and hang to dry. Do not machine wash or dry.	For best results, clean the frame and fabric with a damp cloth, and dry thoroughly. This will help prevent mildew by removing dirt particles that may accumulate.	
Off Season	Clean and dry before storing in a dry, sheltered area.		Clean and dry before storing in a dry, sheltered area.  Umbrella covers keep your product clean and protected when not in use - especially during winter.	

## CANVAS INSPIRED BY CANADA

