




# For Living Cambrian Pergola

---

Product No. 088-2099-6

## Assembly Instructions



**NEED HELP? GIVE US A CALL!  
WE'RE HERE FOR YOU.**



**TOLL-FREE:  
1-877-483-6759**

**IMPORTANT:** Please read this manual carefully before beginning assembly of this product. Keep this manual for future reference.

Production Number: \*\*\*\*\*



From your first apartment to  
downsizing your family home,  
For Living is a great place to start.

Uncomplicate your life with timeless  
style and reliable quality that delivers  
everyday solutions for your home.

Let us know how our products  
work for you. Rate and review at  
[canadiantire.ca](http://canadiantire.ca)

# Table of Contents

Important Safety Instructions	3	Troubleshooting	21
Parts List	5	Caring For Your Item	22
Step-by-step Guide	9	Warranty	23



**IMPORTANT:** Please read and understand this manual before any assembly. Place all parts from the box in a cleared area and position them on the floor in front of you. Remove all packing materials and place them back into the box. Do not dispose of the packing materials until assembly is complete. Read each step carefully before beginning any assembly and make sure you understand each step.



**Let us help you!**


**DO NOT RETURN YOUR PRODUCT TO THE STORE.  
CALL US FIRST! 1-877-483-6759(Toll Free).**

If you have questions regarding your product, require warranty assistance, or have damaged or missing parts, please call our customer service toll-free helpline. Contact us for assistance; we're here to help.



**IMPORTANT:** Please read and understand this manual before any assembly. Before beginning the assembly of product, make sure all parts are available. Compare parts list with packaging contents. If any part is missing, or if you have any questions, contact the service centre at 1-877-483-6759(Toll Free).

Unpack and place all the parts from the packaging box in an open area and position them on the floor. Remove all packing materials and place them back into the box. Do not dispose of the packing materials until assembly is complete. Read each step carefully before beginning any assembly and make sure you understand each step. If you are missing a part, please call our toll-free number for assistance 1-877-483-6759.

## Needed for Assembly: The following tools are not included



Phillips Screwdriver



# Table of Contents



**Warning!** To reduce the risk of serious injury, read the following safety instructions before assembling and using the gazebo.






**Caution!** Always keep children under close supervision while they are playing around this product. Never leave children unattended. Keep pets away while setting up the gazebo.

**Caution!** Check municipal by-laws prior to installing the gazebo.

- This product is intended for domestic outdoor use only.
- The product should be placed and assembled on flat, horizontal ground.
- Consult with your local governing authority/local municipal codes regarding installation of temporary structures before assembly.
- Ensure there is enough clearance around the product. Before assembling the gazebo, make sure to leave a distance of not less than 6' (1.8 m) from any structures or obstructions, such as fences, garages, houses, overhanging branches, laundry lines, or electrical wires.
- Anchor the gazebo to the ground with stakes for added safety. Stakes are provided to secure the gazebo to the ground. If you wish to secure the gazebo to a concrete or wood surface, use anchors suited for these surfaces (anchors not included). Do not assemble the gazebo on sandy, muddy or loose soil, as stakes do not have enough anchorage in these types of soil.
- If more than one gazebo is set up, keep a minimum distance of 10' (3 m) between the gazebos.
- Any assembly or maintenance of the product must be carried out by adults only.
- Some parts may contain sharp edges. Wear protective gloves if necessary.
- Check all nuts and bolts periodically for tightness. When required, tighten them.
- Repairing and replacing parts should be done by a qualified technician.
- This gazebo is intended for decorative and sunshade purposes only.
- The gazebo is not designed to withstand harsh weather, including high winds, rain and snow.
- Make sure there is sufficient manpower when assembling or moving the product.
- Always remove the gazebo in heavy weather conditions, otherwise it might tip over and cause damage to the product or injuries to bystanders.
- During snow days, remove the snow at the top when the snow is thicker than 4" (10 cm).
- After a period of time, usually in 2–3 months, tighten all the bolts.
- After a period of use, rinse the ash on top of the gazebo using water. Avoid using acid or alkali wash lotion.
- Do not hang any weights on the roof frame.
- Do not climb onto the roof of the gazebo. Falling off the gazebo can result in serious injury.
- After a few years, if the paint peels off, use paint of similar colour. It is recommended to use outdoor paint.
- Retain the original packaging to store the gazebo.
- If the product will not be used for a long period of time (e.g. winter time), it should be disassembled and stored in a clean, dry environment.


# Parts List

Item	Description	Thumbnail	Quantity
A P00020060801	Post 1		2
B P00020060901	Post 2		2
C P00010041701	Base		4
D P00610021901	Base cover		4
E P00560045401	Post decoration		4
F P00040117401	Support beam 1		2
G P00040117501	Support beam 2		2
J P00060206901	Top arc beam 1		2
K P00060206801	Top arc beam 2		2
L P00050158501	Top arc beam connector		2
M P00500057601	Support Bar 1		2
N P00500057701	Support Bar 2		2
P P00500057801	Support Bar 3		2






Item	Description	Thumbnail	Quantity
Q P00500057901	Support Bar 4		2
R P00060206601	Top beam 1		5
S P00060206701	Top beam 2		5
T P00570082701	Fabric tube 1		2
U P00570082801	Fabric tube 2		2
V P00640002501	Canopy		1
W P00570082901	Rail tube		4
X P000501518	Rail tube connector		8

# Exploded Parts

for LIVING®



# Hardware List


Item	Description	Thumbnail	Quantity
H1 H100010068	Bolt M6*15		68+4 Spare
H2 H100010059	Bolt M6*45		18+1 Spare
H3 H100010074	Bolt M6*70		8+1 Spare
H4 H100010061	Bolt M6*12		4+1 Spare
H5 H100010090	Bolt M6*15		30+2 Spare
HS H070010001	Stake $\Phi 6*230$		8
HW1 H090010017	Wrench M6		2
HW2 H090030002	Allen Key M6		2

# Step-by-step Guide



## Step 1


**A** X2



**B** X2




**H5** X16



**D** X4






**C** X4



# Step-by-step Guide






## Step 2



# Step-by-step Guide





## Step 3



# Step-by-step Guide






## Step 4



# Step-by-step Guide




## Step 5



# Step-by-step Guide





## Step 6



# Step-by-step Guide




## Step 7



# Step-by-step Guide




## Step 8



# Step-by-step Guide





## Step 9



# Step-by-step Guide




## Step 10



# Step-by-step Guide




## Step 11



# Step-by-step Guide



## Step 13



# Troubleshooting

Need help?

Give us a call! We're here for you.



Before returning your  
product to store



Call us first!

Toll-free: **1-877-483-6759**

If you have questions regarding your product or require warranty assistance, please call our customer service helpline.

# Caring for your Item



**Caution!** Check all screws and nuts periodically for tightness, fastening them again as required.

Cleaning and Maintenance	<p>Clean the gazebo gently with water using a sponge.</p> <p>Do not use abrasive materials, wire brushes, chemicals, cleansers or bleach.</p> <p>Do not use a pressure washer.</p> <p>Rinse well. Allow it to air dry.</p> <p>Steel components of garden accessories and furniture are treated with rust-inhibiting paint. However, due to the nature of steel, surface oxidation (rusting) will occur if this protective coating is scratched. This is a natural process. To minimize this condition, it is recommended to carefully assemble/handle the product, in order to prevent the paint from being scratched. Surface rust can be removed easily using a very light application of common cooking oil. If surface oxidation (rusting) occurs and no measures are taken to correct it, the oxidation may start dripping onto the assembly surface, which may cause stains that may be difficult to remove.</p> <p>Keep instruction manual for future reference.</p> <p>Keep the original packaging to store the gazebo.</p> <p>Remove all excess snow from the roof.</p>
--------------------------	--

# Warranty

## **1-Year Limited Warranty\***

This For Living® product carries a one (1) year warranty against defects in workmanship and materials. Trileaf Distribution agrees to replace the defective product free of charge within the stated warranty period, when returned by the original purchaser with proof of purchase. This product is not guaranteed against wear or breakage due to misuse and/or abuse.

## **Model No. A106000520**

Made in China

Imported by Trileaf Distribution Trifeuil Toronto, Canada M4S 2B8