




Metropolis Gazebo Netting

Product No. 088-2205-4

Model No. A111503600



Assembly Instructions

Toll free: 1-877-483-6759

IMPORTANT: Please read this manual carefully before beginning assembly of this product.
Keep this manual for future reference.

Production Number: XXXXXXXX

Important Safety Instructions	3
Parts List	4
Assembly	5
Cleaning and Maintenance	8
Technical Data	8
Warranty	9



Warning! To reduce the risk of serious injury, read the following safety instructions before assembling the netting to the gazebo.

Caution! Always keep children under close supervision while they are using or around this product. Never leave children unattended.

- This product is intended for domestic outdoor use only.
- For use with For Living® Metropolis Gazebo (088-2023-6) sold separately.
- Any assembly or maintenance of the product must be carried out by adults only.
- If the product will not be used for a longer period (e.g., winter), it should be stored in a clean, dry environment
- Do not light any fires near the product!
- Retain the original packaging to store the netting.

K

P001200162

Mosquito Netting - **1****GG**

P005100264

Ring- **48**


Caution!

- Proper placement of the netting is essential.
- Keep children away during assembly.
This product contains small parts which can be swallowed by children.
- Keep fingers away from the places where they can be pinched or trapped.
- Do not attempt to attach the netting if any parts are missing.


Let us help you!


DO NOT RETURN YOUR PRODUCT TO THE STORE. CALL US FIRST!

1-877-483-6759

If you have questions regarding your product, require warranty assistance, or have damaged or missing parts, please call our customer service toll-free helpline. Contact us for assistance; we're here to help.

IMPORTANT: Please read and understand this manual before any assembly. Before beginning assembly of product, make sure all parts are present. Compare parts with packaging contents list. If any part is missing, or if you have any questions, contact the service centre at 1-877-483-6759 (toll free).

Place all parts from the box in a cleared area and position them on the floor in front of you. Remove all packing materials and place them back into the box. Do not dispose of the packing materials until assembly is complete. Read each step carefully before beginning any assembly and make sure you understand each step. If you are missing a part, please call our toll-free number for assistance 1-877-483-6759.


Needed for assembly:






Ladder



1 person

1





**Caution!**

- Check all screws and nuts on the gazebo periodically for tightness, tightening them again as required.
 - Clean the netting with mild soap and water. Rinse thoroughly, and wait until the product is dry before re-attaching it.
-
- For washing the fabric parts:
 - Spread the fabric and use a soft bristle brush to clean.
 - Always use a natural soap; never use detergent.
 - Water should be cold to lukewarm—never more than 25°C (77°F).
 - Air dry only; do not spin in washing machine nor hand squeeze.
 - Do not use bleach, acid, or other abrasive cleaners on the netting.

Dimensions (Length x Height) 9' 11" x 6' 7"

3 x 2 m

Product weight

1.4 kg

3 lb 1 oz

This For Living product carries a one (1) year warranty against defects in workmanship and materials. Trileaf Distribution agrees to replace the defective product free of charge within the stated warranty period, when returned by the original purchaser with proof of purchase. This product is not guaranteed against wear or breakage due to misuse and/or abuse.