


CANVAS^{TM/MC}

COLLINGWOOD

GAZEBO WALLS

PRODUCT NO. 088-2237-8

MODEL NO. A111302701



ASSEMBLY INSTRUCTIONS

Toll-free: 1-888-670-6684

IMPORTANT: Please read this manual carefully before beginning assembly of this product. Keep this manual for future reference.

Production Number: xxxxxxxx

Important Safety Instructions	3
Parts List	4
General Requirements	5
Assembly	6
Specifications	8
Warranty	8



Caution! Please read and understand the manual before proceeding with assembly. Check and ensure all parts are present.

- This product is intended for domestic, outdoor use only.
- For use with the CANVAS Collingwood Gazebo (088-2022-8), sold separately.
- Any assembly or maintenance of the product must be carried out by adults only.
- If the product will not be used for a longer period (e.g., winter), it should be stored in a clean, dry environment.
- Do not light any fires near the product!
- Retain the original packaging to store the gazebo walls.

4 PRODUCT NO. 088-2237-8 | MODEL NO. A111302701





Let us help you!

DO NOT RETURN YOUR PRODUCT TO THE STORE. CALL US FIRST!


1-888-670-6684

If you have questions regarding your product, require warranty assistance, or have damaged or missing parts, please call our customer service toll-free helpline. Contact us for assistance; we're here to help.

IMPORTANT: Please read and understand this manual before any assembly. Before beginning the assembly of product, make sure all parts are available. Compare parts list with packaging contents. If any part is missing, or if you have any questions, contact the service centre at 1-888-670-6684 (toll-free).

Unpack and place all the parts from the packaging box in an open area and position them on the floor. Remove all packing materials and place them back into the box. Do not dispose of the packing materials until assembly is complete. Read each step carefully before beginning any assembly and make sure you understand each step. If you are missing a part, please call our toll-free number for assistance: 1-888-670-6684.


Needed for assembly: (not included)




Ladder






2 people

STEP 1: Open the walls and unzip to separate the 4 panels

Attach plastic rings to the netting grommets. Divide rings on each quadrant so 7 are on the longer side of gazebo, and 6 are on the shorter side of gazebo.







STEP 2: Assembly of walls



Install the walls on the outer track of the curtain rail

To correctly attach panels, please be sure to match up the small numbers at top of walls (1 + 1; 2 + 2; 3 + 3; 4 + 4) where the zipper seam is located.



8 PRODUCT NO. 088-2237-8 | MODEL NO. A111302701

Walls total size (L x H)	44' 7" x 7' 1" 13.6 x 2.2 m
Compatible gazebo size (L x W x H)	12 x 10 x 10' 3.6 x 3 x 3 m
Product weight	13 lb 13 oz 6.25 kg

This product carries a one (1) year warranty against defects in workmanship and materials.

Trileaf Distribution agrees to replace a defective product free of charge within the stated warranty period, when returned by the original purchaser with proof of purchase. This product is not guaranteed against wear or breakage due to misuse and/or abuse.