
CANVAS

KINGSMERE 10' X 10' GAZEBO WALLS & NETTING

MODEL NO. 088-2268-4



ASSEMBLY INSTRUCTIONS



HAVING TROUBLE?
TOLL-FREE:
1-888-670-6684

IMPORTANT: Please read this manual carefully before beginning assembly of this product. Keep this manual for future reference.

Production Number:xxxxxxxx





We believe in the power of décor and its ability to make up the fabric of your home.

That's why CANVAS™ collections draw inspiration from Canadians and the way they live.

From on-trend furniture pieces to holiday décor and all your outdoor living essentials, CANVAS™ makes it easy to refresh your space to reflect your unique style and the way you live every day.

We would love to hear from you and welcome your thoughtful feedback. Visit our website at **canadiantire.ca** to tell us about your experience, and share your photos with us using **#mycanvasstyle**.

Show us how you bring **CANVAS™** products to life. We can't wait to see!

TABLE OF CONTENTS

Parts List	4
Before You Begin Assembly	7
Step-by-step Guide	8
Technical Data	12
Troubleshooting	13
Caring for Your Item	13
Warranty	14



WARNING! To reduce the risk of serious injury, read the following safety instructions before assembling and using the gazebo. CAUTION! Always keep children and pets under close supervision while they are using or around this product. Never leave children unattended.



Let us help you!

DO NOT RETURN YOUR PRODUCT TO THE STORE. CALL US FIRST! 1-888-670-6684 (toll free).

If you have questions regarding your product, require warranty assistance, or have damaged or missing parts, please call our customer service toll-free helpline. Contact us for assistance; we're here to help.

IMPORTANT: Please read and understand this manual before any assembly. Before beginning assembly of product, make sure all parts are present. Compare parts with packaging contents list. If any part is missing, or if you have any questions, contact us at 1-888-670-6684 (toll free).



- IMPORTANT: Please read and understand this manual before any assembly. Place all parts from the box in a cleared area and position them on the floor in front of you. Remove all packing materials and place them back into the box. Do not dispose of the packing materials until assembly is complete. Read each step carefully before beginning any assembly and make sure you understand each step. If you are missing a part, please call our Customer Service team at 1-888-670-6684 (toll free).
- Keep all children and pets away from assembly area. Children and pets should be supervised when they are in the area.
- Keep all flame and heat sources away from the tent fabric.
- Please wear protective gloves during assembly.

TOOLS REQUIRED

Needed for assembly: Below tools are not included in the package.






1 person

PARTS LIST

ITEM	DESCRIPTION	THUMBNAIL	QUANTITY
A P00130014501	Curtain		1
B P00120027901	Mosquito Netting		1




HARDWARE LIST

ITEM	DESCRIPTION	THUMBNAIL	QUANTITY
HR P005100264	Black Plastic Ring		96+5 Spare


MAKE SURE ALL PARTS ARE PRESENT

Compare all pieces to the parts and hardware lists, and make sure you have all tools required for assembly.




ASSEMBLE IN A CLEARED AREA

Place all parts from the box on the floor in front of you on a clean, dry, level surface to protect the product as it is being assembled.




REMOVE PACKAGING MATERIALS

Place packing materials back in the box. Do not dispose of packaging materials until assembly is complete.





READ EACH STEP CAREFULLY


Make sure you understand each step. If you have questions, contact CANVAS™ customer service at 1-888-660-6684 (toll-free).



STEP-BY-STEP GUIDE










STEP-BY-STEP GUIDE







TECHNICAL DATA



SPECIFICATIONS

ASSEMBLED DIMENSIONS (W x D x H)

110 3/8 x 110 3/8 x 85"

280.5 x 280.5 x 216 cm

TROUBLESHOOTING



HAVING TROUBLE? LET US HELP YOU!

TOLL-FREE: 1-888-670-6684



If you have questions regarding your product or require warranty assistance, please call our customer service helpline.

CARING FOR YOUR ITEM

Cleaning & Use & Care Instructions	Spread the fabric and use a soft-bristle brush to clean.
	Always use a natural soap. Never use detergent.
	Water should be cold to lukewarm, not more than 77°F (25°C).
	Air dry only.
	Do not spin in washing machine or hand squeeze.
	Do not use bleach, acid, or other abrasive cleaners on the canopies or frame parts.
Off Season	If the product will not be used for a longer period (e.g., winter), it should be stored in a clean, dry environment.
	Retain the original packaging to store the walls and netting.

WARRANTY INFORMATION



1-YEAR LIMITED WARRANTY*

This CANVAS™ product carries a one (1) year warranty against defects in workmanship and materials. Trileaf Distribution agrees to replace the defective product free of charge within the stated warranty period, when returned by the original purchaser with proof of purchase. This product is not guaranteed against wear or breakage due to misuse and/or abuse.

MODEL NO. 088-2268-4

Made in China

Imported by Trileaf Distribution Trifeuil Toronto, Canada M4S 2B8

CANVAS



