


CANVAS^{TM/MC}

Alverstone 12' x 12' Gazebo

PRODUCT NO. 088-2282-8



ASSEMBLY INSTRUCTIONS



HAVING TROUBLE?

TOLL-FREE:

1-888-670-6684

IMPORTANT: Please read this manual carefully before beginning assembly of this product. Keep this manual for future reference.

Production Number : *****

CANVAS™

INSPIRED BY CANADA



We believe in the power of décor and its ability to make up the fabric of your home.

That's why **CANVAS®** collections draw **inspiration from Canadians and the way they live.**

From on-trend furniture pieces to holiday décor and all your outdoor living essentials, **CANVAS®** makes it easy to refresh your space to reflect **your unique style and the way you live every day.**

We would love to hear from you and welcome your thoughtful feedback. Visit our website at **canadiantire.ca** to tell us about your experience, and share your photos with us using **#mycanvasstyle.**

Show us how you bring **CANVAS®** products to life. We can't wait to see!

TABLE OF CONTENTS

Parts List.....	5
Step-by-step Guide.....	11
Troubleshooting.....	35
Caring for Your Item.....	36
Warranty.....	37



WARNING! To reduce the risk of serious injury, read the following safety instructions before assembling and using the gazebo.
CAUTION! Always keep children and pets under close supervision while they are using or around this product. Never leave children unattended.



Let us help you!

DO NOT RETURN YOUR PRODUCT TO THE STORE. CALL US FIRST!
1-888-670-6684 (Toll free).


If you have questions regarding your product , require warranty assistance, Or have damaged or missing parts, please call our customer service toll-free helpline. Contact us for assistance, we're here to help.

IMPORTANT: Please read and understand this manual before any assembly. Before beginning assembly of product, make sure all parts are present. Compare parts with packaging contents list. If any part is missing, or if you have any questions, contact the service at 1-888-670-6684 (Toll free).


Place all parts from the box in a cleared area and position them on the floor in front of you. Remove all packing materials and place them back into the box. Do not dispose of the packing materials until assembly is complete. Read each step carefully before beginning any assembly and make sure you understand each step. If you are missing a part, please call our Customer Service team at 1-888-670-6684 (Toll free).

TOOLS REQUIRED

Needed for assembly: Below Tools are not included in the package.




Cordless drill



Hammer



Ladder



4 people

TABLE OF CONTENTS
















CAUTION!














- Proper placement of your gazebo is essential. Do not place the product underneath electrical lines.
- Keep children away during assembly. This product contains small parts which can be swallowed by children.
- Keep fingers away from the places where they can be pinched or trapped.
- Do not attempt to assemble the gazebo if any parts are missing.

- This product is intended for outdoor use only.
- The product should be assembled on a flat stable surface.
- Do not assemble the gazebo on unstable surfaces.
- Ensure the location and clearance of your gazebo is acceptable.
- The gazebo must be anchored with stakes into the ground for added safety. It is recommended that it should not be permanently attached to a concrete floor or platform.
- Arrange the necessary manpower when assembling or moving the product.
- Some parts may contain sharp edges. Wear protective gloves and glasses if necessary.
- Keep children and pets away while setting up the gazebo.
- Check all nuts and bolts periodically for tightness. When required, tighten them again.
- Repairing and replacing parts should be done by a qualified technician.
- The gazebo is intended for decorative and shade purposes only, and is not designed to withstand harsh weather, including high winds, rain and snow.
- If the product is not being used for long periods of time (e.g. winter), it should be store in a clean, dry environment.
- Do not put a Liquid Propane or Wood Burning firepit or fireplace inside the product.
- Do not climb or place heavy objects onto the gazebo roof.
- Retain the original packaging to store and protect the gazebo during the winter months.
- Do not use or enter the gazebo if the following conditions exists:
 - Visible movement of supports, roofing panels or a sagging roof.
 - Unusual noise from the gazebo.
 - Deformed roof panels.
 - Damaged or missing bolts/fasteners.
- Please check your HOA, Local, and State Governments prior to purchasing and assembling gazebo's. These local organizations may require permits and specific requirements for installation.
- Maintain your instruction manual for future reference.
- Warranty: Please retain you receipt for proof of purchase.














PARTS LIST

ITEM	DESCRIPTION	THUMBNAIL	UANTITY
A P00020058101	Post		4
B P00610021401	Base Cover		4
C P00010041501	Base		4
D P00040112601	Cross Beam (Left)		4
E P00040112701	Cross Beam (Right)		4
F P00050155001	Connector for Cross Beam		4
G P00560044501	Middle Insert Card		4
J P00500056201	Slanting Bar 1		4
K P00500056301	Slanting Bar 2		4
L P00050155101	Connector for Slanting Bar 1		4
M P00050155201	Connector for Slanting Bar 2		4
N P00060191501	Big Panel		4
P P00060191701	Upper Slanting Bar		4


PARTS LIST

ITEM	DESCRIPTION	THUMBNAIL	QUANTITY
Q P00060191801	Lower Slanting Bar		4
R P00060191901	Middle Bar		4
S P00060192001	Outer Small Beam 1		4
T P00060192101	Outer Small Beam 2		4
U P00050154901	Small Connector		1
V P00060191601	Slanting Bar for Small Top		4
W P00500056101	Support Tube for Small Slanting Bar		4
X P00560044601	Small Decoration Frame		4
Y P00560044701	Small Decoration Panel		4
AA P00070093301	Small Panel		4
AB P00080032901	Panel for Slanting Bar		4
AC P00090015101	Small Top Cover		1
AD P0058000001	Hook		1


PARTS LIST

ITEM	DESCRIPTION	THUMBNAIL	UANTITY
AE P00060192201	Small Bar 1		4
AF P00060192301	Small Bar 2		4
AG P00220033001	Corner Insert Card		4
AJ P00070092701	Small Panel for Big Top 1		4
AK P00070092801	Small Panel for Big Top 2		4
AL P00070092901	Middle Panel for Big Top 1		4
AM P00070093001	Middle Panel for Big Top 2		4
AN P00070093101	Big Panel for Big Top 1		4
AP P00070093201	Big Panel for Big Top 2		4
AQ P00080033201	Middle Panel		4
AR P00080033001	Upper Panel for Slanging Beam		4
AS P00080033101	Lower Panel for Slanting Beam		4
AT P00220032901	Lower Slanting Panel		4











EXPLODED PARTS



EXPLODED PARTS




HARDWARE LIST







ITEM	DESCRIPTION	THUMBNAIL	QUANTITY
H1 H100010050	Bolt M6X 20		181+10 Spare
H2 H100010086	Bolt M6X 25		52+3 Spare
H3 H100010059	Bolt M6X 45		20+1 Spare
H4 H100010087	Bolt M6X 75		8+1 Spare
H5 H050030001	Flat Washer M6		20+1 Spare
H6 H050050018	Washer rubber M6		24+2 Spare
H7 H040010004	Nut M6		20+1 Spare
H8 H070010003	Stake $\Phi 8 * 180$		8
HW1 H090010017	Wrench M6		2
HW2 H090030002	Allen Key M6		1

STEP-BY-STEP GUIDE

STEP 1





STEP 2





STEP-BY-STEP GUIDE

STEP 3









STEP 4

H1 X16




STEP-BY-STEP GUIDE

STEP 5





STEP 6

N X4




H1 X4



STEP-BY-STEP GUIDE

STEP 7



P X4




Q X4



H1 X4





STEP 8






STEP-BY-STEP GUIDE

STEP 9



STEP 10




STEP-BY-STEP GUIDE

STEP 11



V X4







U X1



W X4





STEP 12







STEP-BY-STEP GUIDE

STEP 13

AA X4






STEP 14



STEP-BY-STEP GUIDE

STEP 15




STEP 16



AE X4



AF X4






H1 X24







STEP-BY-STEP GUIDE

STEP 17







STEP 18








STEP-BY-STEP GUIDE

STEP 19




STEP 20



STEP-BY-STEP GUIDE



STEP 21

AQ X4







H6 X8

H3 X8




STEP 22





STEP-BY-STEP GUIDE

STEP 23



AT X4



H3 X4



STEP 24



TROUBLESHOOTING



**BEFORE RETURNING
YOUR PRODUCT**

**HAVING TROUBLE?
LET US HELP YOU!**

**TOLL-FREE:
1-888-670-6684**



**CALL US,
WE CAN HELP**

If you have questions regarding your product or require warranty assistance, please call our customer service helpline.

CARING FOR YOUR ITEM



CAUTION! CHECK ALL SCREWS AND NUTS PERIODICALLY FOR TIGHTNESS, FASTENING THEM AGAIN AS REQUIRED.

Cleaning & Use & Care Instructions

Always keep children under close supervision while they are using or around this product. Never leave children unattended.

This product is intended for outdoor use only.

Do not light any fires below or near the product.

Clean the gazebo with mild soap and water. Rinse thoroughly and wait until the product is dry before reassembling it.

Check all nuts and bolts periodically for tightness. When required, tighten them again.

Disassemble the gazebo in the reverse order of the assembly steps. Always disassemble the gazebo completely. A partially disassembled gazebo is not stable enough to resist wind and bad weather, and therefore can be damaged and/or cause damages.

Remove all excess snow from the roof.

Do not shake, lean or climb on gazebo.

Clean and dry before storing in a dry, sheltered area. Do not use bleach, acid, or other abrasive cleaners on the canopies or frame parts.

Steel components for this gazebo are treated with rust inhibiting paint to prevent and limit rusting. However, due to the nature of steel, surface oxidation (rusting) will occur if these protective coatings are scratched. This is not a defect and thus not covered by the warranty. To minimize this condition, it is recommended to use care when assembling and handling the product to prevent scratching of the paint. Should any scratching or damage occur, it is recommended to cover the scratch immediately with rust inhibiting paint (not included). Surface rust can also be easily removed with a very light application of regular cooking oil or WD-40. If surface oxidation (rusting) occurs and if no measure is taken to prevent this, the oxidation may start dripping onto deck or patio and cause damaging stains, which may be difficult to remove. This can be prevented if the above-mentioned measures are taken to keep the product from oxidizing.

Keep instruction manual for future reference.

Keep the original packaging to store the gazebo.

WARRANTY INFORMATION



3 YEARS LIMITED WARRANTY*

This CANVAS product carries a three (3) year warranty against defects in workmanship and materials on the frame and 1 year warranty for the remaining parts. Trileaf Distribution agrees to replace a defective product free of charge within the stated warranty period, when returned by the original purchaser with proof of purchase. This product is not guaranteed against wear or breakage due to misuse and/or abuse.

PRODUCT NO. A102002400

Made in China

Imported by Trileaf Distribution Trifeuil Toronto, Canada M4S 2B8

CANVAS™

INSPIRED BY CANADA

