



**Aqua Market Umbrella**  
Product No. 088-2500-0  
**Orange Market Umbrella**  
Product No. 088-2501-8

**Need help? Give us a call!**  
**We're here for you.**



Toll-free:  
**1-877-483-6759**


**IMPORTANT:** Please read this manual carefully before beginning assembly of this product. Keep this manual for future reference.

### Step-by-Step Guide

#### Step 1:

Requires: A, B

Push the button on the pole (B), and insert pole (B) into the sunshade (A). Release the button on the pole (B) and allow it to click into place in the hole in the sunshade pole.




### Step-by-Step Guide

#### Step 2: Opening the umbrella

Requires: A


Shake the umbrella fabric before opening the umbrella. Push the button located on the umbrella shade (A) and move upwards to open.



### Step-by-Step Guide

#### Step 3: Closing the umbrella

Push the button on the umbrella shade (A) and move downwards to close.





**Aqua Market Umbrella**  
**Product No. 088-2500-0**

**Orange Market Umbrella**  
**Product No. 088-2501-8**

**Need help? Give us a call!  
We're here for you.**



Toll-free:  
**1-877-483-6759**

**IMPORTANT:** Please read this manual carefully before beginning assembly of this product. Keep this manual for future reference.

### Caution

Check all bolts and nuts periodically for tightness, fastening them again as required. Disassemble the product in the reverse order of the assembly steps. Always disassemble the product completely. A partially disassembled product is not stable enough to resist wind and bad weather, and therefore can be damaged and/or cause damage. Steel components of garden accessories and furniture are treated with rust-inhibiting paint. However, due to the nature of steel, surface oxidation (rusting) will occur if this protective coating is scratched. This is a natural process. To minimize this condition, it is recommended that care be taken

when assembling and handling the product, in order to prevent the paint from being scratched. If scratching or damage occurs, it is recommended that the area be touched up immediately with rust-inhibiting paint. Surface rust can be removed easily using a very light application of common cooking oil. If surface oxidation (rusting) occurs and no measures are taken to correct it, the oxidation may start dripping onto the assembly surface, which may cause damaging stains that may be difficult to remove.

### Cleaning and Maintenance

Clean the product with mild soap and water. Rinse thoroughly, and wait until the product is dry before reassembling it.

#### For washing the fabric parts:

- Spread the fabric and use a soft bristle brush to clean.
- Always use a natural soap, never detergent.
- Water should be cold to lukewarm, never more than 25°C (77°F).
- Air dry only; do not spin in washing machine or hand squeeze.

Do not use bleach, acid, or other abrasive cleaners on the canopies or frame parts.

### Warning

Do not place the product underneath electrical lines. Keep children away during assembly. This product contains small parts which can be swallowed by children. Keep fingers away from places where they can be pinched or trapped.

### Warranty

This For LIVING® product carries a one (1) year warranty against defects in workmanship and materials. Trileaf Distribution agrees to replace the defective product free of charge within the stated warranty period, when returned by the original purchaser with proof of purchase. This product is not guaranteed against wear or breakage due to misuse and/or abuse.

Made in China

Imported by Trileaf Distribution Trifeuil Toronto, Canada M4S 2B8



Parasol de marché bleu mer

Produit n° 088-2500-0

Parasol de marché orange

Produit n° 088-2501-8

**Vous avez besoin d'aide?  
Appelez-nous! Nous sommes  
ici pour vous aider.**



Numéro sans frais :  
**1 877 483-6759**


**IMPORTANT :** Veuillez lire attentivement ce guide avant de commencer l'assemblage de ce produit. Conservez ce guide aux fins de consultation ultérieure.

### Guide étape par étape

#### Étape 1 :

Nécessite A, B

Appuyez sur le bouton sur le mât (B) et insérez le mât (B) dans le parasol (A). Relâchez le bouton sur le mât (B) et laissez-le s'enclencher dans le trou du mât du pare-soleil.




### Guide étape par étape

#### Étape 2 : Ouvrir le parasol

Nécessite A


Secouez le tissu du parasol avant d'ouvrir le parasol. Appuyez sur le bouton situé sur le parasol (A) et déplacez-le vers le haut pour l'ouvrir.



### Guide étape par étape

#### Étape 3 : Fermer le parasol

Appuyez sur le bouton du parasol (A) et déplacez-le vers le bas pour le fermer.





Parasol de marché bleu mer

Produit n° 088-2500-0

Parasol de marché orange

Produit n° 088-2501-8

**Vous avez besoin d'aide?  
Appelez-nous! Nous sommes  
ici pour vous aider.**



Numéro sans frais :  
**1 877 483-6759**

**IMPORTANT :** Veuillez lire attentivement ce guide avant de commencer l'assemblage de ce produit. Conservez ce guide aux fins de consultation ultérieure.

## Mise en garde

Vérifiez tous les écrous et les boulons périodiquement pour voir si'ils sont bien serrés, et resserrez-les au besoin. Démontez le produit en suivant les étapes d'assemblage dans l'ordre inverse. Démontez toujours le produit entièrement. Lorsqu'il est partiellement démonté, le produit n'est pas assez stable pour résister au vent et aux intempéries, et peut donc être endommagé ou entraîner des dommages. Les pièces en acier des accessoires et des meubles de jardin sont thermolaquées avec une peinture résistante à la rouille. Toutefois, en raison de la nature de l'acier, un revêtement de protection rayé pourrait entraîner l'oxydation de la surface (rouille). Ceci est un processus naturel. Pour

lminimiser cette condition, il est recommandé de faire attention lors du montage et de la manipulation du produit, afin d'éviter que la peinture ne soit rayée. En cas de rayures ou de dommages, il est recommandé de procéder immédiatement à la retouche de la surface avec une peinture antirouille. La rouille en surface peut être facilement enlevée en appliquant un peu d'huile de cuisson. S'il y a présence d'oxydation en surface (rouille) et qu'aucune mesure n'est prise pour corriger la situation, l'oxydation peut commencer à couler sur la surface d'assemblage et laisser des taches qui peuvent être difficiles à éliminer.

## Nettoyage et entretien

Nettoyez le produit au savon doux et à l'eau. Rincez bien, et attendez que le fauteuil soit sec avant de l'assembler à nouveau.

### Pour nettoyer les pièces en tissu :

- Étendez le tissu et utilisez une brosse à poils doux pour nettoyer.
- Utilisez toujours du savon naturel, jamais de détergent.
- L'eau devrait être froide ou tiède, jamais à plus de 25 °C (77 °F).
- Ne séchez le produit qu'à l'air libre; ne l'essorez pas en machine ou à la main.

N'utilisez pas de javellisant, d'acide ou d'autres nettoyants abrasifs sur la table.

## Avertissement

Ne placez pas l'article sous des lignes électriques. Tenez les enfants à l'écart du produit pendant son assemblage. Cet article contient de petites pièces que les enfants peuvent facilement avaler. Tenez vos doigts éloignés des endroits où ils risquent d'être pincés ou pris.

## Garantie

Cet article For LIVING<sup>MD</sup> comprend une garantie de un (1) an contre les défauts de fabrication et de matériaux. Distribution Trifeuil consent à remplacer l'article défectueux lorsqu'il est retourné par l'acheteur original, accompagné de la preuve d'achat, au cours de la période de garantie convenue. Exclusion : usure ou bris causés par un usage abusif ou inapproprié.