


CANVAS^{TM/MC}

THORNE 1-LIGHT PENDANT

PRODUCT NO. 152-2626-8



ASSEMBLY INSTRUCTIONS



HAVING TROUBLE?

TOLL-FREE:

1-888-670-6684

IMPORTANT: Please read this manual carefully before beginning assembly of this product. Keep this manual for future reference.

CANVASTM

INSPIRED BY CANADA



We believe in the power of décor and its ability to make up the fabric of your home.

That's why **CANVASTM** collections draw inspiration from Canadians and the way they live.

From on-trend furniture pieces to holiday décor and all your outdoor living essentials, **CANVASTM** makes it easy to refresh your space to reflect your unique style and the way you live every day.

We would love to hear from you and welcome your thoughtful feedback. Visit our website at **canadiantire.ca** to tell us about your experience, and share your photos with us using **#myCANVASstyle**.

Show us how you bring **CANVASTM** products to life. We can't wait to see!

TABLE OF CONTENTS

Important Safety Instructions	3	Technical Data	12
Parts List	4	Warranty	13
Before You Begin Assembly	6	Troubleshooting	14
Electrical Installation	7	Caring for Your Item	15
Step-by-step Guide	8		



WARNING! CONSULT A QUALIFIED ELECTRICIAN TO ENSURE CORRECT CIRCUIT CONDUCTOR.

CLEANING: Before cleaning your fixture, turn off the switch or power source. Wipe the fixture with a soft, damp cloth.


IMPORTANT: RETAIN FOR FUTURE REFERENCE, AND READ CAREFULLY.




READ INSTRUCTIONS AND REVIEW ALL DIAGRAMS BEFORE INSTALLING FIXTURE. GENERAL INSTRUCTIONS:

1. All electrical connections must be in accordance with local codes, ordinances and the Canadian Electrical Code.
2. These fixtures should be mounted on an electrical outlet box. The box must be directly supported by the building structure.
3. Turn off the circuit breaker or remove the appropriate fuse to disconnect power source before installing fixture.
4. Turning the light switch off to cut the power is not sufficient to prevent electric shock. When in doubt about the safety of any electrical installation or repair, consult a qualified electrician.

TOOLS REQUIRED



NOTE: Do not over-drill/
Be aware of over-drilling.







No. 2 Cross-head Screwdriver
Tip Shown Actual Size

PARTS LIST

ITEM	DESCRIPTION	THUMBNAIL	QUANTITY
1	Fixture		1

HARDWARE LIST

ITEM	DESCRIPTION	THUMBNAIL	QUANTITY
A	Outlet box screw		2
B	Wire connector		3
C	Decorative nut (pre-installed)		2
D	Canopy		1
E	Mounting bracket (pre-installed)		1
F	Strain relief buckle		1
G	E26 Medium base bulb 60 W max (sold separately)		1

EXPLODED PARTS




BEFORE YOU BEGIN ASSEMBLY

MAKE SURE ALL PARTS ARE PRESENT

Compare all pieces to the parts and hardware lists, and make sure you have all tools required for assembly.


ASSEMBLE IN A CLEARED AREA

Place all parts from the box on the floor in front of you on a clean, dry, level surface to protect the product as it is being built.




REMOVE PACKAGING MATERIALS

Place packing materials back in the box. Do not dispose of packaging materials until assembly is complete.



READ EACH STEP CAREFULLY


Make sure you understand each step. For any questions, contact CANVAS™ customer service at 1-888-670-6684 (toll-free).



ELECTRICAL INSTALLATION


STEP 1

Place the wall switch on the “OFF” position.




STEP 2

Depending on which type of fuse box you have in your home:



- Place either the main (Master) switch in the “OFF” position, cutting off power to your entire home, OR turn off the individual switch that provides power to where the fixture will be installed.



- Place either the main (Master) switch in the “OFF” position, cutting off power to the entire home, OR unscrew the fuse that provides power to where the fixture will be installed.


NOTE: Shutting off a wall switch that controls the light is not sufficient to prevent electric shock.



WARNING! CONSULT A QUALIFIED ELECTRICIAN TO ENSURE
CORRECT BRAND CIRCUIT CONDUCTOR.

STEP-BY-STEP GUIDE


STEP 1



Remove the mounting bracket **E** by unscrewing decorative nuts **C**.


Place the canopy **D** against the ceiling and adjust the cord from the fixture **1** to the desired length by pulling the excess cord through the canopy **D**.

When the cord is at the desired length, adjust the strain relief buckle **F** toward the canopy **D**.



STEP-BY-STEP GUIDE

STEP 2



Using the outlet box screws **A**, attach the mounting bracket **E** to the outlet box.


The outlet box screws on the mounting bracket **E** should protrude out of the outlet box as shown.

Attach the white wire from the house to the white wire from the fixture **1** using one of the included wire connectors **B**.

Then, attach the black wire from the house to the black wire from the fixture **1** the same way.


Next, connect the bare copper wire from the fixture around the green screw on the mounting bracket **E**.

Finally, attach the green ground wire (or bare copper wire) from the house to the bare wire and the green wire from the fixture **1** using the remaining wire connector **B**.



STEP-BY-STEP GUIDE


STEP 3



Align the mounting holes on the canopy **D** with mounting screws on the mounting bracket **E**.

Put in place the canopy **D** making sure all wires are secure inside outlet box.

Screw the decorative nuts **C** onto mounting screws to secure the canopy **D** to the mounting bracket **E**.




NOTE:


Ensure wiring is not pinched, pushed or twisted during installation.

STEP-BY-STEP GUIDE

STEP 4



Screw 1 medium base (E26), 60 W max bulb **G** into the socket of the light fixture **1**.



TECHNICAL DATA



SPECIFICATIONS

ASSEMBLED DIMENSIONS (DIA x H)

14 x 78 1/8"

35.6 x 198.4 cm

ASSEMBLED WEIGHT

2 lb 7 oz

1.1 kg

WARRANTY



1-YEAR LIMITED WARRANTY*

This CANVAS™ product carries a one (1) year warranty against defects in workmanship and materials. Trileaf Distribution agrees to replace the defective product free of charge within the stated warranty period, when returned by the original purchaser with proof of purchase. This product is not guaranteed against wear or breakage due to misuse and/or abuse.

PRODUCT NO. 152-2626-8

Made in China

Imported by Trileaf Distribution Trifeuil Toronto, Canada M4S 2B8

TROUBLESHOOTING



BEFORE RETURNING
YOUR PRODUCT

HAVING TROUBLE? LET US HELP YOU!

TOLL-FREE:
1-888-670-6684

If you have questions regarding your product or require warranty assistance, please call our customer service helpline.



CALL US;
WE CAN HELP

PRODUCT TROUBLESHOOTING

PROBLEM	POSSIBLE CAUSES	SOLUTION
Light will not turn on.	Power is off.	Make sure power supply is on.
Light will not turn on.	Bulb is burned out.	Replace bulb.
Light will not turn on.	Bulb is loose.	Tighten the bulb in the socket.
Light will not turn on.	Bad main supply wiring	Consult a certified professional electrician.
Light will not turn on.	Defective switch	Consult a certified professional electrician.
Fuse blows or circuit trips when fixture is turned on.	Wrong wiring or power wire is grounding out.	Consult a certified professional electrician.

CARING FOR YOUR ITEM

1

Clean this unit periodically. Clean the surface finish only using a soft dry cloth. Never use a rough cloth, abrasives or chemical cleaners containing acids or harsh solvents.

CANVASTM




INSPIRED BY CANADA



CANVAS^{TM/MC}

THORNE SUSPENSION 1 LUMIÈRE

N° D'ARTICLE : 152-2626-8



INSTRUCTIONS D'ASSEMBLAGE



VOUS RENCONTREZ DES PROBLÈMES?
NUMÉRO SANS FRAIS :
1 888 670-6684

IMPORTANT: Veuillez lire attentivement ce guide avant de procéder avec l'assemblage de ce produit. Conservez ce guide aux fins de consultation ultérieure.

CANVAS^{TM/MC}

D'INSPIRATION CANADIENNE



Nous croyons au pouvoir de la décoration pour donner son âme à votre maison.

C'est pour cela que les collections **CANVAS^{MC}** s'inspirent des Canadiens et de leur style de vie.

Qu'il s'agisse de meubles tendance, de décos pour les fêtes ou pour le plein air, **CANVAS^{MC}** vous permet de rafraîchir facilement votre espace pour qu'il reflète votre style unique et votre mode de vie.

Nous serions ravis de recevoir vos commentaires judicieux. Visitez notre site Web à canadiantire.ca pour nous communiquer de votre expérience et partagez vos photos avec nous en utilisant **#mycanvasstyle**.

Montrez-nous comment vous donnez vie aux produits **CANVAS^{MC}**. Nous avons hâte de les voir!

TABLE DES MATIÈRES

Consignes de sécurité importantes	19	Garantie	27
Liste des pièces	20	Dépannage	28
Avant le montage	22	Entretien	28
Guide étape par étape	23		
Données techniques	27		

NETTOYAGE : Avant de nettoyer votre luminaire, veuillez mettre l'interrupteur en position d'arrêt ou débranchez le luminaire de la source d'alimentation. Essuyez le luminaire avec un linge doux et humide.

IMPORTANT : CONSERVEZ CE GUIDE AUX FINS DE CONSULTATION ULTÉRIEURE, ET LISEZ-LE ATTENTIVEMENT.



LISEZ LES INSTRUCTIONS ET EXAMINEZ TOUS LES SCHÉMAS AVANT D'INSTALLER LE LUMINAIRE.

CONSIGNES DE SÉCURITÉ :

1. Cette lampe portable est équipée d'une fiche polarisée (une lame est plus large que l'autre) comme mesure de sécurité pour réduire le risque de choc électrique.
2. Cette fiche ne peut être insérée dans une prise de courant polarisée que dans un seul sens. Si la fiche ne s'insère pas complètement dans la prise de courant, inversez la fiche. Si elle ne s'adapte toujours pas, contactez un électricien qualifié.
3. N'utilisez jamais l'article avec une rallonge à moins que la fiche ne puisse être complètement insérée
4. Ne modifiez pas la fiche.

LISTE DE PIÈCES

RÉFÉRENCE	DESCRIPTION	ILLUSTRATION	QUANTITÉ
1	Luminaire		1

LISTE DES ÉLÉMENTS DE QUINCAILLERIE

RÉFÉRENCE	DESCRIPTION	ILLUSTRATION	QUANTITÉ
A	Vis de montage		1
B	Connecteur de fil		2
C	Écrou décoratif (préinstallé)		3
D	Canopé		2
E	Bandé de montage (préinstallé)		1
F	Boucle anti-traction		2
G	Ampoule culot moyen E26 60 W max (vendu séparément)		1

VUE ÉCLATÉE



Ampoule E26
(vendue séparément)


AVANT LE MONTAGE

VÉRIFIER QU'IL NE MANQUE AUCUNE PIÈCE

Comparez les listes des pièces aux éléments de quincaillerie pour vous assurer qu'il ne manque rien, et assurez-vous d'avoir en main tous les outils nécessaires au montage.


ASSEMBLER DANS UN ENDROIT DÉGAGÉ

Retirez les pièces de la boîte et placez-les sur une surface plane propre et sèche pour protéger le produit durant le montage.




RETIRER L'EMBALLAGE

Déposez le matériel d'emballage dans la boîte. Ne jetez rien avant d'avoir terminé le montage.




BIEN LIRE CHAQUE ÉTAPE

Assurez-vous de bien comprendre chaque étape. En cas de question,appelez le au service à la clientèle de CANVAS^{MC} au 1 888 670-6684 (sans frais).



GUIDE ÉTAPE PAR ÉTAPE


ÉTAPE 1



Retirez le support de montage **E** en dévissant les écrous décoratifs **C**.


Placez l'auvent **D** contre le plafond et ajustez le cordon du luminaire **1** à la longueur souhaitée en tirant l'excédent de cordon à travers le couvercle **D**.

Lorsque le cordon est à la longueur souhaitée, ajustez la boucle de décharge de traction **F** vers la voûte **D**.



GUIDE ÉTAPE PAR ÉTAPE

ÉTAPE 2



À l'aide des vis de la boîte de sortie **A**, fixez le support de montage **E** à la boîte de sortie.


Les vis de la boîte de sortie sur le support de montage **E** doivent dépasser de la boîte de sortie, comme illustré.

Reliez le fil blanc du boîtier au fil blanc du luminaire **1** à l'aide de l'un des connecteurs de fil **B**.

Puis, fixez le fil noir du boîtier au fil noir du luminaire **1** de la même manière.


Ensuite, connectez le fil de cuivre nu du luminaire autour de la vis verte du support de montage **E**.

Enfin, fixez le fil de terre vert (ou le fil de cuivre nu) du boîtier au fil nu et au fil vert du luminaire **1** à l'aide du connecteur de fil **B**.




GUIDE ÉTAPE PAR ÉTAPE

ÉTAPE 3



Alignez les trous de fixation du couvercle **D** avec les vis de fixation du support de montage **E**.

Mettez en place le couvercle **D** en vous assurant que tous les fils sont bien fixés à l'intérieur de la boîte de sortie. **C** onto mounting screws to secure the canopy **D** to the mounting bracket **E**.




REMARQUE :


Assurez-vous que le câblage n'est pas pincé, poussé ou tordu pendant l'installation.

GUIDE ÉTAPE PAR ÉTAPE

ÉTAPE 4



Vissez 1 ampoule **G** à culot moyen (E26), 60 W max. dans la douille du luminaire **1**.



DONNÉES TECHNIQUES



CARACTÉRISTIQUES

DIMENSIONS DE L'ARTICLE (DIAM. X H.)

14 x 78 1/8 po

35.6 x 198.4 cm

POIDS DE L'ARTICLE

2 lb 7 oz

1.1 kg

GARANTIE



GARANTIE LIMITÉE DE 1 AN

Cet article CANVAS^{MC} comprend une garantie de un (1) an contre les défauts de fabrication et de matériau(x). Distribution Trifeuil consent à remplacer l'article défectueux lorsqu'il est retourné par l'acheteur original, accompagné de la preuve d'achat, au cours de la période de garantie convenue. Exclusion : usure ou bris causés par un usage abusif ou inapproprié.

N° D'ARTICLE 152-2626-8

Fabriqué en Chine

Importé par Trileaf Distribution Trifeuil Toronto, Canada M4S 2B8

DÉPANNAGE EN COURS DE MONTAGE



AVANT DE
RETOURNER VOTRE
PRODUIT

**VOUS RENCONTREZ DES PROBLÈMES?
LAISSEZ-NOUS VOUS AIDER!**

SANS FRAIS :
1 888 670-6684

En cas de question sur le produit ou la garantie,
appelez le au service à la clientèle.



APPELEZ-NOUS,
NOUS POUVONS
VOUS AIDER

DÉPANNAGE EN CAS DE PROBLÈME AVEC LE PRODUIT

PROBLÈME

CAUSES POSSIBLES

SOLUTION

La lampe ne s'allume pas.

La lampe ne s'allume pas.

Assurez-vous que la source d'alimentation est sous tension.

La lampe ne s'allume pas.

L'ampoule est grillée.

Remplacez l'ampoule.

La lampe ne s'allume pas.

L'ampoule n'est pas complètement serrée.

Serrez l'ampoule dans la douille.

La lampe ne s'allume pas.

Le câblage du circuit d'alimentation principal est inadéquat.

Consultez un maître électricien.

La lampe ne s'allume pas.

L'interrupteur est défectueux.

Consultez un maître électricien.

ENTRETIEN

Nettoyez régulièrement la surface du produit avec un linge doux et sec. N'utilisez jamais de linge rugueux, de substances abrasives, ni de nettoyants chimiques contenant des acides ou des solvants forts.

CANVAS^{TM/MC}

D'INSPIRATION CANADIENNE

