


# 27" (69 cm) 2-Door Wall Cabinet

Product No. 168-0140-8

#### **Assembly Instructions**





NEED HELP? GIVE US A CALL! WE'RE HERE FOR YOU.

TOLL-FREE: 1-877-483-6759

IMPORTANT: Please read this manual carefully before beginning assembly of this product. Keep this manual for future reference.



From your first apartment to downsizing your family home, For LIVING® is a great place to start.

Uncomplicate your life with timeless style and reliable quality that delivers everyday solutions for your home.

Let us know how our products work for you. Rate and review at canadiantire.ca

#### Table of Contents



Parts List	4	Adjust Doors	21
Exploded Parts	5	Technical Data	22
Hardware List	6	Assembly Troubleshooting	23
Before You Begin Assembly	7	Caring for Your Item	23
Step-by-step Guide	8	Warranty	24



**Warning!** Please use your furniture correctly and safely. Improper use can cause safety hazards or damage to your furniture or household items. Carefully read the following safety information.

- Please read and understand this entire manual before attempting to assemble, operate, or install the product.
- Any assembly or maintenance of the product must be carried out by adults only.
- Some parts may contain sharp edges. Wear protective gloves if necessary.
- To prevent damage, place all parts on a level surface during assembly. Add a layer of protective cover if needed.

#### **Needed for Assembly:**



Screwdriver (Not provided)



Level (Not provided)



Hammer (Not provided)



Power Drill (Not provided)






**NOTE:** Do not over-drill. Be aware of over-drilling.

#### Parts List

Item	Description	Thumbnail	Quantity
1	Top panel		1
2	Bottom panel		1
3	Left side panel		1
4	Right side panel		1
5	Partition		1
6	Adjustable shelf		2
7	Left door		1
8	Right door		1
9	Back rail		1
10	Back panel		1
11	Bar		1

# **Exploded Parts**





#### Hardware List


ltem	Description	Thumbnail	Quantity
А	Door bumper		4
В	Cam lock Ø15x12mm		13
С	Cam bolt Ø6x34mm		13
D	Coated paper sticker		13
Е	Wood dowel Ø8x30mm		13
F	Hinge	Jer Ster	4
G	Handle		2
Н	Bolt Ø4x22mm		4
I	Screw Ø4x14mm		24
J	Wall anchor		2
К	Screw Ø4x55mm		2
L	Screw Ø3x15mm		16
М	Shelf support		8

#### Before You Begin Assembly



#### Make Sure All Parts Are Present

Compare all pieces to the parts and hardware lists, and make sure you have all tools required for assembly.



#### **Assemble in a Cleared Area**

Place all parts from the box on the floor in front of you on a clean, dry, level surface to protect the product as it is being built.




#### **Remove Packaging Materials**

Place packing materials back in the box. Do not dispose of packaging materials until assembly is complete.




#### **Read Each Step Carefully**

Make sure you understand each step. If you have any questions, contact the For LIVING® customer service centre at 1-877-483-6759 (toll free).




#### Step 1




Attach 9 wood dowels (E) to back rail (9) and partition (5).

Attach cam bolt (C) to back rail (9). Do not over tighten.






Step 2




Connect partition (5) to back rail (9) using cam lock (B). Tighten cam lock (B).




9

Step 3




Attach four cam bolts (C) to top panel (1) and bottom panel (2). Do not over tighten.

Attach four wood dowels (E) to the top panel (1) and bottom panel (2).







Step 4




Connect top panel (1) and bottom panel (2) to back rail (9) and partition (5) using four cam locks (B). Tighten cam locks (B).



Step 5




Attach eight cam bolts (C) to left side panel (3) and right side panel (4).





Step 6




Connect left side panel (3) to top panel (1), bottom panel (2) and back rail (9) using four cam locks (B). Tighten cam locks (B).


Insert bar (11) into corresponding hole of left side panel (3).

Connect right side panel (4) to top panel (1), bottom panel (2) and back rail (9) using four cam locks (B), ensuring bar (11) is aligned with the corresponding hole of right side panel (4). Tighten cam locks (B).

Cover all cam locks (B) using 13 coated paper stickers (D).



#### Step 7




Attach back panel (10) to cabinet using 16 screws (L), aligning the holes, then tighten all screws (L).

#### **WARNING:**

Please make sure that the back is attached securely.


All screws must be driven into the parts straight and tightened firmly.

Failure to do so could cause instability,






Step 8




Attach two hinges (F) to left door (7) using two screws (I) each.

Attach handle (G) to left door (7) using two bolts (H).

Place two door bumpers (A) on the corners of left door (7) as shown.




Step 9



Attach two hinges (F) to right door (8) using two screws (I) each.

Attach handle (G) to right door (8) using two bolts (H).

Place two door bumpers (A) on the corners of right door (8) as shown.







Step 10




Attach left door (7) to left side panel (3) using eight screws (1).



Step 11




Attach right door (8) to right side panel (4) using eight screws (I).






Step 12




Pick your desired area of placement. Drill two small holes approximately 3/8" (9.5 mm) in diameter and approximately 2" (5 cm) deep. Use a level (not provided) to make sure the two holes you drill are level. After you drill the holes, insert two wall anchors (J) into wall.


Attach cabinet to wall using two screws (K).



Step 13





Insert eight shelf supports (M) into corresponding holes in left side panel (3), right side panel (4) and partition (5), then place two adjustable shelves (6) as shown.



### **Adjust Doors**








(front view)

DOOR

(front view)



(side view)

If doors are not aligned:

Loosen "A" screws. Adjust door.


Tighten "A" screws.

If there is a gap between doors:

Loosen "C" screw. Turn "B" to move door. Tighten "C" screw. If there is a gap between door and side panel:

Loosen "B" and "C" screw. Adjust door. Tighten "B" and "C" screw.

### Technical Data



#### **Specifications**

•	
Assembled Dimensions (W x D x H)	27 x 12 1/2 x 23 5/8"
	68.6 x 31.8 x 60 cm
Assembled Weight	36 lb 6 oz
	16.5 kg
Maximum Weight Capacity	Top: 15 lb; Shelf: 15 lb; Bar: 10 lb

Top: 6.8 kg; Shelf: 6.8 kg; Bar: 4.5 kg

#### **Assembly Troubleshooting**



Need help? Give us a call! We're here for you.



Before returning your product to store



Toll-free: 1-877-483-6759

If you have questions regarding your product or require warranty assistance, please call our customer service helpline.

#### Caring for Your Item

- Check all nuts and bolts periodically for tightness. When required, tighten them again.
- Always keep children under close supervision while they are using or around this product. Never leave children unattended.
- For household use only.

#### Warranty



#### 1-Year Limited Warranty

This For LIVING® product carries a one (1) year warranty against defects in workmanship and materials. Trileaf Distribution agrees to replace the defective product free of charge within the stated warranty period, when returned by the original purchaser with proof of purchase. This product is not guaranteed against wear or breakage due to misuse and/or abuse.

Model No. 168-0140-8

Made in China

Imported by Trileaf Distribution Trifeuil Toronto, Canada M4S 2B8