




1-Door Pantry Storage Cabinet

Product No. 168-0178-0

Assembly Instructions



**NEED HELP? GIVE US A CALL!
WE'RE HERE FOR YOU.**

TOLL-FREE:

1-877-483-6759

IMPORTANT: Please read this manual carefully before beginning assembly of this product. Keep this manual for future reference.





From your first apartment to
downsizing your family home,
For LIVING® is a great place to start.

Uncomplicate your life with timeless
style and reliable quality that delivers
everyday solutions for your home.

Let us know how our products
work for you. Rate and review at
canadiantire.ca

Table of Contents




Parts List	4	Exchange Door	24
Exploded Parts	5	Adjust Levellers	25
Hardware List	6	Technical Data	26
Before You Begin Assembly	8	Assembly Troubleshooting	26
Step-by-step Guide	9	Caring for Your Item	27
Tip Restraint	21	Warranty	28
Adjust Door	23		




Warning! Please use your furniture correctly and safely. Improper use can cause safety hazards or damage to your furniture or household items. Carefully read the following safety information.

- Please read and understand this entire manual before attempting to assemble, operate, or install the product.
- Any assembly or maintenance of the product must be carried out by adults only.
- Some parts may contain sharp edges. Wear protective gloves if necessary.
- To prevent damage, place all parts on a level surface during assembly.
Add a layer of protective cover if needed.


Needed for Assembly:




Screwdriver
(Not provided)




Level
(Not provided)



Hammer
(Not provided)



Power drill
(Not provided)









2 people




NOTE: Do not over-drill.
Be aware of over-drilling.

Parts List







Item	Description	Thumbnail	Quantity
1	Top panel		1
2	Bottom panel		1
3	Left side panel		1
4	Right side panel		1
5	Fixed shelf		1
6	Back panel		1
7	Back bottom rail		1
8	Left bottom rail		1
9	Right bottom rail		1
10	Front bottom rail		1
11	Adjustable shelf		4
12	Door		1

Exploded Parts

for LIVING®



Hardware List

Item	Description	Thumbnail	Quantity
A	Cam lock		32
B	Cam bolt		32
C	Wood dowel		32
D	Hinge		3
E	Screw ø4 x 14 mm		18
F	Shelf support		16
G	Bolt ø4 x 22 mm		2
H	Handle		1
I	Coated paper sticker		24
J	Adjustable leveller		4
K	Screw ø3.5 x 12 mm		16
L	Screw ø4 x 55 mm		2

Hardware List




Item	Description	Thumbnail	Quantity
M	Screw ø4 x 18 mm	A small icon of a screw with a Phillips head and a threaded shank.	2
N	Metal bracket	A small icon of a metal bracket, which is a U-shaped bracket used to support a horizontal structure.	4
O	Anchor	A small icon of an anchor bolt, which is a threaded bolt with a flared base.	2
P	Nylon strap	A small icon of a coiled strap with metal buckles at both ends.	2

Before You Begin Assembly



Make Sure All Parts Are Present

Compare all pieces to the parts and hardware lists, and make sure you have all tools required for assembly.




Assemble in a Cleared Area

Place all parts from the box on the floor in front of you on a clean, dry, level surface to protect the product as it is being built.





Remove Packaging Materials

Place packing materials back in the box. Do not dispose of packaging materials until assembly is complete.



Read Each Step Carefully


Make sure you understand each step. If you have any questions, contact the For LIVING® customer service centre at 1-877-483-6759 (toll free).



Step-by-step Guide




Step 1




Attach 12 cam bolts (B) to left side panel (3) and right side panel (4). Do not over-tighten.

Insert 16 wood dowels (C) to left side panel (3), right side panel (4) and back panel (6).




Step-by-step Guide

Step 2



Attach 14 cam bolts (B) to top panel (1) and bottom panel (2). Do not over-tighten.


Insert four wood dowels (C) to fixed shelf (5).




Step-by-step Guide



Step 3




Insert 12 wood dowels (C) to back bottom rail (7), left bottom rail (8), right bottom rail (9) and front bottom rail (10).




Step-by-step Guide

Step 4



Attach back bottom rail (7), left bottom rail (8), right bottom rail (9) and front bottom rail (10) together.


Attach bottom panel (2) to back bottom rail (7), left bottom rail (8), right bottom rail (9) and front bottom rail (10) using eight cam locks (A). Tighten cam locks (A).




Step-by-step Guide



Step 5




Attach four adjustable levellers (J) using four screws (K) each.




Step-by-step Guide

Step 6




Attach six cam bolts (**B**) to bottom panel (**2**).



Step-by-step Guide



Step 7




Attach left side panel (3) and right side panel (4) to fixed shelf (5) and back panel (6) using four cam locks (A). Tighten cam locks (A).

Cover cam locks (A) using four coated paper stickers (I).




TEAM LIFT
DO NOT LIFT ALONE




Step-by-step Guide

Step 8



Attach top panel (1) and bottom panel (2) to left side panel (3) and right side panel (4) using eight cam locks (A). Tighten cam locks (A).


Cover cam locks (A) using eight coated paper stickers (I).




Step-by-step Guide



Step 9




Move the unit to its upright position. Then attach top panel (1), bottom panel (2), left side panel (3) and right side panel (4) to back panel (6) using 12 cam locks (A). Tighten cam locks (A).




Step-by-step Guide

Step 10



Attach three hinges (D) to door (12) using two screws (E) each.


Attach handle (H) to door (12) using two bolts (G).



Step-by-step Guide




Step 11



Attach door (12) to right side panel (4) using 12 screws (E).




TEAM LIFT
DO NOT LIFT ALONE




Step-by-step Guide

Step 12




Insert 16 shelf supports (N) into corresponding holes in left side panel (3) and right side panel (4), then place four adjustable shelves (11) as shown.



Tip Restraint




Step 13



Pick your desired area of placement. Affix two small holes approximately 3/8" (9.5 mm) in diameter and approximately 2" (5 cm) deep. Use a level to make sure the two holes you affix are level. After you affix the holes, insert wall anchors (**O**) into wall.

Attach metal brackets (**N**) to wall using screws (**L**).

Attach metal brackets (**N**) to top panel (**1**) using screws (**M**).




Caution! If installing the unit on drywall or other hollow wall applications, the metal bracket must be fastened to studs, headers, or other structural wall supports. The included anchors are intended for use with solid wall applications only (tile or concrete).

DO NOT USE WITH DRYWALL OR OTHER HOLLOW WALL APPLICATIONS.

Tip Restraint


Step 14





Attach cabinet to wall using two nylon straps (**P**) as shown.




Warning! To reduce the risk of serious injury and avoid the potential for furniture tipping over, install the tip restraint hardware.




Adjust Door



(front view)



(front view)



(side view)

If doors are not aligned:

Loosen "A" screws.
Adjust door.
Tighten "A" screws.



If there is a gap between doors:

Loosen "C" screw.
Turn "B" to move door.
Tighten "C" screw.

If there is a gap between door and side panel:

Loosen "B" and "C" screw.
Adjust door.
Tighten "B" and "C" screw.

Exchange Door



1. Loosen the screws on hinges, unassemble door from right panel.


2. Turn the door 180 degrees.

3. Assemble the door to the left panel.


Adjust Levellers



Note: If your item is not level, put it on a hard surface, then adjust the levellers.



Technical Data



Specifications

Assembled Dimensions (W x D x H)

18 x 19 1/8 x 72"

45.7 x 48.6 x 182.8 cm

Assembled Weight

109 lb

49.5 kg

Maximum Weight Capacity

Shelf: 25 lb; Bottom: 50 lb

Shelf: 11.3 kg; Bottom: 22.6 kg

Assembly Troubleshooting



Need help?

Give us a call! We're here for you.

Toll-free: 1-877-483-6759



Before returning your
product to store



If you have questions regarding your product
or require warranty assistance, please call our
customer service helpline.

Caring for Your Item

- 1** Check all screws and bolts periodically for tightness. When required, tighten them again.
- 2** Always keep children under close supervision while they are using or around this product. Never leave children unattended.
- 3** For household use only.
- 4** Wipe clean with damp cloth.

Warranty



1-Year Limited Warranty

This For LIVING® product carries a one (1) year warranty against defects in workmanship and materials. Trileaf Distribution agrees to replace the defective product free of charge within the stated warranty period, when returned by the original purchaser with proof of purchase. This product is not guaranteed against wear or breakage due to misuse and/or abuse.

Model No. 168-0178-0

Made in China

Imported by Trileaf Distribution Trifeuil Toronto, Canada M4S 2B8