


# CANVAS™

## KELSEY 2-DOOR MEDIUM WARDROBE

---

PRODUCT NO. 168-0187-8



### ASSEMBLY INSTRUCTIONS



**HAVING TROUBLE?**

**TOLL-FREE:**

**1-888-670-6684**

IMPORTANT: Please read this manual carefully before beginning assembly of this product. Keep this manual for future reference.

# CANVAS™

INSPIRED BY CANADA



To the trend seekers and design mavens.  
**CANVAS™** is the furniture and décor brand  
that helps you imagine and create a space  
you can be proud of.

That's because **CANVAS™** offers style with  
ease with products that are made for real life  
and Canadian inspired.

We would love to hear from you and welcome  
your thoughtful feedback. Visit our website  
at **canadiantire.ca** to tell us about your  
experience, and share your photos with us  
using **#myCANVAS style**.

Show us how you bring **CANVAS™** products  
to life. We can't wait to see!

## TABLE OF CONTENTS


Parts List .....	4
Before You Begin Assembly .....	8
Step-by-step Guide .....	10
Tip Restraint .....	26
Adjust Door .....	28
Adjust Levellers .....	29
Technical Data .....	30
Caring for Your Item .....	31
Warranty Information .....	32




**WARNING! TO REDUCE THE RISK OF SERIOUS INJURY, READ THE FOLLOWING SAFETY INSTRUCTIONS BEFORE ASSEMBLING AND USING THE PRODUCT.**

- Please read and understand this entire manual before attempting to assemble, operate, or install the product.
- Any assembly or maintenance of the product must be carried out by adults only.
- Some parts may contain sharp edges. Wear protective gloves if necessary.
- To prevent damage, place all parts on a level surface during assembly. Add a layer of protective surface if needed.

## TOOLS REQUIRED




Screwdriver  
(Not provided)




Level  
(Not provided)




Mallet  
(Not provided)



Power Drill  
(Not provided)















2 people




**NOTE:** Do not over-drill.  
Be aware of over-drilling.











## PARTS LIST

ITEM	DESCRIPTION	THUMBNAIL	QUANTITY
1	Top panel		1
2	Bottom panel		1
3	Fixed shelf		1
4	Left side panel		1
5	Right side panel		1
6	Left door		1
7	Right door		1
8	Left back panel		1
9	Right back panel		1
10	Adjustable shelf		3
11	Front bottom rail		1
12	Bottom frame		1









## EXPLODED VIEW



## HARDWARE LIST

ITEM	DESCRIPTION	THUMBNAIL	QUANTITY
A	Cam lock ø15x12mm		26
B	Cam bolt ø6x34mm		26
C	Wood dowel ø8x30mm		36
D	Hinge		6
E	Screw ø4x14mm		40
F	Shelf support		12
G	Bolt ø4x25mm		4
H	Handle		2
I	Coated paper sticker		8
J	Adjustable leveller		4
K	Screw ø3.5x12mm		16
L	Screw ø4x55mm		2
M	Screw ø4x18mm		2


## HARDWARE LIST

ITEM	DESCRIPTION	THUMBNAIL	QUANTITY
N	Metal bracket		4
O	Anchor		2
P	Nylon strap		2
Q	Screw ø4x50mm		4
R	Hanging rod supports		2
S	Hanging rod		1
T	Metal bracket		2
U	Screw ø4x38mm		6

## BEFORE YOU BEGIN ASSEMBLY


### MAKE SURE ALL PARTS ARE PRESENT

Compare all pieces to the parts and hardware lists, and make sure you have all tools required for assembly.




### ASSEMBLE IN A CLEARED AREA

Place all parts from the box on the floor in front of you on a clean, dry, level surface to protect the product as it is being built.




### REMOVE PACKAGING MATERIALS

Place packing materials back in the box. Do not dispose of packaging materials until assembly is complete.



### READ EACH STEP CAREFULLY

Make sure you understand each step. For any questions, contact CANVAS™ customer service at 1-888-670-6684 (toll-free).







## BEFORE YOU BEGIN ASSEMBLY

**NOTE:** IT IS VERY IMPORTANT TO USE GLUE WITH DOWELS. EXCESS GLUE CAN BE WIPED OFF WITH DAMP CLOTH.

Insert the dowel at least half way by tapping lightly with a rubber mallet IF NECESSARY.



## CAM LOCK SYSTEM OPERATION



## HOW THE KNOCK DOWN (KD) ASSEMBLY SYSTEM WORKS

1. Screw the cam bolt into the pre-drilled threaded holes on the panel. Connect both panels together making sure cam bolt goes into the pre-drilled large hole on the end of panel that will accommodate the cam lock.
2. Insert the cam lock into the pre-drilled large hole on the panel. Make sure the arrow on the face of cam lock faces out and points towards cam bolt.
3. Take a cross-head screwdriver and rotate the cam lock clockwise to lock the cam bolt in place.







## SPECIAL NOTE

Please read the instruction sheets completely before assembly. Examine all packaging material before discarding carton. Remove all parts from carton and separate into groups as indicated on parts list. Please ensure all parts are included prior to assembly. Use of power tools to complete assembly is not recommended.

**You are now ready to assemble the KD unit.**


## STEP-BY-STEP GUIDE

### STEP 1

<b>4</b> X1	<b>5</b> X1	<b>B</b> X16	<b>C</b> X4	<b>E</b> X6	<b>R</b> X2
					






Insert sixteen cam bolts **B** into left side panel **4** and right side panel **5**. Do not over-tighten. Insert four wood dowels **C** into left side panel **4** and right side panel **5**.

Attach two hanging rod supports **R** to left side panel **4** and right side panel **5** using three screws **E** each.



## STEP-BY-STEP GUIDE


### STEP 2

<b>1</b> X1	<b>2</b> X1	<b>12</b> X1	<b>B</b> X10	<b>C</b> X8
				

Insert eight cam bolts **B** into top panel **1**. Do not over-tighten.


Insert two cam bolts **B** and six wood dowels **C** into bottom panel **2**.  
Do not over-tighten.

Insert two wood dowels **C** into bottom frame **12**.



## STEP-BY-STEP GUIDE

### STEP 3




Insert four wood dowels **C** into fixed shelf **3**.

Insert nine wood dowels **C** into left back panel **8**.








Insert five wood dowels **C** into right back panel **9**.

Insert six wood dowels **C** into front bottom rail **11**.



## STEP-BY-STEP GUIDE


### STEP 4

<b>6</b> X1	<b>7</b> X1	<b>A</b> X2	<b>D</b> X6	<b>E</b> X12	<b>G</b> X4	<b>H</b> X2
						

Attach front bottom rail **11** to bottom panel **2** using two cam locks **A**. Tighten cam locks **A**.

Attach six hinges **D** to left door **6** and right door **7** using twelve screws **E**.

Attach two handles **H** to left door **6** and right door **7** using four bolts **G**.




## STEP-BY-STEP GUIDE

### STEP 5

**U** X6




Attach bottom frame **12** to bottom panel **2** using six screws **U**.




## STEP-BY-STEP GUIDE

### STEP 6



Attach fixed shelf **3** to right side panel **5** using two cam locks **A**.  
Tighten cam locks **A**.

Cover cam locks **A** using two coated paper stickers **I**.




## STEP-BY-STEP GUIDE

### STEP 7

**A** X2



Attach bottom panel **2** to right side panel **5** using two cam locks **A**.  
Tighten cam locks **A**.






## STEP-BY-STEP GUIDE

### STEP 8

**A** X4




Attach right back panel **9** to right side panel **5** using four cam locks **A**.  
Tighten cam locks **A**.



## STEP-BY-STEP GUIDE




### STEP 9

Attach left back panel **8** to right back panel **9**.



## STEP-BY-STEP GUIDE


### STEP 10

<b>T</b> X2	<b>E</b> X4	<b>Q</b> X4
		

Attach two metal brackets **T** to left back panel **8** and right back panel **9** using four screws **E**.


Attach left back panel **8** and right back panel **9** to bottom panel **2** using four screws **Q**.

Warning: Ensure one person holds panel 8 in place while the other person secures the panels.




## STEP-BY-STEP GUIDE

### STEP 11




Attach left side panel **4** to bottom panel **2**, fixed shelf **3** and left back panel **8** using eight cam locks **A**. Tighten cam locks **A**.

Cover cam locks **A** using two coated paper stickers **I** on fixed shelf **3**.




## STEP-BY-STEP GUIDE

### STEP 12




Attach top panel **1** to left side panel **4**, right side panel **5**, left back panel **8** and right back panel **9** using eight cam locks **A**. Tighten cam locks **A**.

Cover cam locks **A** using two coated paper stickers **I** on left side panel **4** and right side panel **5** each.




## STEP-BY-STEP GUIDE

### STEP 13



Attach four adjustable levellers **J** to left side panel **4**, front bottom rail **11**, right side panel **5**, left back panel **8** and right back panel **9** using four screws **K** each.




## STEP-BY-STEP GUIDE

### STEP 14

**E** X18




Attach left door **6** and right door **7** to left side panel **4** and right side panel **5** using eighteen screws **E**.




## STEP-BY-STEP GUIDE

### STEP 15



Insert twelve shelf supports **F** into left side panel **4** and right side panel **5**.


Place three adjustable shelves **10** on shelf supports **F**.






## STEP-BY-STEP GUIDE

### STEP 16







Place hanging rod **S** on hanging rod supports **R**.



Note: Please tighten the bolt.

## TIP RESTRAINT


### STEP 17

L X2	M X2	N X4	O X2
			

Pick your desired area of placement. Drill two small holes approximately 3/8" (9.5 mm) in diameter and approximately 2" (5 cm) deep. Use a level to make sure the two holes you drill are level. After you drill the holes, insert wall anchors **O** into wall.

Attach metal brackets **N** to wall using screws **L**.


Attach metal brackets **N** to top panel **1** using screws **M**.



## TIP RESTRAINT

### STEP 18




**P** X2





Attach cabinet to wall using two nylon straps **P** as shown.



**WARNING!** TO REDUCE THE RISK OF SERIOUS INJURY AND AVOID THE POTENTIAL FOR FURNITURE TIPPING OVER, INSTALL THE TIP-OVER RESTRAINT HARDWARE.




## ADJUST DOOR




(front view)

If doors are not aligned:  
Loosen "A" screws.  
Adjust door.  
Tighten "A" screws.



(front view)

If there is a gap between doors:  
Loosen "C" screw.  
Turn "B" to move door.  
Tighten "C" screw.




(side view)


If there is a gap between door and side panel:  
Loosen "B" and "C" screw.  
Adjust door.  
Tighten "B" and "C" screw.

## ADJUST LEVELLERS

Note: If your item is not level, put it on a hard surface, then adjust the levellers.



## TECHNICAL DATA



## SPECIFICATIONS

### ASSEMBLED DIMENSIONS (W x D x H)

76.2 x 57.8 x 203.2 cm

30 x 22 3/4 x 80"

### ASSEMBLED WEIGHT

88.3 kg

194 lb

**MAXIMUM WEIGHT CAPACITY** Adjustable shelf: 11.3 kg (25 lb); Fixed shelf: 13.6 kg (30 lb);  
Bottom: 13.6 kg (30 lb); Rod: 13.6 kg (30 lb)

## ASSEMBLY TROUBLESHOOTING



**BEFORE RETURNING  
YOUR PRODUCT**

**HAVING TROUBLE?  
LET US HELP YOU!**

**TOLL-FREE:  
1-888-670-6684**

If you have questions regarding your product or require warranty assistance, please call our customer service helpline.



**CALL US;  
WE CAN HELP**

## CARING FOR YOUR ITEM

- 1 Always use unit with tip-restraints installed as per instructions.
- 2 Always keep children under close supervision while they are using or around this product. Never leave children unattended.
- 3 For household use only.
- 4 Wipe clean with damp cloth.

## WARRANTY INFORMATION



### 1-YEAR LIMITED WARRANTY

This CANVAS™ product carries a one (1) year warranty against defects in workmanship and materials. Trileaf Distribution agrees to replace the defective product free of charge within the stated warranty period, when returned by the original purchaser with proof of purchase. This product is not guaranteed against wear or breakage due to misuse and/or abuse.

PRODUCT NO. 168-0187-8

Made in China

Imported by Trileaf Distribution Trifeuil Toronto, Canada M4S 2B8



# CANVAS™

INSPIRED BY CANADA

