


CANVAS^{TM/MC}

Invermere 2-Cube Organizer

PRODUCT NO. 168-0215-2



ASSEMBLY INSTRUCTIONS



HAVING TROUBLE?

TOLL-FREE:

1-888-670-6684

IMPORTANT: Please read this manual carefully before beginning assembly of this product. Keep this manual for future reference.

CANVAS™

REDISCOVER YOUR SPACE



To the trend seekers and design mavens,
CANVAS™ is the furniture and décor brand
that helps you imagine and create a space
you can be proud of.

That's because **CANVAS™** offers style with
ease with products that are **made for real life**
and Canadian inspired.

We would love to hear from you and welcome
your thoughtful feedback. Visit our website
at **canadiantire.ca** to tell us about your
experience, and share your photos with us
using **#myCANVASstyle**.

Show us how you bring **CANVAS™** products
to life. We can't wait to see!

TABLE OF CONTENTS


Parts List	4
Before You Begin Assembly	7
Step-by-step Guide	9
Technical Data	13
Caring for Your Item	14
Warranty	14




WARNING! TO REDUCE THE RISK OF SERIOUS INJURY, READ THE FOLLOWING SAFETY INSTRUCTIONS BEFORE ASSEMBLING AND USING THE PRODUCT.

- Please read and understand this entire manual before attempting to assemble, operate, or install the product.
- Follow all warning labels.
- Any assembly or maintenance of the product must be carried out by adults only.
- Some parts may contain sharp edges. Wear protective gloves if necessary.
- To prevent damage, place all parts on a level surface during assembly. Add a layer of protective surface if needed.
- Due to the nature of steel, surface oxidation (rusting) will occur if the protective coating is scratched. This is a natural process. To minimize this condition, it is recommended that care be taken when assembling and handling the product in order to prevent the paint from being scratched.


TOOLS REQUIRED



No. 2 Cross-head Screwdriver
Tip Shown Actual Size








NOTE: Do not over-drill.
Be aware of over-drilling.




2 people

PARTS LIST


ITEM	DESCRIPTION	THUMBNAIL	QUANTITY
1	Top panel		1
2	Shelf		1
3	Bottom panel		1
4	Left panel		1
5	Right panel		1

EXPLODED VIEW



Warning: Before assembly, please check all accessories in the hardware box, and ensure parts are not missing.


HARDWARE LIST

ITEM	DESCRIPTION	THUMBNAIL	QUANTITY
A	Screw M7x70mm		12
B	Wood dowel M8x30mm		12
C	Anti-tip bracket		1
D	Wall anchor		1
E	Screw M4x12mm		1
F	Screw M4x35mm		1
G	Hex key		1
H	Coated paper sticker		12
I	EVA foot pad		4

BEFORE YOU BEGIN ASSEMBLY


MAKE SURE ALL PARTS ARE PRESENT

Compare all pieces to the parts and hardware lists, and make sure you have all tools required for assembly.




ASSEMBLE IN A CLEARED AREA

Place all parts from the box on the floor in front of you on a clean, dry, level surface to protect the product as it is being built.




REMOVE PACKAGING MATERIALS

Place packing materials back in the box. Do not dispose of packaging materials until assembly is complete.




READ EACH STEP CAREFULLY

Make sure you understand each step. If you have any questions, contact CANVAS™ customer service at 1-888-670-6684 (toll free).



BEFORE YOU BEGIN ASSEMBLY

CAM LOCK SYSTEM OPERATION




1. Screw cam bolt into the pre-drilled small holes on panel. Align the panels to be joined so that the cam bolt goes into the pre-drilled hole on the edge of the second panel and protrudes into the hole that will house the cam lock.
2. Insert the cam lock into pre-drilled large hole on panel. Make sure arrow on the cam lock is pointed toward the cam bolt.
3. Once the cam bolt is connected inside cam lock, take a cross-head screwdriver and tighten the cam lock by turning clockwise.


You are now ready to assemble the product.

STEP-BY-STEP GUIDE

STEP 1



Insert four wood dowels **B** into both sides of shelf **2**.
Insert the other ends of wood dowels into left panel **4** and right panel **5**.
Insert four screws M7x70 **A** through left panel **4** and right panel **5**.
Use hex key **G** to tighten all screws.




STEP-BY-STEP GUIDE

STEP 2


1 x1	3 x1	A x8	B x8	G x1

Insert eight wood dowels **B** into each end of left panel **4** and right panel **5**. Insert the other ends of wood dowels into top panel **1** and bottom panel **3**. Insert eight screws M7x70 **A** through top panel **1** and bottom panel **3**. Use hex key **G** to tighten all screws.




STEP-BY-STEP GUIDE

STEP 3




Paste eight coated paper sticker **H** onto all cam bolt holes.
Paste four EVA foot pads **I** onto the bottom panel **3**.



STEP-BY-STEP GUIDE


STEP 4




Fasten anti-tip bracket **C** to the item with screw M4x12 **E**.

Drill a hole and insert one wall anchor **D** into the wall. Hammer wall anchor into the wall.

Fasten the anti-tip bracket **C** to the wall with one screw M4x35 **F**.



TECHNICAL DATA



SPECIFICATIONS

ASSEMBLED DIMENSIONS (W x D x H)

41.9 x 36.8 x 77.9 cm

16 1/2 x 14 1/2 x 30 11/16"

ASSEMBLED WEIGHT

12.9 kg

28 lb 7 oz

MAXIMUM WEIGHT CAPACITY (Top and bottom)

10 kg

22 lb

MAXIMUM WEIGHT CAPACITY (Shelf)

5 kg

11 lb

ASSEMBLY TROUBLESHOOTING



**BEFORE RETURNING
YOUR PRODUCT**

**HAVING TROUBLE?
LET US HELP YOU!**

**TOLL-FREE:
1-888-670-6684**

If you have questions regarding your product or require warranty assistance, please call our customer service helpline.



**CALL US;
WE CAN HELP**

CARING FOR YOUR ITEM

1

Weight Capacity:

- Do not exceed maximum weight capacity of 5 kg (11 lb) on shelf.
- Do not exceed maximum weight capacity of 10 kg (11 lb) on top and bottom.

2

Furniture tipping over can be dangerous. To reduce your risk:

- Do not stand on, sit on or climb this unit.
- Do not sit on top of unit.
- For indoor use only.
- Always place the unit on a flat, level surface.
- Regularly tighten all hardware to ensure unit is secure and stable.

3

Wipe clean with a damp cloth.

4

Avoid placing in direct sunlight.

WARRANTY INFORMATION



1-YEAR LIMITED WARRANTY*

This CANVAS™ product carries a one (1) year warranty against defects in workmanship and materials. Trileaf Distribution agrees to replace the defective product free of charge within the stated warranty period, when returned by the original purchaser with proof of purchase. This product is not guaranteed against wear or breakage due to misuse and/or abuse.

PRODUCT NO. 168-0215-2

Made in China

Imported by Trileaf Distribution Trifeuil Toronto, Canada M4S 2B8

CANVAS™

REDISCOVER YOUR SPACE

