



CANVAS™

EVELYN DINING CHAIR

PRODUCT NO. 168-0228-2



ASSEMBLY INSTRUCTIONS



HAVING TROUBLE?

TOLL-FREE:

1-888-670-6684

IMPORTANT: Please read this manual carefully before beginning assembly of this product. Keep this manual for future reference.

CANVAS™

REDISCOVER YOUR SPACE



We believe in the power of décor and its ability to make up the fabric of your home.

That's why **CANVAS™** collections draw **inspiration from Canadians and the way they live.**

From on-trend furniture pieces to holiday décor and all your outdoor living essentials, **CANVAS™** makes it easy to refresh your space to reflect **your unique style and the way you live every day.**

We would love to hear from you and welcome your thoughtful feedback. Visit our website at **canadiantire.ca** to tell us about your experience, and share your photos with us using **#myCANVASstyle.**

Show us how you bring **CANVAS™** products to life. We can't wait to see!

TABLE OF CONTENTS


Parts List	4
Exploded Parts	5
Hardware List	6
Before You Begin Assembly	7
Step-by-step Guide	8
Technical Data	15
Troubleshooting	16
Caring for Your Item	16
Warranty	17



WARNING! TO REDUCE THE RISK OF SERIOUS INJURY, READ THE FOLLOWING SAFETY INSTRUCTIONS BEFORE ASSEMBLING AND USING THE PRODUCT.

- Please read and understand this entire manual before attempting to assemble, operate, or install the product.
- Any assembly or maintenance of the product must be carried out by adults only.
- Some parts may contain sharp edges. Wear protective gloves if necessary.
- To prevent damage, place all parts on a level surface during assembly. Add a layer of protective surface if needed.
- Due to the nature of steel, surface oxidation (rusting) will occur if this protective coating is scratched. This is a natural process. To minimize this condition, it is recommended that care be taken when assembling and handling the product in order to prevent the paint from being scratched.

TOOLS REQUIRED








NOTE: To avoid damage, ensure screws are hand tightened. DO NOT USE POWER TOOLS TO ASSEMBLE YOUR UNIT.




1 person






PARTS LIST

ITEM	DESCRIPTION	THUMBNAIL	QUANTITY
1	Back		1
2	Seat		1
3	Back frame		1
4	Upper metal leg		1
5	Bottom metal leg		1

EXPLODED PARTS




HARDWARE LIST

ITEM	DESCRIPTION	THUMBNAIL	QUANTITY
A	Hex key		1
B	Bolt M6x10mm		4
C	Bolt M6x18mm		9
D	Bolt M6x20mm		4
E	Washer Ø6*Ø14		12

BEFORE YOU BEGIN ASSEMBLY


MAKE SURE ALL PARTS ARE PRESENT

Compare all pieces to the parts and hardware lists, and make sure you have all tools required for assembly.




ASSEMBLE IN A CLEARED AREA

Place all parts from the box on the floor in front of you on a clean, dry, level surface to protect the product as it is being built.




REMOVE PACKAGING MATERIALS

Place packing materials back in the box. Do not dispose of packaging materials until assembly is complete.




READ EACH STEP CAREFULLY

Make sure you understand each step. If you have any questions, contact CANVAS™ customer service at 1-888-670-6684 (toll free).





STEP-BY-STEP GUIDE

STEP 1




Attach upper metal leg (4) to seat (2) with four washers (E) and four bolts (C). Tighten with hex key (A), but do not fully tighten.




STEP-BY-STEP GUIDE

STEP 2




Attach bottom metal leg (5) to seat (2) with four washers (E) and five bolts (C). Tighten with hex key (A), but do not fully tighten.




STEP-BY-STEP GUIDE

STEP 3




Install the back frame (3) to the legs (4) and (5) as shown. Align the bolt holes.





STEP-BY-STEP GUIDE

STEP 4




Attach back frame (3) and legs (4) and (5) with four bolts (B) using the hex key (A).





STEP-BY-STEP GUIDE

STEP 5




Tighten all the bolts under the seat with hex key (A).





STEP-BY-STEP GUIDE

STEP 6




Attach back (1) to back frame (3) with four washers (E) and four bolts (D). Tighten with hex key (A). Fully tighten all the screws. Assembly complete.




STEP 7

To accommodate uneven floors, adjust the levelling feet.

**NOTE:**

Do not over-extend or over-tighten the adjustable feet.

TECHNICAL DATA



SPECIFICATIONS

ASSEMBLED DIMENSIONS (W x D x H)

47 x 51.5 x 82 cm

18 1/2 x 20 5/16 x 32 5/16"

ASSEMBLED WEIGHT

5.53 kg

12 lb 3 oz

MAXIMUM WEIGHT CAPACITY

100 kg

220 lb

TROUBLESHOOTING



**BEFORE RETURNING
YOUR PRODUCT**

**HAVING TROUBLE?
LET US HELP YOU!**

**TOLL-FREE:
1-888-670-6684**

If you have questions regarding your product or require warranty assistance, please call our customer service helpline.



**CALL US;
WE CAN HELP**

CARING FOR YOUR ITEM

- 1** Spot clean fabric with mild detergent. Wipe legs with clean, damp cloth. Do not use bleach, acid or other abrasive cleaners.
- 2** Do not stand or step on this stool.
- 3** Do not sit on the front edge of the stool. Use for seating only one person at one time.
- 4** Do not use this stool until all bolts are firmly secured.
- 5** Do not exceed maximum weight capacity of 100 kg (220 lb).
- 6** This product is intended for domestic, indoor use only. Avoid direct contact with sunlight.

WARRANTY INFORMATION



1-YEAR LIMITED WARRANTY*

This CANVAS™ product carries a one (1) year warranty against defects in workmanship and materials. Trileaf Distribution agrees to replace the defective product free of charge within the stated warranty period, when returned by the original purchaser with proof of purchase. This product is not guaranteed against wear or breakage due to misuse and/or abuse.

PRODUCT NO. 168-0228-2

Made in China

Imported by Trileaf Distribution Trifeuil Toronto, Canada M4S 2B8

CANVAS™

REDISCOVER YOUR SPACE

