CANVAS™

LANGDON WIDE BOOKCASE

PRODUCT NO. 168-0269-4



ASSEMBLY INSTRUCTIONS

HAVING TROUBLE?

TOLL-FREE:
1-888-670-6684

IMPORTANT: Please read this manual carefully before beginning assembly of this product. Keep this manual for future reference.

CANVAS™

INSPIRED BY CANADA

To the trend seekers and design mavens. **CANVAS™** is the furniture and décor brand that helps you imagine and create a space you can be proud of.

That's because **CANVAS™** offers style with ease with products that are **made for real life and Canadian inspired.**

We would love to hear from you and welcome your thoughtful feedback. Visit our website at **canadiantire.ca** to tell us about your experience, and share your photos with us using **#myCANVAS style**.

Show us how you bring **CANVAS™** products to life. We can't wait to see!

TABLE OF CONTENTS

Parts List 4
Before You Begin Assembly 8
Step-by-step Guide 10
Tip-Over Restraint 22
Adjust Levellers 24
Adjust Door 25
Technical Data 26
Assembly Troubleshooting 27
Caring for Your Item 27
Warranty Information 28

WARNING! TO REDUCE THE RISK OF SERIOUS INJURY, READ THE FOLLOWING SAFETY INSTRUCTIONS BEFORE ASSEMBLING AND USING THE PRODUCT.

- Please read and understand this entire manual before attempting to assemble, operate, or install the product.
- Any assembly or maintenance of the product must be carried out by adults only.
- Some parts may contain sharp edges. Wear protective gloves if necessary.
- To prevent damage, place all parts on a level surface during assembly. Add a layer of protective surface if needed.

TOOLS REQUIRED



Screwdriver
(Not provided)



Level
(Not provided)



Mallet
(Not provided)



Power Drill
(Not provided)



2 people



NOTE: Do not over-drill. Be aware of over-drilling.

PARTS LIST

ITEM	DESCRIPTION	THUMBNAIL	QUANTITY
1	Top panel		1
2	Bottom panel		1
3	Top shelf		1
4	Left side panel		1
5	Right side panel		1
6	Door		1
7	Back panel		1
8	Middle shelf		2
9	Upper back rail		4
10	Bottom rail		1
11	Upper metal frame		3
12	Left lower metal frame		1
13	Lower back rail		1
14	Middle lower metal frame		1
15	Right lower metal frame		1

EXPLODED VIEW



HARDWARE LIST

ITEM	DESCRIPTION	THUMBNAIL	QUANTITY
A	Cam lock ø15x12mm		12
B	Cam bolt ø6x34mm		12
C	Wood dowel ø8x30mm		30
D	Hinge		2
E	Screw ø4x14mm		12
F	Screw ø3x12mm		2
G	Screw ø4x38mm		23
H	Handle		1
I	Coated paper sticker		12
J	Short bolt		16
K	Long bolt		30
L	Screw ø4x55mm		2
M	Screw ø4x18mm		2

HARDWARE LIST

ITEM	DESCRIPTION	THUMBNAIL	QUANTITY
N	Metal bracket		4
O	Anchor		2
P	Steel cable		2
Q	Allen key		1

BEFORE YOU BEGIN ASSEMBLY

MAKE SURE ALL PARTS ARE PRESENT

Compare all pieces to the parts and hardware lists, and make sure you have all tools required for assembly.



ASSEMBLE IN A CLEARED AREA

Place all parts from the box on the floor in front of you on a clean, dry, level surface to protect the product as it is being built.



REMOVE PACKAGING MATERIALS

Place packing materials back in the box. Do not dispose of packaging materials until assembly is complete.



READ EACH STEP CAREFULLY

Make sure you understand each step. For any questions, contact CANVAS™ customer service at 1-888-670-6684 (toll-free).



CAM LOCK SYSTEM OPERATION



HOW THE KNOCK DOWN (KD) ASSEMBLY SYSTEM WORKS

1. Screw the cam bolt into the pre-drilled threaded holes on the panel. Connect both panels together, making sure cam bolt goes into the pre-drilled large hole on the end of the panel that will accomodate the cam lock.
2. Insert the cam lock into the pre-drilled large hole on the panel. Make sure the arrow on the face of the cam lock faces out and points towards cam bolt.
3. Take a cross-head screwdriver, and rotate the cam lock clockwise to lock the cam bolt in place.

STEP 1



Insert twelve cam bolts **B** into top panel **1**, left side panel **4**, and right side panel **5**. Do not over-tighten.



STEP 2

2 X1	3 X1	8 X2	9 X4	13 X1	G X19	C X14
						

Attach back rails **9** to top panel **1**, top shelf **3**, and middle shelves **8** using four screws **G** and three wood dowels **C** in each.

Attach lower back rail **13** to bottom panel **2** using three screws **G** and two wood dowels **C**.



STEP 3



Attach right side panel **5** to back panel **7** using two cam locks **A** and two wood dowels **C**. Tighten cam locks **A**.



STEP 4



Attach bottom panel **2** to back panel **7** and right side panel **5** using four screws **G** and four wood dowels **C**.



STEP 5

A X4	C X4

Attach left side panel **4** to bottom panel **2** and back panel **7** using four cam locks **A** and four wood dowels **C**. Tighten cam locks **A**.



STEP 6



Attach top panel **1** to the assembled unit using six cam locks **A** and six wood dowels **C**. Tighten cam locks **A**.



STEP 7

11 X3	12 X1	14 X1	15 X1	J X12	Q X1
					

Attach three upper metal frames **11** to lower metal frames **(12, 14, and 15)** using four short bolts **J** in each. Tighten bolt by Allen key **Q**.



STEP 8



Attach the shelfs **(3 and 8)** and cabinet assemblies to the left metal frame **(11 and 12)** using eight long bolts **K** as shown. Tighten bolt by Allen key **Q**.



STEP 9



To avoid scratching the finishes, it is recommended for two people to position the middle frame for assembly.

Attach the shelf and cabinet assemblies to the middle metal frame **(11 and 14)** using ten long bolts **K** as shown. Tighten bolt by Allen key **Q**.



STEP 10



Attach the shelf and cabinet assemblies to the right metal frame **(11 and 15)** using ten long bolts **K** as shown.

Attach the bottom rail **10** to the assembled unit using four short bolts **J** and two long bolts **K**. Tighten bolt by Allen key **Q**.



STEP 11

6 X1	D X2	E X4
		

Attach two hinges **D** to door **6** using four screws **E**.



STEP 12



Align two hinges **D** to left side panel **4**.

Attach door **6** with eight screws **E**.

Attach handle **H** to door **6** using two screws **F**.

Place coated paper stickers **I** over visible cam locks **A**.





TIP-OVER RESTRAINT

STEP 13

L X2	M X2	N X4	O X2
			

Choose the spot where you want to place your bookcase. Drill two small holes approximately 3/8” (9.5 mm) in diameter and approximately 2” (5 cm) deep into the wall. Use a level to make sure the two holes you drill are level. After you drill the holes, insert wall anchors **O** into wall.

Attach metal brackets **N** to wall using screws **L**.

Attach metal brackets **N** to top shelf **3** using screws **M**.



TIP-OVER RESTRAINT

STEP 14



Attach cabinet to wall using two steel cables **P** as shown.

WARNING! TO REDUCE THE RISK OF SERIOUS INJURY AND AVOID THE POTENTIAL FOR FURNITURE TIPPING OVER, INSTALL THE TIP-OVER RESTRAINT HARDWARE.



ADJUST LEVELLERS

Note: If your item is not level, then adjust the levellers.



Note: Feet levelling pre-installed

ADJUST DOOR





(front view)

If doors are not aligned:

Loosen "A" screws.
Adjust door.
Tighten "A" screws.



(front view)

If there is a gap between doors:

Loosen "C" screw.
Turn "B" to move door.
Tighten "C" screw.



(side view)

If there is a gap between door and side panel:

Loosen "B" and "C" screws.
Adjust door.
Tighten "B" and "C" screws.

TECHNICAL DATA



SPECIFICATIONS

ASSEMBLED DIMENSIONS (W x D x H)	42 1/4 x 16 x 72″
	107.2 x 40.6 x 182.9 cm
ASSEMBLED WEIGHT	78 lb 4 oz
	35.5 kg
MAXIMUM WEIGHT CAPACITY	All shelves: 20 lb (9.07 kg)

ASSEMBLY TROUBLESHOOTING

BEFORE RETURNING YOUR PRODUCT

HAVING TROUBLE? LET US HELP YOU!

TOLL-FREE:
1-888-670-6684

If you have questions regarding your product or require warranty assistance, please call our customer service helpline.

CALL US; WE CAN HELP

CARING FOR YOUR ITEM

1. Always use unit with tip-restraints installed as per instructions.
2. Always keep children under close supervision while they are using or around this product. Never leave children unattended.
3. For household use only.

WARRANTY INFORMATION

1-YEAR LIMITED WARRANTY

This CANVAS™ product carries a one (1) year warranty against defects in workmanship and materials. Trileaf Distribution agrees to replace the defective product free of charge within the stated warranty period, when returned by the original purchaser with proof of purchase. This product is not guaranteed against wear or breakage due to misuse and/or abuse.

PRODUCT NO. 168-0269-4

Made in Vietnam

Imported by Trileaf Distribution Trifeuil Toronto, Canada M4S 2B8

CANVAS™

REDISCOVER YOUR SPACE