


CANVAS^{TM/MC}

EDENVALE 4-PIECE SECTIONAL SET

PRODUCT NO. 188-0280-6



ASSEMBLY INSTRUCTIONS



HAVING TROUBLE?

TOLL-FREE:

1-888-670-6684

IMPORTANT: Please read this manual carefully
before beginning assembly of this product.
Keep this manual for future reference.

Production Number: xxxxxxxx

CANVAS™

INSPIRED BY CANADA



To the trend seekers and design mavens,
CANVAS™ is the furniture and décor brand
that helps you imagine and create a space
you can be proud of.

That's because **CANVAS™** offers style with
ease with products that are **made for real life
and Canadian inspired.**

We would love to hear from you and welcome
your thoughtful feedback. Visit our website
at **canadiantire.ca** to tell us about your
experience, and share your photos with us
using **#myCANVASstyle.**

Show us how you bring **CANVAS™** products
to life. We can't wait to see!

TABLE OF CONTENTS

Important Safety Instructions	3
Parts List	4
Before You Begin Assembly	8
Step-by-step Guide	9
Technical Data	19
Troubleshooting	20
Caring for Your Item	20
Limited Warranty	21

IMPORTANT SAFETY INSTRUCTIONS



WARNING: To reduce the risk of serious injury, read the following safety instructions before assembly and use of the sectional.

- This product is intended for domestic, outdoor use only.
- The product should be placed on flat, horizontal ground.
- Any assembly or maintenance of the product must be carried out by adults only.
- Some parts may contain sharp edges. Wear protective gloves if necessary.
- Keep children and pets away while setting up the sectional.
- Check all nuts and bolts periodically for tightness. When required, tighten them again.
- Keep the original packaging until assembly is complete.



Let us help you!

DO NOT RETURN YOUR PRODUCT TO THE STORE. CALL US FIRST!
1-888-670-6684

If you have questions regarding your product, require warranty assistance, or have damaged or missing parts, please call our customer service toll-free helpline. Contact us for assistance; we're here to help.


IMPORTANT: Please read and understand this manual before any assembly. Before beginning assembly of the product, make sure all parts are available. Compare parts with package contents list. If any part is missing, or if you have any questions, contact the service centre at 1-888-670-6684 (toll-free).

Take all parts from the box and position them on a clean floor. Remove all packing materials and place them back into the box. Do not dispose of the packing materials until assembly is complete. Read each step carefully before beginning any assembly and make sure you understand each step.

TOOLS REQUIRED













Hex key (included)













2 people







PARTS LIST

ITEM	DESCRIPTION	THUMBNAIL	QUANTITY
A P00150015801	3-Seat Sofa Back		1
B P00140038601	Left Armrest (Pre-assembled)		1
C P00140038701	Right Armrest (Pre-assembled)		1
D P00160029301	3-Seat Sofa Seat		1
E P00540071001	Chair Leg		12
F P00180022201	Seat Cushion		6
G P00170001401	Back Cushion		5
J H990030025	Adjustable Foot (Pre-assembled)		16
K P00170001201	Corner Back Cushion (Big)		1
L P00170001301	Corner Back Cushion (Small)		1


PARTS LIST

ITEM		DESCRIPTION	THUMBNAIL	QUANTITY
M	P00540071101	Support Leg		3
N	H990030038	Plastic Plug (Pre-assembled)		3
P	P00150015701	Loveseat Back		1
Q	P00160029401	Loveseat Seat		1
R	P00150015901	Corner Back 1 (Long) (Pre-assembled)		1
S	P00150016001	Corner Back 2 (Short) (Pre-assembled)		1
T	P00160029501	Corner Seat		1
U	P00210056801	Table Top		1
V	P00540071201	Table Leg		4
W	P00050198601	Spacer		4

PARTS LIST

ITEM		DESCRIPTION	THUMBNAIL	QUANTITY
H1	H010030047	Bolt (M6*20)		48+5 Spare
H2	H010030103	Bolt (M6*45)		13+1 Spare
H3	H010030119	Bolt (M6*65)		4+1 Spare
H4	H050070012	Flat Washer M6		65+7 Spare
H5	H100090001	Wing Bolts and Square Wing Nuts (M8*70)		4+1 Spare
HW	H090030002	Hex Key M6		1


EXPANDED VIEW



BEFORE YOU BEGIN ASSEMBLY


MAKE SURE ALL PARTS ARE PRESENT

Compare all pieces to the parts and hardware lists, and make sure you have all tools required for assembly.




ASSEMBLE IN A CLEARED AREA

Place all parts from the box on the floor in front of you on a clean, dry, level surface to protect the product as it is being assembled.




REMOVE PACKAGING MATERIALS

Place packing materials back in the box. Do not dispose of packaging materials until assembly is complete.



READ EACH STEP CAREFULLY


Make sure you understand each step. If you have questions, contact CANVAS™ customer service at 1-888-670-6684 (toll-free).



STEP-BY-STEP GUIDE


STEP 1

Attach the 3-seat sofa back **A** & left armrest **B** to 3-seat sofa seat **D** using bolts **H2** and **H3** and washers **H4**, aligning the holes. Do not tighten completely.



NOTE:


Do not tighten screws all the way until you have assembled the sofa. Once assembly is complete, tighten each screw.



STEP-BY-STEP GUIDE


STEP 2

Attach the chair legs **E** to the underside of the sofa using bolts **H1** and washers **H4**, aligning the holes. Tighten all bolts.



NOTE:

Do not tighten screws all the way until you have assembled the sofa. Once assembly is complete, tighten each screw.




STEP-BY-STEP GUIDE

STEP 3

Attach the support legs **M** to the underside of the sofa, aligning the holes.


M X2



STEP-BY-STEP GUIDE


STEP 4

Attach the loveseat back **P** & right armrest **C** to loveseat seat **Q** using bolts **H2** and **H3** and washers **H4**, aligning the holes. Do not tighten completely.



NOTE:



Do not tighten screws all the way until you have assembled the sofa. Once assembly is complete, tighten each screw.



STEP-BY-STEP GUIDE

STEP 5

Attach the chair legs **E** to the underside of the loveseat using bolts **H1** and washers **H4**, aligning the holes. Tighten all bolts.



NOTE:


Do not tighten screws all the way until you have assembled the sofa. Once assembly is complete, tighten each screw.

STEP-BY-STEP GUIDE

STEP 6

Attach the support leg **M** to the underside of the loveseat, aligning the holes.

M X1





NOTE:

Do not tighten screws all the way until you have assembled the sofa. Once assembly is complete, tighten each screw.

STEP-BY-STEP GUIDE

STEP 7

Attach the chair legs **E** to the underside of the corner seat **T** using bolts **H1** and washers **H4**, aligning the holes.





NOTE:

Do not tighten screws all the way until you have assembled the sofa. Once assembly is complete, tighten each screw.

STEP-BY-STEP GUIDE

STEP 8

Turn the table top **U** upside down and attach the table legs **V** to the underside of the table top using bolts **H1** and washers **H4**, aligning the holes.






NOTE:

Do not tighten screws all the way until you have assembled the sofa. Once assembly is complete, tighten each screw.

STEP-BY-STEP GUIDE

STEP 9



Use wing bolts and wing nuts **H5** and spacer **W** to fix the seat.




STEP-BY-STEP GUIDE

STEP 10

Place seat cushions **F** and back cushions **G**, **L** and **K** on the sectional.



TECHNICAL DATA



SPECIFICATIONS (3-seat Sofa)

ASSEMBLED DIMENSIONS (W x D x H)	86 x 30 x 28 15/16"
	218.5 x 76.2 x 73.5 cm

SPECIFICATIONS (Loveseat)

ASSEMBLED DIMENSIONS (W x D x H)	62 x 30 x 28 15/16"
	157.5 x 76.2 x 73.5 cm

SPECIFICATIONS (Corner Chair)

ASSEMBLED DIMENSIONS (W x D x H)	29 15/16 x 29 15/16 x 28 15/16"
	76 x 76 x 73.5 cm

SPECIFICATIONS (Coffee Table)

ASSEMBLED DIMENSIONS (W x D x H)	48 x 25 x 15"
	122 x 63.5 x 38.1 cm

ASSEMBLED WEIGHT	151 lb 10 oz
	68.8 kg

MAXIMUM WEIGHT CAPACITY PER SEAT	225 lb
	102 kg

ASSEMBLED SECTIONAL DIMENSIONS

WIDTH: 115 15/16" (294.5 cm)	DEPTH: 91 15/16" (233.5 cm)
HEIGHT: 28 15/16" (73.5 cm)	SEAT HEIGHT: 18 1/8" (46 cm)

TROUBLESHOOTING



**BEFORE RETURNING
YOUR PRODUCT**

**HAVING TROUBLE?
LET US HELP YOU!**

**TOLL-FREE:
1-888-670-6684**



**CALL US,
WE CAN HELP**

If you have questions regarding your product or require warranty assistance, please call our customer service helpline.

CARING FOR YOUR ITEM

- 1 We recommend the use of furniture covers when not in use.
- 2 The cushion may be spot cleaned on the surface only; do not clean in washing machine.
- 3 Clean and dry before storing in a dry, sheltered area.
- 4 Clean the chair frame with mild soap and water. Rinse thoroughly.
- 5 Do not use bleach, acid or other abrasive cleaners on the chair or frame parts.

LIMITED WARRANTY



5-YEAR LIMITED WARRANTY

This CANVAS product carries a five (5) year warranty against defects in workmanship and materials on the frame and wicker a one (1) year warranty for the remaining parts. Trileaf Distribution agrees to replace a defective product free of charge within the stated warranty period, when returned by the original purchaser with proof of purchase. This product is not guaranteed against wear or breakage due to misuse and/or abuse.

PRODUCT NO. 188-0280-6

Made in China

Imported by Trileaf Distribution Trifeuil Toronto, Canada M4S 2B8

CANVAS™


INSPIRED BY CANADA



CANVAS^{TM/MC}

ENSEMBLE MODULAIRE DE 4 PIÈCES EDENVALE

N° DE MODÈLE : 188-0280-6



INSTRUCTIONS D'ASSEMBLAGE



**VOUS RENCONTREZ DES PROBLÈMES?
SANS FRAIS :**

1 888 670-6684

IMPORTANT : Veuillez lire attentivement ce guide avant
de procéder à l'assemblage de cet article.
Conservez ce guide aux fins de consultation ultérieure.

N° de production : xxxxxxxx

CANVAS^{MC}

INSPIRÉE DU CANADA



Pour les chercheurs de tendances et les experts en design, **CANVAS^{MC}** est la marque de meubles et de décoration qui vous aide à imaginer et à créer un espace dont vous pouvez être fier.

C'est parce que **CANVAS^{MC}** offre un style facile avec des produits qui sont **faits pour la vie réelle et d'inspiration canadienne.**

Nous serions ravis de connaître votre opinion et nous vous invitons à nous faire part de vos commentaires. Visitez notre site Web à **canadiantire.ca** pour nous communiquer de votre expérience et partagez vos photos avec nous en utilisant le mot-clic **#MonStyleCANVAS.**

Montrez-nous comment vous donnez vie aux articles **CANVAS^{MC}**. Nous avons hâte de les voir!

TABLE DES MATIÈRES

Liste des pièces	3
Liste de la quincaillerie	4
Avant de commencer l'assemblage	8
Guide étape par étape	9
Fiche technique	19
Dépannage	20
Entretien de votre article	20
Garantie	21

CONSIGNES DE SÉCURITÉ IMPORTANTES



AVERTISSEMENT : Veuillez lire les consignes de sécurité suivantes avant d'assembler et d'utiliser cet ensemble afin de réduire le risque de blessures graves.

- Cet article est uniquement destiné à un usage domestique et doit être utilisé à l'extérieur.
- L'article doit être placé sur une surface plane et horizontale.
- L'assemblage et l'entretien de cet article ne doivent être effectués que par des adultes.
- Certaines pièces peuvent contenir des bords tranchants. Portez des gants de protection si nécessaire.
- Tenez les enfants et les animaux de compagnie à l'écart de l'ensemble pendant son assemblage.
- Assurez-vous périodiquement que tous les écrous et boulons sont bien serrés. Au besoin, resserrez-les.
- Conservez l'emballage d'origine jusqu'à ce que le montage soit terminé.



Laissez-nous vous aider!

NE RETOURNEZ PAS VOTRE ARTICLE AU MAGASIN.

APPELEZ-NOUS D'ABORD! 1 888 670-6684.

Si vous avez des questions concernant votre article, si vous avez besoin d'aide au sujet de la garantie ou si des pièces sont endommagées ou manquantes, composez le numéro sans frais de notre service à la clientèle. N'hésitez pas à communiquer avec nous, nous sommes là pour vous aider.


IMPORTANT : Veuillez lire ce guide et bien le comprendre avant de commencer l'assemblage. Avant de procéder à l'assemblage du produit, assurez-vous que toutes les pièces sont présentes. Comparez les pièces à la liste de contenu de l'emballage. S'il manque une pièce, ou si vous avez des questions, composez le numéro sans frais au 1 888 670-6684.

Disposez toutes les pièces de la boîte d'emballage sur un plancher propre. Retirez tout le matériel d'emballage et remettez-le dans la boîte. Ne les jetez pas avant d'avoir terminé l'assemblage. Veuillez lire attentivement chaque étape avant de procéder à l'assemblage, et assurez-vous de comprendre toutes les étapes.

OUTILS REQUIS













Clé hexagonale (incluse)













2 personnes

LISTE DES PIÈCES

RÉFÉRENCE	DESCRIPTION	ILLUSTRATION	QUANTITÉ
A P00150015801	Dossier de canapé 3 places		1
B P00140038601	Accoudoir gauche (préassemblé)		1
C P00140038701	Accoudoir droit (préassemblé)		1
D P00160029301	Siège de canapé 3 Places		1
E P00540071001	Patte de chaise		12
F P00180022201	Coussin de siège		6
G P00170001401	Coussin de dossier		5
J H990030025	Pied réglable (préassemblé)		16
K P00170001201	Coussin de dossier de canapé de coin (grand)		1
L P00170001301	Coussin de dossier de canapé de coin (petit)		1


LISTE DES PIÈCES

RÉFÉRENCE	DESCRIPTION	ILLUSTRATION	QUANTITÉ
M P00540071101	Patte de support		3
N H990030038	Bouchon en plastique (préassemblé)		3
P P00150015701	Dossier de la causeuse		1
Q P00160029401	Siège de la causeuse		1
R P00150015901	Dossier de canapé de coin 1 (long) (préassemblé)		1
S P00150016001	Dossier de canapé de coin 2 (court) (préassemblé)		1
T P00160029501	Siège de canapé de coin		1
U P00210056801	Dessus de table		1
V P00540071201	Patte de table		4
W P00050198601	Entretoise		4

LISTE DES PIÈCES

RÉFÉRENCE	DESCRIPTION	ILLUSTRATION	QUANTITÉ
H1 H010030047	Boulon (M6* 20)	A side view of a bolt with a hexagonal head and a threaded shaft.	48+5 pièce de rechange
H2 H010030103	Boulon (M6* 45)	A side view of a longer bolt with a hexagonal head and a threaded shaft.	13+1 pièce de rechange
H3 H010030119	Boulon (M6* 65)	A side view of a very long bolt with a hexagonal head and a threaded shaft.	4+1 pièce de rechange
H4 H050070012	Rondelle plate M6	A top view of a circular plate washer with a central hole.	65+7 pièce de rechange
H5 H100090001	Boulons à oreilles et écrous à oreilles à col carré (M8*70)	A side view of a bolt with ears, featuring a square neck and a threaded shaft.	4+1 pièce de rechange
HW H090030002	Clé hexagonale M6	A side view of a hex key with a hexagonal head and a long shaft.	1


VUE ÉCLATÉE



AVANT DE COMMENCER L'ASSEMBLAGE


S'ASSURER QUE TOUTES LES PIÈCES SONT COMPRISES

Comparez toutes les pièces aux listes de pièces et de quincaillerie et assurez-vous d'avoir tous les outils nécessaires pour l'assemblage.




ASSEMBLER DANS UNE ZONE DÉGAGÉE

Placez toutes les pièces de la boîte sur le sol devant vous sur une surface propre, sèche et plane afin de protéger l'article pendant son assemblage.




RETIRER LES MATÉRIAUX D'EMBALLAGE

Remettez les matériaux d'emballage dans la boîte. Ne les jetez pas avant d'avoir terminé l'assemblage.



LIRE ATTENTIVEMENT CHAQUE ÉTAPE


Assurez-vous de bien comprendre chaque étape. Si vous avez des questions, contactez le service à la clientèle CANVAS^{MC} au 1 888 670-6684 (sans frais).



GUIDE ÉTAPE PAR ÉTAPE


ÉTAPE 1

Fixez le dossier du canapé 3 places **A** et l'accoudoir gauche **B** au **D** siège du canapé 3 places au moyen des boulons **H2** et **H3** et des rondelles **H4**, en alignant les trous. Ne les serrez pas à fond.



REMARQUE :


Ne serrez pas les vis avant d'avoir fini l'assemblage.
Une fois l'assemblage terminé, serrez chaque vis.



GUIDE ÉTAPE PAR ÉTAPE


ÉTAPE 2

Fixez les pattes de chaise **E** au-dessous du canapé au moyen des boulons **H1** et des rondelles **H4**, en alignant les trous. Serrez tous les boulons.



REMARQUE :

Ne serrez pas les vis avant d'avoir fini l'assemblage. Une fois l'assemblage terminé, serrez chaque vis.




GUIDE ÉTAPE PAR ÉTAPE

ÉTAPE 3



Fixez les pattes de support **M** sous le canapé, en alignant les trous.

M X2



ÉTAPE 4

Fixez le dossier de la causeuse **P** et l'accoudoir droit **C** à la causeuse **Q**, au moyen des boulons **H2** et **H3** et des rondelles **H4**, en alignant les trous. Ne les serrez pas à fond.





REMARQUE :

Ne serrez pas les vis avant d'avoir fini l'assemblage. Une fois l'assemblage terminé, serrez chaque vis.

ÉTAPE 5

Fixez les pattes de chaise **E** au-dessous de la causeuse au moyen des boulons **H1** et des rondelles **H4**, en alignant les trous. Serrez tous les boulons.




REMARQUE :

Ne serrez pas les vis avant d'avoir fini l'assemblage. Une fois l'assemblage terminé, serrez chaque vis.

ÉTAPE 6

Fixez les pattes de support **M** sous la causeuse, en alignant les trous.

M X1





REMARQUE :

Ne serrez pas les vis avant d'avoir fini l'assemblage. Une fois l'assemblage terminé, serrez chaque vis.

ÉTAPE 7

Fixez les pattes de chaise **E** au-dessous du canapé de coin **T** au moyen des boulons **H1** et des rondelles **H4**, en alignant les trous.





REMARQUE :

Ne serrez pas les vis avant d'avoir fini l'assemblage.
Une fois l'assemblage terminé, serrez chaque vis.

ÉTAPE 8

Tournez le dessus de table **U** à l'envers et fixez les pattes de table **V** au-dessous du dessus de table au moyen des boulons **H1** et des rondelles **H4**, en alignant les trous.




REMARQUE :

Ne serrez pas les vis avant d'avoir fini l'assemblage.
Une fois l'assemblage terminé, serrez chaque vis.


GUIDE ÉTAPE PAR ÉTAPE

ÉTAPE 9



Utilisez les boulons à oreilles et les écrous à oreilles **H5** et les entretoises **W** pour fixer le siège.



W X4





H5 X4




GUIDE ÉTAPE PAR ÉTAPE

ÉTAPE 10

Placez les coussins de siège **F** et coussins de dos **G**, **L** et **K** sur le modulaire.



FICHE TECHNIQUE



FICHE TECHNIQUE (canapé 3 places)

DIMENSIONS (larg. x P. x H.)

86 x 30 x 28 15/16 po

218,5 x 76,2 x 73,5 cm

FICHE TECHNIQUE (causeuse)

DIMENSIONS (larg. x P. x H.)

62 x 30 x 28 15/16 po

157,5 x 76,2 x 73,5 cm

FICHE TECHNIQUE (canapé de coin)

DIMENSIONS (larg. x P. x H.)

29 15/16 x 29 15/16 x 28 15/16 po

76 x 76 x 73,5 cm

FICHE TECHNIQUE (table basse)

DIMENSIONS (larg. x P. x H.)

48 x 25 x 15 po

122 x 63,5 x 38,1 cm

POIDS

151 lb 10 oz

68,8 kg

CAPACITÉ DE POIDS MAXIMALE PAR SIÈGE

225 lb

102 kg

DIMENSIONS DE LA CAUSEUSE ASSEMBLÉE

LARGEUR : 115 15/16 po (294,5 cm) **PROFONDEUR :** 91 15/16 po (233,5 cm)

HAUTEUR : 28 15/16 po (73,5 cm) **HAUTEUR DU SIÈGE :** 18 1/8 po (46 cm)

DÉPANNAGE



**AVANT DE RETOURNER
VOTRE ARTICLE**

**VOUS RENCONTREZ DES PROBLÈMES?
LAISSEZ-NOUS VOUS AIDER!**

**SANS FRAIS :
1 888 670-6684**

Si vous avez des questions concernant votre article ou avez besoin d'une assistance au titre de la garantie, veuillez appeler notre service d'assistance à la clientèle.



**APPELEZ-NOUS,
NOUS POUVONS
VOUS AIDER**

ENTRETIEN DE VOTRE ARTICLE

- 1 Nous recommandons l'utilisation de housses de meubles lorsque l'article n'est pas utilisé.
- 2 Le coussin peut être nettoyé sur place uniquement en surface; ne lavez pas en machine.
- 3 Nettoyez et séchez l'article avant de le ranger dans un endroit sec et abrité
- 4 Nettoyez la chaise avec du savon doux et de l'eau. Rincez abondamment.
- 5 N'utilisez pas de produits à base de Javel, d'acide ou autres nettoyants abrasifs sur le fauteuil ou les parties du cadre.

GARANTIE LIMITÉE



GARANTIE LIMITÉE DE 5 ANS*

Cet article CANVAS comprend une garantie de cinq (5) ans contre les défauts de fabrication et de matériaux du cadre et de l'osier et un (1) an de garantie pour toutes les autres pièces. Distribution Trifeuil consent à remplacer l'article défectueux sans frais lorsqu'il est retourné, accompagné de la preuve d'achat, par l'acheteur original au cours de la période de garantie convenue. Exclusion : usure ou bris causés par un usage abusif ou inapproprié.

N° DE MODÈLE : 188-0280-6

N° DE MODÈLE : 188-0280-6

Importé par Trileaf Distribution Trifeuil Toronto, Canada M4S 2B8

CANVAS^{MC}

INSPIRÉE DU CANADA

