




Springdale 8x8' Gazebo

Model No. 188-1359-6

Assembly Instructions



NEED HELP? GIVE US A CALL!
WE'RE HERE FOR YOU.

TOLL-FREE:
1-877-483-6759

IMPORTANT: Please read this manual carefully
before beginning assembly of this product.
Keep this manual for future reference.

Production Number: xxxxxxxx





From your first apartment to
downsizing your family home,
For LIVING® is a great place to start.

Uncomplicate your life with timeless
style and reliable quality that delivers
everyday solutions for your home.

Let us know how our products
work for you. Rate and review at
canadiantire.ca.

Table of Contents

Important Safety Instructions	4	Technical Data	19
Parts List	5	Troubleshooting	20
Before You Begin Assembly	8	Caring for Your Item	20
Step-by-step Guide	9	Warranty	21

Caution!



- Proper placement of your gazebo is essential.
- Do not place the product underneath electrical lines.
- Keep children away during assembly.
- This product contains small parts which can be swallowed by children.
- Keep fingers away from the places where they can be pinched or trapped.
- Do not attempt to assemble the gazebo if any parts are missing.



Let us help you!

DO NOT RETURN YOUR PRODUCT TO THE STORE. CALL US FIRST!


1-877-483-6759

If you have questions regarding your product, require warranty assistance, or have damaged or missing parts, please call our customer service toll-free helpline. Contact us for assistance; we're here to help.

IMPORTANT: Please read and understand this manual before any assembly. Before beginning the assembly of product, make sure all parts are available. Compare parts list with packaging contents. If any part is missing, or if you have any questions, contact the service centre at 1-877-483-6759 (toll free).

Take all parts from the packaging box and position them on a clean floor. Remove all packing materials and place them back into the box. Do not dispose of the packing materials until assembly is complete. Read each step carefully before beginning any assembly and make sure you understand each step. If you are missing a part, please call our toll-free number for assistance: 1-877-483-6759.


Needed for Assembly: (The following are not included)




Hammer



Screwdriver



Ladder



2 people

Safety Instructions



Warning!

To reduce the risk of serious injury, read the following safety instructions before assembling and using the gazebo.

Caution!













Always keep children under close supervision while they are playing around this product. Never leave children unattended. Keep pets away while setting up the gazebo.

Caution!

Check municipal by-laws prior to installing the gazebo.




- This product is intended for domestic, outdoor use only.
- Always place and assemble the gazebo on flat, horizontal ground.
- Consult with your local governing authority/local municipal codes regarding installation of temporary structures before assembly.
- Ensure there is enough clearance around the product. Before assembling the gazebo, make sure to leave a distance of not less than 1.8 m (6') from any structures or obstructions, such as fences, garages, houses, overhanging branches, laundry lines, or electrical wires.
- Anchor the gazebo to the ground with stakes for added safety. Stakes are provided to secure the gazebo to the ground. If you wish to secure the gazebo to a concrete and wood surfaces, use anchors suited for these surfaces (anchors not included). Do not assemble the gazebo on sandy, muddy or loose soil, as stakes are not strong enough to anchor in these types of soil.
- If more than one gazebo is set up, keep a minimum distance of 3 m (10') between the gazebos.
- Any assembly or maintenance of the gazebo must be carried out by adults only.
- Make sure there is sufficient manpower when assembling or moving the gazebo.
- Some parts may contain sharp edges. Wear protective gloves if necessary.
- Check all nuts and bolts periodically for tightness. If required, tighten them.
- Repairing and replacing parts should be done by a qualified technician.
- This gazebo is intended for decorative and sunshade purposes only, and is not designed to withstand harsh weather, including high winds, rain, and snow.
- Always disassemble the gazebo in heavy wind conditions. If not, it might tip over and could cause injury to bystanders.
- Always ensure that the canvas is taut to avoid water accumulation on the roof. If water accumulates on the roof, remove it immediately or disassemble the gazebo in order to avoid damages.
- Do not light any fires inside or near the gazebo.
- Do not panic if fire breaks out inside the gazebo. Search for the nearest exit. Do not return to the gazebo until the firemen allow you to do so.
- Do not hang any weights on the roof frame.
- Do not climb onto the roof of the gazebo. Doing so may cause the gazebo to fall down, thereby resulting in serious injury.
- Retain the original packaging to store the gazebo.
- If the gazebo will not be used for a long period of time (e.g., during winter time), disassemble and store it in a clean, dry environment.

Parts List





Item		Description	Thumbnail	Quantity
A	P00630019001	Post Frame 1		4
B	P00630019101	Post Frame 2		4
C1	P00230013101	Shelf		4
C2	P00010059701	Post Frame Bracket		12
D1	P00040184501	Cross Beam 2		4
D2	P00040184401	Cross Beam 1		4
E	P00050236601	Slanting Beam Lower Connector		4
F	P00060324701	Slanting Lower Tube 1		3
G	P00060324801	Slanting Lower Tube 2		1
J	P00060324901	Slanting Upper Tube		4
K	P00570048001	Adjustment Tube		4
L	P0050236701	Big Connector		1

Parts List




Item	Description	Thumbnail	Quantity
M P00580015401	Hook		1
P P00110076601	Big Canopy		1
Q P00110076501	Small Canopy		1

Hardware List

Item	Description	Thumbnail	Quantity
H1 H100010069	Bolt M6*15		24+3 Spare
H2 H100010095	Bolt M6*30		28+3 Spare
HW H090010017	M6 Wrench		1
HS H070010005	Stake Dia.6*180		12+4

Exploded View



Before You Begin Assembly





Make Sure All Parts Are Present

Compare all pieces to the parts and hardware lists, and make sure you have all tools required for assembly.





Assemble in a Cleared Area

Place all parts from the box on the floor in front of you on a clean, dry, level surface to protect the product as it is being assembled.





Remove Packaging Materials

Place packing materials back in the box. Do not dispose of packaging materials until assembly is complete.







Read Each Step Carefully



Make sure you understand each step. For any questions, contact the For LIVING® customer service centre at 1-877-483-6759 (toll free).




Step-by-step Guide

Step 1

A X4	B X4	C1 X4	C2 X12
			




H2 X12

H1 X12




Step-by-step Guide






Step 2



Step-by-step Guide




Step 3



Step-by-step Guide





Step 4



Step-by-step Guide



Step 5



Step-by-step Guide





Step 6



Step-by-step Guide


Step 7




Step-by-step Guide



Step 8




To achieve a snug fit for the canopy, adjust the position of K using a different hole as shown below.



Step-by-step Guide

Step 9




Assemble this corner last to ensure a tight fit.

Step-by-step Guide




Step 10

HS X12



Technical Data



Dimensions (L x W x H)

2.7 x 2.7 x 2.65 m

8' 10" x 8' 10" x 8' 3"

Product weight

26 kg

57 lb

Need help?

Give us a call! We're here for you.

Toll-free: 1-877-483-6759



Before returning your product to store



Call us first!

If you have questions regarding your product or require warranty assistance, please call our customer service helpline.

Caring for Your Item



Caution!

- Check all screws and nuts periodically for tightness, fastening them again as required.
- Disassemble the gazebo in the reverse order of the assembly steps. Always disassemble the gazebo completely. A partially-disassembled gazebo is not stable enough to resist wind and bad weather, and therefore can be damaged and/or cause damage.
- Keep all flame and heat sources away from the tent fabric. This tent is made with fabric that meets CPAI-84 specifications for flame resistance. It is not fire proof. The fabric will burn if left in continuous contact with any flame source. The application of any foreign substance to the tent fabric may render the flame-resistant properties ineffective.

- To wash the fabric parts:
 - Spread the fabric and use a soft-bristle brush to clean.
 - Always use a natural soap. Never use detergent.
 - Water should be cold to lukewarm, not more than 25°C (77°F).
 - Air dry only. Do not spin in washing machine or hand squeeze.
- Do not use bleach, acid, or other abrasive cleaners on the canopies or frame parts.
- Steel components of garden accessories and furniture are coated with rust-inhibiting paint. However, due to the nature of steel, surface oxidation (rusting) will occur if this protective coating is scratched. This is a natural process. To minimize this condition, it is recommended that care be taken when assembling and handling the product, in order to prevent the paint from being scratched. Surface rust can be removed easily by applying little common cooking oil. If surface oxidation (rusting) occurs and no measures are taken to correct it, the oxidation may start dripping onto the assembly surface, which may cause stains that could be difficult to remove.
- Keep instruction manual for future reference.
- Keep the original packaging to store the gazebo.



1-Year Limited Warranty*

This For LIVING® product carries a one (1) year warranty against defects in workmanship and materials. Trileaf Distribution agrees to replace the defective product free of charge within the stated warranty period, when returned by the original purchaser with proof of purchase. This product is not guaranteed against wear or breakage due to misuse and/or abuse.

Model No. 188-1359-6

Made in China

Imported by Trileaf Distribution Trifeuil Toronto, Canada M4S 2B8