


model no. 052-4934-0 | contact us: 1.800.388.6141



**IMPORTANT:** Please read this manual carefully before assembly and save it for reference

### ASSEMBLY:

- 1) Carefully take out all parts from box and lay them on a smooth surface.
- 2) Attach the nipple joint of shade assembly into the bushing as shown in left diagram and tighten.
- 3) Install the bulb into the socket, Uses a Max 40-watt type "B" bulb.(Bulb not included).  
**CAUTION:** A CFL Bulb is not recommended for use in this lamp. Please use the suggested wattage incandescent bulb for best results.
- 4) Plug into outlet.
- 5) Touch the lamp base to operate:  
**ON -- NIGHT LIGHT -- BRIGHT LIGHT -- OFF**

### If the lamp does not work:

- 1) Ensure the power outlet is working correctly.
- 2) Check the bulb is tightly fitted inside the lamp socket.
- 3) If the bulb is burned out, replace the faulty bulb.
- 4) If the circuit breaker is off, resume the circuit breaker is switched to the "ON" position.

### ⚠ CAUTION:

1. For indoor use only.
2. Keep away from any source of flame or heat.
3. Do not use any cleaners with chemicals, solvents, or harsh abrasives. Use only a dry, soft cloth to dust or wipe carefully.
4. To clean the fixture, disconnect power by turning off the circuit breaker or by removing the fuse at the fuse box. Use a dry or slightly dampened, clean cloth to wipe the exterior surface of the fixture.
5. Do not exceed the recommended wattage. Refer to the re-lamping label on the light socket for maximum wattage.
6. Do not replace a bulb when electrical outlet switch is turned to the "ON" position.
7. Do not immerse your lamp in water; doing so will damage the wire.
8. Before you work on any electrical fixture, you must be aware of the hazards involved with electrical circuitry and be familiar with the standard codes and practices for preventing accidents, in order to reduce the risk of fire, electrical shock, or personal injury.

This Noma® product carries a one = (1) = year warranty against defects in workmanship and materials. Noma Canada agrees to replace a defective product, within the stated warranty period, when returned to the place of purchase with proof of purchase. This product is not guaranteed against wear or breakage due to misuse and/or abuse.

MADE IN CHINA  
Imported by Noma Canada  
Toronto, Canada M4S 2B8