


# CANVAS™/MC

## PARKER 49.625~61" FLOOR LAMP

MODEL NO. 052-7841-2



### ASSEMBLY INSTRUCTIONS

IMPORTANT: Please read this manual carefully before beginning assembly of this product.  
Keep this manual for future reference.


1

MODEL NO. 052-7841-2

## CANVAS™/MC


#### Step 1 - requires 1, 5, 6

Screw tubes B (6) onto joint stem (1) clockwise to tighten. Then, screw tubes A (5) onto tubes B (6) clockwise to tighten.




#### Step 2 - requires 3, 4, 7

Insert harp (3) into saddle (7), and then unscrew finial (4) from harp (3).




#### Step 3 - requires 2, 3, 4

Install lampshade (2) onto harp (3) by reattaching finial (4).



#### Step 4


Install light bulb (not included). Use one 150 W (max.) type A medium-base bulb.



# CANVAS™/MC

Floor of Contents	2
Parts List	3
Assembly	4
Warranty	5

### FLOOR OF CONTENTS



### PARTS LIST

3

4

5