


IMPORTANT: Please read this manual carefully before assembly and save it for reference.



WARNING: This portable light has a polarized plug (one blade is wider than the other) as a safety feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless the plug can be fully inserted. Do not alter the plug.


⚠ CAUTION:

Please read the following instructions carefully. **ALWAYS** ensure that the light is unplugged and switch is OFF, before commencing assembly or cleaning the light.

Cleaning: Before cleaning your light, turn off the switch or power source. Wipe the light with a soft, damp cloth.

This product carries a five (5) year warranty against defects in workmanship and materials. Noma Canada agrees to replace a defective product, within the stated warranty period, when returned to the place of purchase with proof of purchase. This product is not guaranteed against wear or breakage due to misuse and/or abuse.

IMPORTANT : Veuillez lire attentivement et comprendre le présent guide avant tout assemblage et conservez-le pour consultation ultérieure.



AVERTISSEMENT : Cette lampe portative est munie d'une fiche polarisée (une borne plus large que l'autre). Ce dispositif de sécurité diminue le risque de choc électrique puisque la fiche ne s'insère dans la prise que d'un seul côté. Si elle n'entre pas entièrement dans la prise, inversez-la. Si elle n'entre toujours pas, communiquez avec un électricien qualifié. N'utilisez jamais de rallonge, sauf si la fiche s'insère entièrement. Ne modifiez pas la fiche.

⚠ ATTENTION :

Veuillez lire attentivement les instructions suivantes. Il faut TOUJOURS s'assurer que la lampe est débranchée et éteinte avant de commencer l'assemblage ou de nettoyer la lampe.

Nettoyage : Avant de nettoyer votre lampe, fermez l'interrupteur ou coupez la source d'électricité. Essuyez la lampe avec un chiffon doux et humide.

Cet article est doté d'une garantie de cinq (5) ans contre les défauts de fabrication et de matériau(x). Noma Canada consent à remplacer un article défectueux sans frais, pendant la période de la garantie, lorsqu'il est retourné, accompagné de la preuve d'achat, à l'endroit de l'achat. Exclusion : usure ou bris causés par un usage abusif ou inapproprié.