


Berkeley Lifelike Tree

model no. 151-5591-2 | Toll-free Number : 1-866-827-4985

IMPORTANT: Please read this manual carefully before assembly and save it for reference

ASSEMBLY:

- 1) Place the tree stand near a location with a wall power outlet.
- 2) Carefully insert the bottom section of the tree (C) into the tree stand. Make sure the pole is firmly inserted into the stand.
- 3) Insert the middle section (B) into the bottom section (C) by attaching the corresponding poles and plugs.
- 4) Insert the top section (A) into the middle section (B) by attaching the corresponding poles and plugs.
- 5) Plug the electric cord into the wall outlet. The entire tree should now be lit. If some bulbs do not light, search for any loose plugs and broken, loose or missing bulbs (refer to the Troubleshooting section). Keep the tree plugged in while shaping branches. Should a light flicker while this is being done, check for the bulb(s) that may be causing the trouble.
- 6) Allow branches to fall into place or gently pull branches up and outwards. When adjusting branches, be sure that all the wires are free of branch hinges.
- 7) Shape the branches by working from the bottom of the tree upwards. Start with the tips closest to the tree's centre pole. Fan out the tips in a pattern of one to the right, one to the left, and one to the centre of the main stem. Tips at the centre position should be alternately placed so that they do not line up one after the other.
- 8) After shaping the tree, step back and take an overall look. Shift branches to fill any gaps. Slightly upsweep all branch tips for a uniform look. The tree is now ready to be decorated and enjoyed.






STORAGE:

- 1) Unplug the tree from the wall outlet.
- 2) Carefully lift off the top tree section (A) from the middle tree section (B) and disconnect the plugs.
- 3) Carefully lift off the middle tree section (B) from the bottom tree section (C) and disconnect the plugs.
- 4) Remove the bottom tree section (C) from the tree stand.
- 5) Store in original carton.
- 6) Do not store in direct sunlight, in a damp area, or in an area where the temperature exceeds 40°C.







If the lights do not work:

- 1) Ensure the power outlet is working correctly. Check whether the cord is properly plugged into the outlet.
- 2) Check that all bulbs are tightly fitted inside their respective holders.
- 3) If a bulb is not working, replace the faulty bulb as shown in the figures below. Use the replacement bulbs provided.



Spare bulbs

- 4) If none of the lights are working, check the fuse in light string. If the fuse is blown, replace the blown fuse following the diagram below. There is a spare fuse included for easy replacement.



Spare fuse

⚠ CAUTION:

- 1) Read all instructions and warning tags carefully.
- 2) For indoor use only.
- 3) Do not place near gas or electric heaters, radiators, fireplaces, candles or other similar sources of heat.
- 4) Place on a hard, flat, level surface. Do not place where the tree is likely to tip or wobble due to uneven flooring or thick carpeting.
- 5) Do not install near fountains, bathtubs, sinks or other wet areas.
- 6) Do not use candles on the tree.
- 7) After assembling and decorating the tree, ensure that it is stable. If the tree is unstable, attach support wires to walls and/or window frames (ensure that support wires are also secure).
- 8) Do not overload extension cords or power bars; see ratings on these devices and check the rating labels on the tree for compatibility.
- 9) This is a Christmas decoration. This is not a toy. Keep out of the hands of small children.
- 10) For festive use only. Not intended for consecutive use over 90 days each season.

This Canvas product carries a one (1) year warranty against defects in workmanship and materials. Trileaf Distribution agrees to replace a defective product, within the stated warranty period, when returned to the place of purchase with proof of purchase. This product is not guaranteed against wear or breakage due to misuse and/or abuse.

MADE IN CHINA

Imported by

Trileaf Distribution Trifeuil Toronto, Canada M4S 2B8

