

CANVAS^{TM/MC}

PLAYA COLLECTION HIGH DINING TABLE

PRODUCT NO. 088-1772-8



ASSEMBLY INSTRUCTIONS

Toll-free: 1-888-670-6684

IMPORTANT: Please read and understand this manual before any assembly. Before beginning assembly of product, make sure all parts are present. Compare parts with packaging contents list. If any part is missing, or if you have any questions, contact the customer service department at 1-888-670-6684.

IMPORTED FOR TRILEAF DISTRIBUTION TRIFEUIL TORONTO, CANADA M4S 2B8

Table of Contents	3
Important Safety Instructions	3
Parts List	4
Assembly	5
Cleaning and Maintenance	8
Technical Data	8
Warranty	9



Warning! To reduce the risk of serious injury, read the following safety instructions before assembling and using the table.

Caution! Always keep children under close supervision while they are using or around this product.

Never leave children unattended.


- This product is intended for domestic outdoor use only.
- The product should be placed on flat, horizontal ground.
- Any assembly or maintenance of the product must be carried out by adults only.
- Arrange necessary manpower when assembling or moving the product.
- Some parts may contain sharp edges. Wear protective gloves if necessary.
- Keep children and pets away while setting up the table
- Check all nuts and bolts periodically for tightness. When required, tighten them again.
- Repairing and replacing parts should be done by a qualified technician.
- If the product will not be used for a longer period (e.g. winter time), it should be stored in a clean, dry environment.
- Do not light any fires inside or near the product!
- Retain the original packaging to store the table.

PART LIST

4 PRODUCT NO. 088-1772-8

1

Table frame - 1



A

Screw with washer M6X20 - 20



2

Leg frame - 4



B

Hex key - 1



3

Leg side panel - 4



4

Glass table top - 1



**CAUTION!**

- The maximum load of this product is 44 lb (20 kg).
Do not stand or sit on the product.
- Keep children away during assembly.
This product contains small parts which can be swallowed by children.
- Keep fingers away from the places where they can be pinched or trapped.
- Do not attempt to assemble the table if any parts are missing.



Let us help you!

DO NOT RETURN YOUR PRODUCT TO THE STORE. CALL US FIRST!

1-888-670-6684


If you have questions regarding your product, require warranty assistance, or have damaged or missing parts, please call our customer service toll-free helpline. Contact us for assistance; we're here to help.

Place all parts from the box in a cleared area and position them on the floor in front of you. Remove all packing materials and place them back into the box. Do not dispose of the packing materials until assembly is complete. Read each step carefully before beginning any assembly and make sure you understand each step. If you are missing a part, please call our toll-free number for assistance 1-888-670-6684.

Needed for assembly:



Hex key




Two people

Note: Do not tighten screws all the way until you have assembled the table. Once assembly is complete, go back and tighten each screw.

Step 1

Requires part 1, 2, A, B


Attached each leg frame (2) to the table frame (1), using the M6X20 screws (A) with washers, then tighten the screws with Hex Key (B).



Step 2

Requires part 3, A, B


Connect the leg side panel (3) to table legs, using the M6X20 screw (A) with washers, then tighten the screws with Hex Key (B).



Step 3

Requires parts 4

Turn the table to upright position and put on the glass table top (4).



When using an umbrella, insert the pole of the umbrella through the opening on the table frame. Make sure the protection ring is in place in the central hole of the table frame.

**CAUTION!**

- Check all screws and nuts periodically for tightness, tightening them again as required.
- Disassemble the table in the reverse order of the assembly steps. Always disassemble the table completely.

- Clean the product with a slightly damp cloth and a little detergent. Let it dry thoroughly.
- Do not use bleach, acid, or other abrasive cleaners on the canopies or frame parts.
- Steel components of garden accessories and furniture are treated with rust-inhibiting paint. However, due to the nature of steel, surface oxidation (rusting) will occur if this protective coating is scratched. This is a natural process. To minimize this condition, it is recommended that care be taken when assembling and handling the product in order to prevent the paint from being scratched .

Dimensions (L x W x H)

77.5 x 77.5 x 101cm

30 8/16 x 30 8/16 x 40in

Product weight

15.6kg

34 lb 6 oz

This CANVAS product carries a one (1) year warranty against defects in workmanship and materials.

Trileaf Distribution agrees to replace the defective product free of charge within the stated warranty period, when returned by the original purchaser with proof of purchase. This product is not guaranteed against wear or breakage due to misuse and/or abuse.