




Bluetooth® True Wireless Earbuds User Manual

Model No. 035-7309-4




**BUILT-IN
MICROPHONE**



Usage precautions

1. Use the product for its intended purpose only.
2. Do not disassemble product. This product does not contain parts that are entitled to self-sufficient repair.
3. Keep away from children under the age of 3, as it contains small parts.
4. Avoid use in humid conditions or extreme temperatures. High heat will shorten lifespan of electronic components, damage battery and deform some plastic parts. Avoid extreme cold temperatures as damage to the PCB board may occur.
5. Keep away from vibrations and mechanical stress, which can cause mechanical damage to the product. In case of mechanical damage, warranty is voided.
6. Do not use product while driving any vehicle as it may distract your attention. Check your local laws and regulations.
7. High volume may lead to permanent hearing damage and hearing loss. Set the volume at a reasonable setting and avoid loud volumes at all times.
8. Danger of fire, explosion and burns if the operating temperature is substantially exceeded, if the electronics housing is opened and in case of battery short-circuit, when touching a leaking battery.
9. Do not charge continuously for more than 10 hours as this will shorten the lifespan of the product.

Key Parts Diagram




Earbuds LED Indicator

Earbuds status	LED Indication
In idle mode after paired	Blue light flickers once every 7 seconds
Incoming call	Blue light flickers once every 7 seconds
Low battery	Red light flickers once every 2 seconds
Charging	Red light is on
Power on	Blue light flickers once
Power off	Red light flickers once
True Wireless Earbuds pairing	Blue and red light flickers alternatively
Bluetooth® pairing	Blue and red light flickers alternatively

Sounds & Voice Prompt Functions

Function	Voice Prompt/Audio Tone
Powering on your Earbuds	Power On
Powering off your Earbuds	Power Off
Power on and Pairing	Power On, Pairing
Disconnecting from Bluetooth®	Disconnected, Pairing
Low battery power	Please charging
True Wireless Earbuds pairing	Searching for slave
True Wireless Earbuds connected	Pairing success, Connected Left Channel, Right Channel
Bluetooth® pairing	Pairing
Bluetooth® connected	Pairing success, Connected
Incoming call	You have an incoming call

Charging Your Earbuds and Charging Case



The Earbuds have an internal, rechargeable charging case which must be fully charged before using for the first time. It takes 1 1/2 hours to fully charge the unit for the first time. You can charge the charging case either by using an AC adaptor (max output: 5 V 1 A) or a PC.

The charging case can charge the Earbuds 3 times after fully charged.



When the charging case is fully charged, the four battery level indicator will turn blue. Put the Earbuds into the charging case to charge. During charging, The red charging LED indicator on the Earbuds will be on. When the battery is fully charged, the red LED indicator will turn off.



You can charge your Earbuds at any time when you put them back into the charging case.

Note: When the Earbud batteries are out of power, the red LED indicator starts to flicker every 2 seconds with prompt of "please charging" every 60 seconds. The Earbuds need to be charged as soon as possible.

Put Earbuds on the charging case; the Earbuds can not be operated during charging.


Once charging case charging has been completed, remove the micro-USB plug from the charging case.

The charging case is only for charging of the Earbuds. DO NOT recharge other devices.


Pairing Your Earbuds with a Bluetooth® Device




① True Wireless Earbuds Pairing Mode
Red & Blue Flashing LED



② True Wireless Earbuds Paired Red & Blue Flashing LED (Main Earbuds)




③ Bluetooth® Connected Blue Flashing LED



1. Press and hold both Earbuds power keys until the red and blue LED indicator flickers alternately, with prompt of "Power On" to indicate the Earbuds are on. The prompts "Connected", "Left Channel", "Right Channel" will indicate that the left and right true wireless Earbuds are connected with each other.
2. The red and blue LED indicator flickers alternately, with prompt "pairing" to indicate your Earbuds are in Bluetooth® pairing mode.
3. Go to the Bluetooth® settings menu on your phone / tablet / Bluetooth® devices. Make sure that Bluetooth® is turned on. Connect to the device listed as "035-7309-4". A prompt " Pairing Success, Connected" indicates your device has been successfully connected and the Earbuds are ready to use.

Note: If pairing is not completed within 5 minutes, the Earbuds will automatically power off. If this happens, repeat the pairing steps above.

Using Your Earbuds



PRESS ONCE

▶/▷ Play / Pause Music
📞 / 📞 Answer Call / End Call

PRESS TWICE

📞 Redial

PRESS & HOLD

켬 Power On / Power Off
🔕 Reject a Call



The medium size of the Earbud Caps have been placed on the Earbuds.
Change to another size of caps to fit your ears.

Tips for True Wireless Earbuds Pairing

True Wireless Earbuds pairing is a technical term of using the Bluetooth® product. Two Bluetooth® enable devices can be connected.

It will automatically distinguish between left channel and right channel Earbuds.

Either one of the Earbuds can be the main one and should be paired and connected with Bluetooth® mobile phone.

After True Wireless Earbuds connecting, you can play / pause (Power Key) music through either of the two Earbuds, but only the main Earbud has call function.

When the True Wireless Earbuds are "On", press and hold Power Key of either headset for 5 seconds to power both Earbuds off.

If they are not in True Wireless Earbuds connection, you can pair and connect them respectively with Bluetooth® mobile phone.

Specifications

Bluetooth® Specifications: V 4.2

Bluetooth® Profiles Supported: HFP / A2DP / AVRCP

Effective Range: Up to 10 m (32')

Each Earbud Battery: 45 mAh

Charger Case Battery: 400 mAh

Charging Time for Earbuds: 1 1/2 hours

Charging Time for Case: 2 1/2 hours

Playing Time: up to 3 hours (at medium volume)

Talking Time: up to 4 hours (at medium volume)

Standby Time: 25 hours

Frequency Response: 20-20k HZ

Includes Charging Cable, 3 ear caps (S,M,L)

Working Temperature: -5°C to 35°C (23°F to 95°F)

Storage Temperature: -5°C to 60°C (23°F to 140°F)

Maintenance and Care

Before using your Earbuds and charging case, examine the Earbud caps to make sure that they are clean. Similarly, inspect the ports and jacks of your Earbuds and charging case to make sure that they are clear of dust and debris before charging.

Use a soft cloth or paper towel to clean your Earbuds and charging case. Do not allow moisture to get inside the Earbud caps. Never use any harsh chemicals or detergents for cleaning. Make sure your Earbuds and charging case are dry before using.

When your Earbuds and charging case are not in use, they should be stored in a cool, dry place.

Never tug or yank on the USB cable while it is connected to your charging case. Connect and disconnect cables as carefully as possible.

Never expose your Earbuds and charging case to high temperatures, extreme cold, high humidity or excessive moisture or water.

This Class B digital apparatus complies with Canada ICES-003.

CAN ICES-3(B)/NMB-3(B)

IC: 25177-208T

This device complies with Industry Canada licence-exempt RSSs. Operation is subject to the following two conditions:

- (1) This device may not cause interference; and
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

The term "IC: " before the certification/registration number only signifies that the Industry Canada technical specifications were met. This product meets the applicable Industry Canada technical specifications.



Product must be recycled or disposed of properly. Dispose of as per the requirements of your local municipality.

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by HANK Electronics Co., Ltd. is under licence. Other trademarks and trade names are those of their respective owners.

Made in China

Imported by Trileaf Distribution Toronto, Canada M4S 2B8