



BLUEHIVE™ BLUEBASS ELITE TRUE WIRELESS HEADPHONES

User Manual

Model No. 035-8101-0



**BUILT-IN
MICROPHONE**




**Connectivity
Bluetooth
or Aux-in**

Usage Precautions

1. Use the product for its intended purpose only.
2. Do not disassemble product. This product does not contain user-serviceable parts.
3. Keep away from children under the age of 3, as it contains small parts.
4. Avoid use in humid conditions or extreme temperatures. High heat will shorten lifespan of electronic components, damage battery and deform some plastic parts. Avoid extreme cold temperature as damage to the PCB board may occur.
5. Keep away from vibrations and mechanical stress, which can cause mechanical damage to the product. In case of mechanical damage, warranty is void.
6. Do not use product while driving any vehicle as it may distract your attention. Check your local laws and regulations.
7. High volume may lead to permanent hearing damage and hearing loss. Set the volume at a reasonable setting and avoid loud volume at all times.
8. Danger of fire, explosion and burns if the operating temperature is substantially exceeded, if the electronics housing is opened, and in case of battery short-circuit, when touching a leaking battery.
9. Do not charge continuously for more than 10 hours as this will shorten the lifespan of the product.

Key Parts Diagram



1. Head Band

2. Right Headphone

3. Left Headphone

4. + Button

5. Power Button

6. - Button

7. AUX In

8. Type-C Charging Port

9. LED Light

10. ANC Button

11. Audio Cable

12. USB Charging Cable


LED Indicator

Headphone status	LED Indication
Incoming call	Blue light flickers 2 times every 1 second
Low battery	Red light flickers once every 10 seconds
Charging	Red light is on
Power on	Purple light is on 1 second
Power off	Red light flickers three times then off
Bluetooth® pairing	Blue and red light flickers alternately


Sounds & Voice Prompts Functions

Function	Voice Prompt/Audio Tone
Powering on your headphones	Power On
Powering off your headphones	Power Off
Bluetooth® pairing	Pairing
Bluetooth® connected	Connected
Disconnecting from Bluetooth®	Disconnecting
Low battery power	Battery Low
ANC mode on	ANC on
ANC mode off	ANC off


Charging Your Headphones



1. Plug the Type-C charger into the charging port on the bottom of the right headphone.



2. Slot the other end of the USB cable into a power source such as a computer, laptop or wall charger.




3. The red light will turn on, indicating the headphones are charging. Charging time is approximately 2 hours. Once the headphones are fully charged, the charging indicator will turn off.
When fully charged, disconnect the headphones and remove USB cable from the power source.

NOTES:

When the headphone battery is out of power, the red LED indicator flashes once every 10 seconds. Recharge the headphones as soon as possible. The headphones cannot be operated during charging.

Pairing Your Headphones with a Bluetooth® Device




1. Turn on your headphones by pressing and holding the button  for 2 seconds until you hear the prompt "Power On" blue and red lights light alternately. The headphones are now in pairing mode and ready to be connected to your Bluetooth® device.
2. Open your Bluetooth® device. Keep the headphones and Bluetooth® enabled device within 32' (10 m) of each other during the pairing process.
3. Go to the Bluetooth® setting menu on your phone/tablet/Bluetooth® device. Connect to the device listed as "Bluebass Elite". A prompt "Connected" indicates your device has been successfully connected and the headphones are ready to use.

NOTES:


Next time you use your headphones, it will automatically attempt to connect back to the previously paired Bluetooth® device.

If the headphones do not find a connection, or are disconnected over 5 minutes, they will shut down automatically.


Connecting Your Headphones Using the Included Audio Cable



1. Slot one end of the 3.5 mm audio cable into the 3.5 mm audio cable socket on the bottom of the right headphone.



2. Slot the other end of the audio cable into the audio out socket on the device you want to connect to the headphones.



















NOTES:

When a device is connected to the headphones using the audio cable, the controls on the headphones will not work with the connected device. You will have to use the device's controls to play/pause, skip tracks and adjust the music volume.

When using a 3.5 mm audio cable, you cannot use the microphone built into the headphones.

When using the audio cable, the headphones are not required to have power.

Using Your Headphones

	Button	Function	Operation
On/Off		Turn On	Press and hold  button for 2s
		Turn Off	Press and hold  button for 5s
Music Function		Play Music	Press the  button once
		Pause Music	Press the  button once
		Next Track	Press and hold the  button
		Volume +	Press the  button once
		Previous Track	Press and hold the  button
		Volume -	Press the  button once
Mobile Phone Function		Answer Call	Press the  button once
		Call End	Press the  button once
		Reject Call	Press and hold  button for 2s
ANC Function*	ANC	ANC On	Press "ANC" button once
		ANC Off	Press "ANC" button once

*ANC function: Active Noise Cancelling Function: play in this mode when in a noisy environment.

IMPORTANT: The ANC function uses more power when turned on and will reduce the use time after the headphone is fully charged.

Specification

Bluetooth® Specifications: V 5.3

Bluetooth® Profiles Supported: HFP/A2DP/HSP/AVRCP

Effective Range: Up to 10 m (32')

Battery Capacity: 300 mAh

Charging Time: 2 hours

Playing Time (Bluetooth® only): up to 25 hours

Playing Time (Bluetooth® with ANC): up to 15 hours

Working Temperature: -5°C to + 45°C (23°F to 113°F)

Maintenance and Care

Before using your headphones, examine the headphones to make sure that they are clean. Similarly, inspect the ports and jacks of your headphones to make sure that they are clear of dust and debris before charging.

Use a soft cloth or paper towel to clean your headphone. Do not allow moisture to get inside the headphones. Never use any harsh chemicals or detergents for cleaning. Make sure your headphones are dry before using. When your headphones are not in use, they should be stored in a cool, dry place.

Never tug or yank on the USB cable while it is connected to your headphones. Connect and disconnect cables as carefully as possible.

Never expose your headphones to high temperatures, extreme cold, high humidity or excessive moisture or water.

Troubleshooting

Problem	What to do
Headphones do not power on	Headphones have run out of power; recharge for approximately 2 hours to fully charge using the USB cable.
Cannot find headphones in Bluetooth® pairing list	<ol style="list-style-type: none">1. Delete pairing list in Bluetooth® device and reconnect.2. If it still cannot be found, please restart both the Bluetooth® device and headphones.
Interrupted connection	<ol style="list-style-type: none">1. Power too low; recharge the headphones.2. Device beyond 32' (10 m) range, or the signal has been blocked by an obstacle.
No sound when calling	Check the Bluetooth® settings in your device to ensure the headphones are connected or turn the volume up on the device or headphones.
No sound when playing music	Check the Bluetooth® settings in your device to ensure the headphones are connected or turn the volume up on the device or headphones.
No sound when using the 3.5 mm audio cable	Turn the device volume up. Check the jack plugs are correctly inserted. Check the 3.5 mm audio cable has not become damaged.
Unable to charge	Check the charging cable is connected properly and that it has not been damaged. If using a charging adaptor, ensure it is inserted correctly and not damaged.

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth® SIG, Inc. and any use of such marks by Canadian Tire Corporation, Ltd. is under licence. Other trademarks and trade names are those of their respective owners.

This Class B digital apparatus complies with Canada ICES-003.

CAN ICES-3(B)/NMB-3(B)

IC: 30599-0358101

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference; and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

CAN RSS-216 / CNR-216



Product must be recycled or disposed of properly. Dispose of as per the requirements of your local municipality.

Made in China

Imported by Trileaf Distribution Toronto, Canada M4S 2B8