


CANVAS^{TM/MC}

LAWSON CONSOLE MICROWAVE STAND

PRODUCT NO. 168-0134-4



ASSEMBLY INSTRUCTIONS



HAVING TROUBLE?

TOLL-FREE:

1-888-670-6684

IMPORTANT: Please read this manual carefully before beginning assembly of this product. Keep this manual for future reference.

CANVAS™

INSPIRED BY CANADA



We believe in the power of décor and its ability to make up the fabric of your home.

That's why **CANVAS®** collections draw **inspiration from Canadians and the way they live.**

From on-trend furniture pieces to holiday décor and all your outdoor living essentials, **CANVAS®** makes it easy to refresh your space to reflect **your unique style and the way you live every day.**

We would love to hear from you and welcome your thoughtful feedback. Visit our website at **canadiantire.ca** to tell us about your experience, and share your photos with us using **#myCANVASstyle.**

Show us how you bring **CANVAS®** products to life. We can't wait to see!

TABLE OF CONTENTS



Parts List	4
Before You Begin Assembly	9
Step-by-step Guide	10
Technical Data	26
Caring for Your Item	27
Warranty	27



WARNING! TO REDUCE THE RISK OF SERIOUS INJURY, READ THE FOLLOWING SAFETY INSTRUCTIONS BEFORE ASSEMBLING AND USING THE PRODUCT.


- Please read and understand this entire manual before attempting to assemble, operate, or install the product.
- Follow all warning labels.
- Any assembly or maintenance of the product must be carried out by adults only.
- Some parts may contain sharp edges. Wear protective gloves if necessary.
- To prevent damage, place all parts on a level surface during assembly. Add a layer of protective surface if needed.
- Due to the nature of steel, surface oxidation (rusting) will occur if the protective coating is scratched. This is a natural process. To minimize this condition, it is recommended that care be taken when assembling and handling the product in order to prevent the paint from being scratched.

TOOLS REQUIRED

















NOTE: Do not over drill/
Be aware of over-drilling

No. 2 Cross-head Screwdriver
Tip Shown Actual Size









2 people


PARTS LIST

ITEM	DESCRIPTION	THUMBNAIL	QUANTITY
1	Top		1
2	Shelf		1
3	Drawer support		1
4	Rail		1
5	Left side		1
6	Right side		1
7	Bottom		1
8	Upper back		1
9	Legs		2
10	Left door		1
11	Right door		1
12	Connections		2
13	Drawer bottom		1
14	Drawer front		1

PARTS LIST














ITEM	DESCRIPTION	THUMBNAIL	QUANTITY
15	Drawer left		1
16	Drawer back		1
17	Drawer right		1
18	Drawer bottom support		1
19	H-shaped strip		1
20	Lower back		1

EXPLODED PARTS
















Warning: Before assembly, please check all accessories in the hardware box, and ensure parts are not missing.

HARDWARE LIST

ITEM	DESCRIPTION	THUMBNAIL	QUANTITY
A	Cam bolt		17
B	Cam lock		17
C	Wood dowel		18
D	Anti-tip bracket		2
E	Drawer handle		1
F	Left extension rail		1
G	Right extension rail		1
H	Left extension silde		1
I	Right extension slide		1
J	Screw		2
K	Backboard locker		6
L	Power station		1
M	Door handle		2

HARDWARE LIST

ITEM	DESCRIPTION	THUMBNAIL	QUANTITY
N	Screw		5
O	Screw		2
P	Screw		2
Q	Screw		4
R	Wall anchor		2
S	Hex screw		4
T	Hex screw		8
U	Hex key		1
V	Screw		14
W	Screw		24
X	Hinge		4
Y	Coated paper sticker		8
Z	Adjustable foot		4

BEFORE YOU BEGIN ASSEMBLY


MAKE SURE ALL PARTS ARE PRESENT

Compare all pieces to the parts and hardware lists, and make sure you have all tools required for assembly.




ASSEMBLE IN A CLEARED AREA

Place all parts from the box on the floor in front of you on a clean, dry, level surface to protect the product as it is being built.




REMOVE PACKAGING MATERIALS

Place packing materials back in the box. Do not dispose of packaging materials until assembly is complete.









READ EACH STEP CAREFULLY

Make sure you understand each step. If you have any questions, contact CANVAS® customer service at 1-888-670-6684 (toll free).




STEP-BY-STEP GUIDE

STEP 1

5 x1	6 x1	A x8	F x1	G x1	V x6
					


Insert eight cam bolts **A** into the left side **5** and right side **6**.
 Insert three screws **V** through the left extension rail **F** into the left side **5**.
 Insert three screws **V** through the right extension rail **G** into the right side **6**.
 Tighten all screws.




Note: Do not overtighten.

STEP-BY-STEP GUIDE

STEP 2








Insert two wood dowels **C** into the shelf **2**.
Attach the rail **4** onto the shelf **2**.




STEP-BY-STEP GUIDE

STEP 3


3 x1	5 x1	6 x1	B x8	C x8
				

Insert eight wood dowels **C** into the shelf **2**, rail **4** and drawer support **3**.
 Attach the left side **5** and right side **6** to the shelf **2**, rail **4** and drawer support **3**.
 Insert eight cam locks **B** into the shelf **2**, rail **4** and drawer support **3**.
 Tighten all cam locks.



STEP-BY-STEP GUIDE


STEP 4



Insert the upper back **8**, H-shaped strip **19** and lower back **20** to the groove between the left side **5** and right side **6** as shown.


Make equal margins along all four edges of the backs.

Push on opposite corners of your unit if needed to make it “square”.




STEP-BY-STEP GUIDE

STEP 5




Insert four wood dowels **C** into the left side **5** and right side **6**.
Insert four screws **Q** through the bottom **7** into the left side **5** and right side **6**.
Tighten all screws.




STEP-BY-STEP GUIDE

STEP 6



Insert four hex screws **S** through the legs **9** into the connections **12**.
Screw four adjustable feet **Z** into the legs **9**.
Tighten all screws.




STEP-BY-STEP GUIDE

STEP 7

T x8







Insert eight hex screws **T** through the legs **9** and connections **12** to the bottom **7**. Tighten all screws.



STEP-BY-STEP GUIDE


STEP 8

1 x1	A x4	D x2	O x2
			

Insert four cam bolts **A** into the top **1**.

Insert two screws **O** through the anti-tip brackets **D** into the top **1**.

Tighten all cam bolts and screws.



STEP-BY-STEP GUIDE

STEP 9


B x4



C x4




Insert four wood dowels **C** into the left side **5** and right side **6**.
Attach the top **1** to the left side **5** and right side **6**.
Insert four cam locks **B** into the left side **5** and right side **6**.
Tighten all cam locks.



STEP-BY-STEP GUIDE

STEP 10


K x6



Y x4








Place four coated paper stickers **Y** over the cam lock holes. Insert six screws **K** through the backboard lockers **K** into the groove as shown. Tighten all screws.




STEP-BY-STEP GUIDE

STEP 11

10 x1	11 x1	W x8	X x4	M x2
				

Insert eight screws **W** through the hinge **X** into the left door **10** and right door **11**. Insert two screws **M** through the left door **10** and right door **11** into the door handle **M**.

Tighten all screws.



STEP-BY-STEP GUIDE




STEP 12

W x16



Fasten the hinges to the left side **5** and right side **6**.









Insert sixteen screws **W** through the hinges **X** into the left side **5** and right side **6**. Tighten all screws.



Note: Do not overtighten.

STEP-BY-STEP GUIDE

STEP 13


14 x1	15 x1	16 x1	17 x1	A x5	E x1	J x2	N x4
							

Insert five cam locks **A** into the drawer front **14**.

Insert two screws **J** through the drawer front **14** into the drawer handle **E**.





Insert four screws **N** through the drawer left **15** and drawer right **17** into the drawer back **16**.

Tighten all screws.



STEP-BY-STEP GUIDE

STEP 14


13 x1	18 x1	B x5	N x1
			

Insert one screw **N** through the drawer back **16** into the drawer bottom support **18**. Tighten all screws.

Insert the drawer bottom **13** into the groove around the bottom of the drawer left **15**, drawer right **17** and drawer back **16**.






Attach the drawer front **14** to the drawer left **15** and drawer right **17**.

Insert five cam locks **B** into the left **15**, drawer right **17** and drawer back support **18**. Tighten screw and all cam locks.




STEP-BY-STEP GUIDE

STEP 15

V x8	H x1	I x1	L x1	Y x4
				

Insert three screws **V** through the right extension slide **I** into the drawer right **17**.
 Insert three screws **V** through the left extension slide **H** into the drawer left **15**.
 Plug the power station **L** into the hole of drawer back **16** from inside drawer.
 Insert two screws **V** through the power station **L** into the drawer back **16**.
 Tighten all screws.
 Place the coated paper stickers **Y** over the screw holes.



Note: Do not overtighten.

STEP-BY-STEP GUIDE

STEP 16


R x2




P x2



Using the anti-tip brackets **D** as a guide, mark two spots on the wall. Drill a hole at each mark and hammer two wall anchors **R** into the wall. Fasten the anti-tip brackets **D** to the wall by screwing two screws **P** into the wall anchors **R**. Insert the drawer into the unit by lining up the slide track on the drawer with the slide runner on the unit.



TECHNICAL DATA



SPECIFICATIONS

ASSEMBLED DIMENSIONS (W x D x H) 23 5/8 x 19 1/2 x 37 11/16"

60 x 49.5 x 95.7 cm

ASSEMBLED WEIGHT 58 lb 3 oz

26.4 kg

MAXIMUM WEIGHT CAPACITY (Top) 22 lb

10 kg

MAXIMUM WEIGHT CAPACITY (Shelf) 33 lb

15 kg

MAXIMUM WEIGHT CAPACITY (Drawer) 11 lb

5 kg

MAXIMUM WEIGHT CAPACITY (Bottom shelf) 26 lb 7 oz

12 kg

ASSEMBLY TROUBLESHOOTING



**BEFORE RETURNING
YOUR PRODUCT**

**HAVING TROUBLE?
LET US HELP YOU!**

**TOLL-FREE:
1-888-670-6684**

If you have questions regarding your product or require warranty assistance, please call our customer service helpline.



**CALL US;
WE CAN HELP**

CARING FOR YOUR ITEM

1

Weight Capacity:

- Do not exceed maximum weight capacity of 22 lb (10 kg) on top.
- Do not exceed maximum weight capacity of 33 lb (15 kg) on shelf.
- Do not exceed maximum weight capacity of 11 lb (5 kg) in drawer.
- Do not exceed maximum weight capacity of 26 lb 7 oz (12 kg) on bottom shelf.

2

Furniture tipping over can be dangerous. To reduce your risk:

- Do not stand on, sit on or climb this unit.
- Do not sit on top of unit.
- For indoor use only.
- Always place the unit on a flat, level surface.
- Regularly tighten all hardware to ensure unit is secure and stable.

3

Wipe clean with a damp cloth.

4

Avoid direct sunlight.

WARRANTY INFORMATION



1-YEAR LIMITED WARRANTY*

This CANVAS® product carries a one (1) year warranty against defects in workmanship and materials. Trileaf Distribution agrees to replace the defective product free of charge within the stated warranty period, when returned by the original purchaser with proof of purchase. This product is not guaranteed against wear or breakage due to misuse and/or abuse.

PRODUCT NO. 168-0134-4

Made in China

Imported by Trileaf Distribution Trifeuil Toronto, Canada M4S 2B8

CANVAS™

INSPIRED BY CANADA

