


# CANVAS™

## EVANSTON SLIM WARDROBE

---

PRODUCT NO.168-0204-8



### ASSEMBLY INSTRUCTIONS



**HAVING TROUBLE?**

**TOLL-FREE:**

**1-888-670-6684**

IMPORTANT: Please read this manual carefully before beginning assembly of this product. Keep this manual for future reference.

# CANVAS™

INSPIRED BY CANADA



To the trend seekers and design mavens.  
**CANVAS™** is the furniture and décor brand  
that helps you imagine and create a space  
you can be proud of.

That's because **CANVAS™** offers style with  
ease with products that are made for real life  
and Canadian inspired.

We would love to hear from you and welcome  
your thoughtful feedback. Visit our website  
at **canadiantire.ca** to tell us about your  
experience, and share your photos with us  
using **#myCANVAS style**.

Show us how you bring **CANVAS™** products  
to life. We can't wait to see!

## TABLE OF CONTENTS


Parts List .....	4
Before You Begin Assembly .....	9
Step-by-step Guide .....	11
Tip Restraint .....	33
Adjust Door .....	35
Adjust Levellers .....	36
Technical Data .....	37
Caring for Your Item .....	38
Warranty Information .....	39




**WARNING! TO REDUCE THE RISK OF SERIOUS INJURY, READ THE FOLLOWING SAFETY INSTRUCTIONS BEFORE ASSEMBLING AND USING THE PRODUCT.**

- Please read and understand this entire manual before attempting to assemble, operate, or install the product.
- Any assembly or maintenance of the product must be carried out by adults only.
- Some parts may contain sharp edges. Wear protective gloves if necessary.
- To prevent damage, place all parts on a level surface during assembly. Add a layer of protective surface if needed.


## TOOLS REQUIRED




Screwdriver  
(Not provided)




Level  
(Not provided)




Mallet  
(Not provided)



Power drill  
(Not provided)
















2 people















**NOTE:** Do not over-drill.  
Be aware of over-drilling.


## PARTS LIST

ITEM	DESCRIPTION	THUMBNAIL	QUANTITY
1	Top panel		1
2	Bottom panel		1
3	Left panel		1
4	Right panel		1
5	Back panel		1
6	Fixed shelf		1
7	Front apron		1
8	Left apron		1
9	Right apron		1
10	Back apron		1
11	Drawer front panel		1
12	Drawer left panel		1
13	Drawer right panel		1














## PARTS LIST

ITEM	DESCRIPTION	THUMBNAIL	QUANTITY
14	Drawer back panel		1
15	Drawer bottom		1
16	Drawer front panel		1
17	Drawer left panel		1
18	Drawer right panel		1
19	Drawer back panel		1
20	Drawer bottom		3
21	Drawer front panel		2
22	Drawer left panel		2
23	Drawer right panel		2
24	Drawer back panel		2
25	Door		1










## EXPLODED VIEW



## HARDWARE LIST

ITEM	DESCRIPTION	THUMBNAIL	QUANTITY
A	Cam lock ø15x12mm		32
B	Cam bolt		46
C	Wood dowel ø8x30mm		32
D	Hinge		4
E	Screw ø4x14mm		28
F	Handle		1
G	Bolt ø4x22mm		2
H	Rod		1
I	10" slide		2
J	12" slide		6
K	Screw ø3.5x12mm		64
L	Cam lock ø15x10mm		14
M	Screw ø4x38mm		16

## HARDWARE LIST


ITEM	DESCRIPTION	THUMBNAIL	QUANTITY
N	Wood dowel		2
O	Hanging rod support		2
P	Coated paper sticker		18
Q	Adjustable leveller		4
R	Screw ø4x55mm		2
S	Screw ø4x18mm		2
T	Metal bracket		4
U	Anchor		2
V	Nylon strap		2



## BEFORE YOU BEGIN ASSEMBLY


### MAKE SURE ALL PARTS ARE PRESENT

Compare all pieces to the parts and hardware lists, and make sure you have all tools required for assembly.




### ASSEMBLE IN A CLEARED AREA

Place all parts from the box on the floor in front of you on a clean, dry, level surface to protect the product as it is being built.



### REMOVE PACKAGING MATERIALS

Place packing materials back in the box. Do not dispose of packaging materials until assembly is complete.



### READ EACH STEP CAREFULLY


Make sure you understand each step. For any questions, contact CANVAS™ customer service at 1-888-670-6684 (toll free).




## BEFORE YOU BEGIN ASSEMBLY

**NOTE:** IT IS VERY IMPORTANT TO USE GLUE WITH DOWELS. EXCESS GLUE CAN BE WIPED OFF WITH DAMP CLOTH.

Insert the dowel at least half way by tapping lightly with a rubber mallet IF NECESSARY.



## CAM LOCK SYSTEM OPERATION



## HOW THE KNOCK DOWN (KD) ASSEMBLY SYSTEM WORKS

1. Screw the cam bolt into the pre-drilled threaded holes on the panel. Connect both panels together making sure cam bolt goes into the pre-drilled large hole on the end of panel that will accommodate the cam lock.
2. Insert the cam lock into the pre-drilled large hole on the panel. Make sure the arrow on the face of cam lock faces out and points towards cam bolt.
3. Take a cross-head screwdriver and rotate the cam lock clockwise to lock the cam bolt in place.


## SPECIAL NOTE

Please read the instruction sheets completely before assembly. Examine all packaging material before discarding carton. Remove all parts from carton and separate into groups as indicated on parts list. Please ensure all parts are included prior to assembly. Use of power tools to complete assembly is not recommended.

**You are now ready to assemble the KD unit.**


## STEP-BY-STEP GUIDE

### STEP 1









Slides must be separated before assembly.  
After separation, set aside until needed for assembly.

Push lever up, then remove runner.



## STEP-BY-STEP GUIDE


### STEP 2

<b>3</b> X 1	<b>4</b> X 1	<b>B</b> X 12	<b>C</b> X 8	<b>E</b> X 4	<b>O</b> X 2
					

Attach twelve cam bolts **B** to left panel **3** and right panel **4**. Do not over-tighten.





Attach two hanging rod supports **O** to left panel **3** and right panel **4** using two screws **E** each.

Insert eight wood dowels **C** into left panel **3** and right panel **4**.



## STEP-BY-STEP GUIDE

### STEP 3


<b>1</b> X 1	<b>5</b> X 1	<b>B</b> X 6	<b>C</b> X 8
			

Attach six cam bolts **B** to top panel **1**. Do not over-tighten.

Insert eight wood dowels **C** into back panel **5**.




**TEAM LIFT**  
DO NOT LIFT ALONE






## STEP-BY-STEP GUIDE

### STEP 4




Attach one 10" slide **I** and three 12" slides **J** to left panel **3** using three screws **K** each. Make sure slide's open end and slide roller face the same direction.





## STEP-BY-STEP GUIDE

### STEP 5



Attach one 10" slide **I** and three 12" slides **J** to right panel **4** using three screws **K** each. Make sure slide's open end and slide roller face the same direction.





## STEP-BY-STEP GUIDE

### STEP 6

**A** X 4




Attach back panel **5** and left panel **3** using four cam locks **A**. Tighten cam locks **A**.






## STEP-BY-STEP GUIDE

### STEP 7



Insert four wood dowels **C** into fixed shelf **6**. Then attach fixed shelf **6** to left panel **3** using two cam locks **A**. Tighten cam locks **A**.



## STEP-BY-STEP GUIDE

### STEP 8

**A** X6




Attach right panel **4** to back panel **5** and fixed shelf **6** using six cam locks **A**.

Tighten cam locks **A**.




**TEAM LIFT**  
DO NOT LIFT ALONE



## STEP-BY-STEP GUIDE


### STEP 9



Attach top panel **1** to left panel **3**, right panel **4** and back panel **5** using six cam locks **A**.






Tighten cam locks **A**.

Cover cam locks **A** using four coated paper stickers **P** on left panel **3** and right panel **4**.




## STEP-BY-STEP GUIDE

### STEP 10


<b>7</b> X 1	<b>8</b> X 1	<b>9</b> X 1	<b>10</b> X 1	<b>C</b> X 12
				

Insert twelve wood dowels **C** into front apron **7**, left apron **8**, right apron **9** and back apron **10**, then attach front apron **7**, left apron **8**, right apron **9** and back apron **10** together as shown.




## STEP-BY-STEP GUIDE

### STEP 11






Attach eight cam bolts **B** to bottom panel **2**. Do not over-tighten.

Attach front apron **7**, left apron **8**, right apron **9** and back apron **10** to bottom panel **2** using eight cam locks **A**. Tighten cam locks **A**.




## STEP-BY-STEP GUIDE

### STEP 12

<b>B</b> X 6	<b>K</b> X 16	<b>Q</b> X 4
		

Attach four adjustable levellers **Q** using four screws **K** each.

Turn piece over 180 degrees. Attach six cam bolts **B** to bottom panel **2**. Do not over-tighten.




## STEP-BY-STEP GUIDE

### STEP 13

**A** X 6











Attach bottom panel **2** to left panel **3**, right panel **4** and back panel **5** using six cam locks **A**. Tighten cam locks **A**.



## STEP-BY-STEP GUIDE


### STEP 14

<b>11</b> X 1	<b>12</b> X 1	<b>13</b> X 1	<b>15</b> X 1	<b>B</b> X 2	<b>L</b> X 2
					
<b>N</b> X 2	<b>P</b> X 2				
					

Attach two cam bolts **B** to drawer front panel **11**. Do not over-tighten. Insert two wood dowels **C** into drawer left panel **12** and drawer right panel **13**.

Attach drawer left panel **12** and drawer right panel **13** to drawer front panel **11** using two cam locks **L**. Tighten cam locks **L**. Cover cam locks **L** using two coated paper stickers **P**.





Insert drawer bottom panel **15** as shown.






## STEP-BY-STEP GUIDE

### STEP 15

<b>14</b> X 1	<b>I</b> X 2	<b>K</b> X 6	<b>M</b> X 4
			








Attach drawer back panel **14** to drawer left panel **12** and drawer right panel **13** using four screws **M**.

Attach two 10" slides **I** to drawer left panel **12** and drawer right panel **13** using three screws **K** each.



## STEP-BY-STEP GUIDE


### STEP 16

<b>16</b> X 1	<b>17</b> X 1	<b>18</b> X 1	<b>20</b> X 1	<b>B</b> X 4	<b>L</b> X 4	<b>P</b> X 4
						

Attach four cam bolts **B** to drawer front panel **16**. Do not over-tighten.


Attach drawer left panel **17** and drawer right panel **18** to drawer front panel **16** using four cam locks **L**. Tighten cam locks **L**. Cover cam locks **L** using four coated paper stickers **P**.

Insert drawer bottom panel **20** as shown.




## STEP-BY-STEP GUIDE

### STEP 17










Attach drawer back panel **19** to drawer left panel **17** and drawer right panel **18** using four screws **M**.

Attach two 12" slides **J** to drawer left panel **17** and drawer right panel **18** using three screws **K** each.



## STEP-BY-STEP GUIDE

### STEP 18


<b>20</b> X 2	<b>21</b> X 2	<b>22</b> X 2	<b>23</b> X 2	<b>B</b> X 8	<b>L</b> X 8
					
<b>P</b> X 8					
					

Attach four cam bolts **B** to drawer front panel **21**. Do not over-tighten.

Attach drawer left panel **22** and drawer right panel **23** to drawer front panel **21** using four cam locks **L**. Tighten cam locks **L**. Cover cam locks **L** using four coated paper stickers **P**.


Insert drawer bottom panel **20** as shown.

Repeat for the other drawer.



## STEP-BY-STEP GUIDE


### STEP 19



Attach drawer back panel **24** to drawer left panel **22** and drawer right panel **23** using four screws **M**.






Attach two 12" slides **J** to drawer left panel **22** and drawer right panel **23** using three screws **K** each.

Repeat for the other drawer.




## STEP-BY-STEP GUIDE

### STEP 20

<b>25</b> X 1	<b>D</b> X 4	<b>E</b> X 8	<b>F</b> X 1	<b>G</b> X 2
				

Attach four hinges **D** to door **25** using two screws **E** each.


Attach handle **F** to door **25** using two bolts **G**.



## STEP-BY-STEP GUIDE




### STEP 21

**H** X 1



Pull the inner ball bearing slides on each side all the way out until they stop, then insert all drawers as shown (may be slightly greasy).

Attach rod **H** as shown.



## STEP-BY-STEP GUIDE

### STEP 22


**E** X 16



Attach door **25** to left panel **3** using sixteen screws **E**.







**TEAM LIFT**  
DO NOT LIFT ALONE





## TIP RESTRAINT



### STEP 23

R X 2	S X 2	T X 4	U X 2
			

Pick your desired area of placement. Drill two small holes approximately 3/8" (9.5 mm) in diameter and approximately 2" (5 cm) deep. Use a level to make sure the two holes you drill are level. After you drill the holes, insert wall anchors **U** into wall.

Attach metal brackets **T** to wall using screws **R**.

Attach metal brackets **T** to top panel **1** using screws **S**.



Caution! If installing the unit on drywall or other hollow wall applications, the metal bracket must be fastened to studs, headers, or other structural wall supports. The included anchors are intended for use with solid wall applications only (tile or concrete).

**DO NOT USE WITH DRYWALL OR OTHER HOLLOW WALL APPLICATIONS.**

## TIP RESTRAINT

### STEP 24


V X 2





Attach cabinet to wall using two nylon straps **V** as shown.



**WARNING!** TO REDUCE THE RISK OF SERIOUS INJURY AND AVOID THE POTENTIAL FOR FURNITURE TIPPING OVER, INSTALL THE TIP-OVER RESTRAINT HARDWARE.



## ADJUST DOOR




(front view)

If doors are not aligned:

Loosen "A" screws.

Adjust door.

Tighten "A" screws.




(front view)

If there is a gap between doors:

Loosen "C" screw.

Turn "B" to move door.

Tighten "C" screw.



(side view)

If there is a gap between door and side panel:


Loosen "B" and "C" screw.

Adjust door.


Tighten "B" and "C" screw.

## ADJUST LEVELLERS

Note: If your item is not level, put it on a hard surface, then adjust the levellers.



## TECHNICAL DATA



## SPECIFICATIONS

### ASSEMBLED DIMENSIONS (W x D x H)

53.3 x 55.9 x 198.1 cm

21 x 22 x 78"

### ASSEMBLED WEIGHT

77.4 kg

170 lb 10 oz

### MAXIMUM WEIGHT CAPACITY

Drawer: 6.8 kg; Shelf: 13.6 kg; Rod: 13.6 kg

Drawer: 15 lb; Shelf: 30 lb; Rod: 13.6 kg

## ASSEMBLY TROUBLESHOOTING



**BEFORE RETURNING  
YOUR PRODUCT**

**HAVING TROUBLE?  
LET US HELP YOU!**

**TOLL-FREE:  
1-888-670-6684**

If you have questions regarding your product or require warranty assistance, please call our customer service helpline.



**CALL US;  
WE CAN HELP**

## CARING FOR YOUR ITEM

- 1 Always use unit with tip-restraints installed as per instructions.
- 2 Always keep children under close supervision while they are using or around this product. Never leave children unattended.
- 3 For household use only.
- 4 Wipe clean with damp cloth.

## WARRANTY INFORMATION



### 1-YEAR LIMITED WARRANTY

This CANVAS™ product carries a one (1) year warranty against defects in workmanship and materials. Trileaf Distribution agrees to replace the defective product free of charge within the stated warranty period, when returned by the original purchaser with proof of purchase. This product is not guaranteed against wear or breakage due to misuse and/or abuse.

PRODUCT NO. 168-0204-8

Made in China

Imported by Trileaf Distribution Trifeuil Toronto, Canada M4S 2B8

# CANVAS™

INSPIRED BY CANADA

