


IMPORTANT NOTICE

Please see HOW TO MOVE THE TREADMILL on page 15 of the user's manual. Read and understand the instructions below before you move the treadmill.

CAUTION: Do not move the treadmill while it is folded.

To reduce the risk of injury, raise the uprights (A) to the locked position shown at the right before you move the treadmill. In addition, remove the key from the console and unplug the power cord. You must be able to safely lift 45 lbs. (20 kg) to raise, lower, or move the treadmill.



AVIS IMPORTANT

Veuillez vous référer à la section COMMENT DÉPLACER LE TAPIS DE COURSE page 15 du manuel de l'utilisateur. Lisez les directives ci-dessous pour bien les comprendre avant de déplacer le tapis de course.

MISE EN GARDE : ne déplacez pas le tapis de course dans sa position pliée.

Pour réduire le risque de blessures, élevez les montants (A) à la position verrouillée tel qu'illustré à droite avant de déplacer le tapis de course. De plus, retirez la clé de la console et débranchez le cordon d'alimentation. Vous devez être en mesure de soulever sans danger un poids de 45 lb (20 kg) pour élever, abaisser ou déplacer le tapis de course.

